

Welding torch for robot with a built-in shock sensor

M I G

Coaxial power cable for robot



MTXA-2531 MTXCA-2531

MTXAW-5031 MTXCAW-5031

Instruction Manual
 = Safety and Operation =

Instruction Manual No.
 1L7060-E-2

First thoroughly read this manual to operate the machine correctly.

- Installation, maintenance, and repair of this welding machine should be made by qualified persons or persons who fully understand welding machines for extra safety.
- Operation of this welding machine should be made by persons who have knowledge and technical skill to understand the contents of this manual well and handle the machine safely for extra safety.
- Regarding safety education, utilize courses and classes held by head/branch offices of the Welding Society/Association and the related societies/associations and qualifying examinations for welding experts/consultant engineers.
- After thoroughly reading this manual first, store it with the warranty in the place where the persons concerned can read at any time. Read it again as occasion demands.
- If incomprehensible, contact our offices. For servicing, contact our local distributor or sales representatives in your country. Our addresses and telephone numbers are listed in the back cover of this Instruction Manual.


Contents


- ① NOTES ON SAFETY S1
- ② IMPORTANT SAFEGUARDS S2
- ③ PRECAUTIONS IN OPERATING S6
- 1. Specifications of welding torch for robot1
- 2. Receiving inspection1
- 3. Outline drawing of welding torch for robot2
- 4. Mounting and adjusting welding torch.....4
- 5. Coaxial power cable for robot9
- 6. Setting robot control.....10
- 7. Trouble shooting.....13
- 8. Parts for replacement in changing welding wire diameter13
- 9. Parts list.....15


NOTES ON SAFETY


1. Notes on Safety

- Before operating this product, you should first thoroughly read this Instruction Manual to operate the product correctly.
- Precautions in this Instruction Manual are described to prevent you and others from being injured and suffering loss in your property by having the product operated correctly and safely.
- This welding machine is designed and manufactured in due consideration of safety, but you should observe the handling precautions described in this Instruction Manual. If you fail to do so, there may occur an accident resulting in serious injury or death.
- Various ranks of accidents resulting in injury, death or damage may be caused by the mishandling of devices. The following safety alert symbols and signal words are used throughout this manual to identify various hazards and special instructions.

 **DANGER** : Mishandling may create seriously dangerous situation that could cause serious injury or death to personnel. Limited situation of great urgency.


 **WARNING** : Mishandling may create a dangerous situation that could cause serious injury or death to personnel.

 **CAUTION** : Mishandling may create a dangerous situation that could cause medium or slight injury to personnel, or material damage.

Hazards and special instructions identified by  **CAUTION** are very important as well because neglecting them may occasionally cause serious injury or death to personnel. Do follow the instructions identified by all three safety alert symbols and signal words because they are all very important.

The meanings of "serious injury", "medium or slight injury" and "material damage" are as follows.


- Serious injury : Injury with a sequela due to a loss of eyesight, injury, burn (high temperature and low temperature), electric shock, a bone fracture, poisoning and so on as well as injury that requires hospital treatment or long treatment as an outpatient.
- Medium or slight injury : Injury, burn, electric shock and so on that require no hospital treatment nor long treatment as an outpatient.
- Material damage : Damage to property, and direct and incidental / consequential damage due to the damage to devices.

Ref.:  **IMPORTANT** : IMPORTANT statements identify special instructions necessary for the most efficient operation.

IMPORTANT SAFEGUARD



2. Precautions for Safety

2.1 Read, understand, and comply with all safety rules described at the beginning of the welding power source manual in addition to the following before initiating arc welding operations.

 WARNING	<ul style="list-style-type: none"> ● Observe the following to prevent a serious accident that results in a serious injury or a death
--------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------

- 1) This wire feeding reducer is designed and manufactured in due consideration of safety, but you should observe the handling precautions described in this Instruction Manual. If you fail to do so, there may occur an accident resulting in a serious injury or a death.
- 2) Related laws and regulations and your company's standards should be observed in constructing input power source, selecting an installation area, handling/storing/piping high pressure gas, storing welded products, and disposing wastes.
- 3) Keep out of the moving zone of a welding machine and the welding area.
- 4) A person with a pacemaker should not go near the operating welding machine and the welding area unless his or her doctor permits. A welding machine generates a magnetic field around it during powered, and that will have a bad effect on the pacemaker.
- 5) Installation, maintenance and repair of this wire feeding reducer should be done by qualified personnel or those who fully understand a welding torch for further safety.
- 6) Operation of this wire feeding reducer should be done by personnel who have knowledge and technical skill to be able to understand the contents of this manual well and to handle the wire feeding reducer safely.
- 7) This wire feeding reducer must not be used for purposes other than welding.



2.2 Observe the following to prevent an electric shock.

 WARNING	<ul style="list-style-type: none"> ● Do not touch live electrical parts .
	<ul style="list-style-type: none"> ● Touching live electrical parts can cause fatal shock or severe burns.

- 1) Only qualified personnel should do the grounding work of the welding power source and a workpiece, or a workpiece and powered peripheral jigs while abiding by domestic regulations.
- 2) Do not touch live electrical parts.
- 3) Always wear dry insulating gloves and other body protection. Do not wear torn or wet gloves and work clothes.
- 4) Before doing the installation, inspection, maintenance, etc. of this product, be sure to turn off all the input power sources and check, several minutes later, that there is no charging voltage since the condenser and the like may have been recharged.
- 5) Do not use cables with insufficient capacity, with damage, or with naked conductors.
- 6) Be sure to tighten the connections of cables and insulate them in order to prevent personnel from touching those parts easily.
- 7) DO NOT use a welding machine with its case or cover removed.
- 8) Secure a firm foothold before initiating work. DO NOT perform work with an unstable foothold or with a foothold at a height of two meters or above.
- 9) Make periodic inspection and maintenance. Damaged parts should be repaired before use.
- 10) Turn off POWER switch when not in use.



IMPORTANT SAFEGUARD (continued)

2.3 All the personnel in and around the working area including an operator should wear appropriate protection to protect themselves from arc rays, spatters, slag and noise produced by welding.

 WARNING	<ul style="list-style-type: none"> ● Install a lightproof wall where arc is generated. ● Wear appropriate eye, ear, and body protection.
	<ul style="list-style-type: none"> ● Arc rays may cause inflammation of eyes and burns on skin ● Spatter s and slag may cause eye troubles and burns. ● Noise may cause hearing problems.

- 1) Wear lightproof glasses or a welder's shield helmet with a proper shade of filter when welding or watching a welder work.
- 2) **INSTALL ARC PROTECTIVE CURTAINS** in between an operator and arc rays.
- 3) **WEAR PROPER SAFETY GLASSES** in work area at all times.
- 4) **WEAR PROPER EAR PROTECTION.**
- 5) **WEAR PROPER BODY PROTECTION** including woolen clothing, flameproof apron and gloves, leather leggings, high boots and leather arm and shoulder gauntlets.
- 6) **WEAR PROPER SAFETY GLASSES** to protect eyes and skin from spatters and slag.



2.4 All the personnel in and around the working area including an operator should wear appropriate protection to protect themselves from fumes and gases produced by welding.

 WARNING	<ul style="list-style-type: none"> ● DO NOT inhale fumes and gases generated by welding. ● Ventilate the area sufficiently and wear a welder's shield mask if necessary.
	<ul style="list-style-type: none"> ● Fumes and gases generated by welding have a harmful effect on human body. ● Welding in a small area may cause suffocation due to the lack of air.

- 1) **KEEP YOUR HEAD** out of fumes and **DO NOT** inhale any.
- 2) **USE FORCED EXHAUST VENTILATION** at the arc.
- 3) **VENTILATE** the area to prevent build-up of fumes and gases.
- 4) If ventilation is insufficient, **USE APPROVED BREATHING DEVICES.**
- 5) **READ AND FOLLOW WARNING LABELS** on all containers of welding materials.
- 6) Before use, **READ AND UNDERSTAND** the manufacture's instructions, Material Safety Data Sheets (MSDSs), and follow your employer's safety practices.
- 7) To prevent gas poisoning and suffocation, use a local ventilator or a respirator specified by your country's domestic laws.
- 8) Be sure to ventilate the area or wear a respirator by welding in a small place.
A well-trained watchman should observe the work.
- 9) Do not weld near the place where degreasing, cleaning or spraying is carried out. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases. If welding is carried out there, harmful gases may be produced.
- 10) Toxic fumes and gases are produced when coated steel is welded.
Be sure to ventilate the area sufficiently or use a respirator.

IMPORTANT SAFEGUARD (continued)

2.5 Prevent fire, explosion, burns and injury caused by heated workpiece, spatters, slag, and arc sparks right after welding as described below.

 WARNING	<ul style="list-style-type: none">● Do not weld near flammable materials.● Watch for fire: keep a fire extinguisher nearby.● NEVER do welding on inflammables such as a piece of wood or cloth.● Do not weld on closed containers.
	<ul style="list-style-type: none">● Heated workpiece, spatters, slag and arc sparks right after welding may cause fire.● Incomplete cable connections, incomplete contacts in the current circuit of the workpiece such as steel frames may cause a fire due to the heat generated when powered.● Arc generated on containers of inflammables such as gasoline may cause an explosion.● Welding of airtight tanks and pipes may cause a bursting.● Touching a heated workpiece, spatters, slag or arc sparks will cause a serious burn.

- 1) KEEP FLAMMABLE MATERIALS out of the robotic cell.
- 2) Welders should wear appropriate protection such as flameproof leather gloves, work clothes with long sleeves, a leg cover, a flameproof leather apron in order to prevent burns caused by touching heated workpiece, spatters, slag and arc sparks right after welding..
- 3) WATCH for fire.
- 4) Have a fire extinguisher nearby. Operators should know how to use it.
- 5) DO NOT touch heated workpiece and peripheral jigs with inflammables such as a piece of wood or cloth. Doing so might cause not only a fire but also burns.
- 6) DO NOT put heated workpiece close to inflammables right after welding.
- 7) Remove inflammables from the place where welding is carried out so that spatters and slag will not strike them.
- 8) Do not use inflammable gases near the welding sight.
- 9) Tighten and insulate the cable connections completely.
- 10) Connect the cables on the workpiece side as close to the welding area as possible to prevent the welding current from traveling along unknown paths and causing electric shock and fire hazards.
- 11) A gas pipe with gas sealed in, an airtight tank and a pipe must not be welded because they might explode.
- 12) NEVER do welding on inflammables such as a piece of wood or cloth.
- 13) When welding a large-size structure such as a ceiling, floor, wall, etc., remove any inflammables hidden behind a workpiece.

IMPORTANT SAFEGUARD (continued)

For reference purposes

PRINCIPAL SAFETY STANDARDS

Safety in Welding and Cutting, ANSI Standard Z49.1, from American Welding Society.

Safety and Health Standards, OSHA 29 CFR 1910, from Superintendent of Documents, U.S. Government Printing Office.

Recommended Practices for Plasma Arc Cutting, American Welding Society Standard AWS C5.2, from American Welding Society.

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers That Have Held Hazardous Substances, American Welding Society Standard AWS F4.1, from American Welding Society.

National Electrical Code, NFPA Standard 70, from National Fire Protection Association.

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association.

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association, Standards Sales.


Safe Practices For Occupation And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute.

Cutting And Welding Processes, NFPA Standard 51B, from National Fire Protection Association.

PRECAUTIONS IN OPERATING


3. Precautions in operating

3.1 Duty cycle

 CAUTION	<ul style="list-style-type: none"> ● Observe the following to prevent a serious accident that results in a serious injury or a death
--------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------



Welding torch	Rated duty cycle
MTXA-2531	250A 70%
MTXCA-2531	
MTXAW-5031	500A 70%
MTXCAW-5031	

- The rated duty cycle of 70% means that the torch is operated at the rated welding current for 7 minutes out of 10 minutes and suspended for 3 minutes.
- If the torch is operated at more than the rated duty cycle, the welding torch temperature rises over the allowable value to cause to be burnt and cause a burn.
- When MTXAW-5031/MTXCAW-5031 is operated, feed water with a water pump without fail. If no water is circulated, the welding torch temperature rises over the allowable value to cause to be burnt and cause a burn.




PRECAUTIONS IN OPERATING


3.2 Inching

 WARNING	<ul style="list-style-type: none">● Do not look into the tip hole in inching to cheek.● In inching, the welding torch tip must not be put near to your face, eye, and body.
	<ul style="list-style-type: none">● Do not look into the tip hole in inching to check if the wire is fed. The wire may spring out and stick into your face, eyes, and body. It is very dangerous.● In inching, the welding torch tip must not be put near to your face, eyes, and body. The wire may spring out and stick into your face, eyes, and body to injure.


3.3 Replacement of Parts

 CAUTION	<ul style="list-style-type: none">● To prevent burns, observe the following.
--------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------


- Do not directly touch the high-temperature parts of a nozzle, an electrode and so on.
- When welding, wear suitable protection such as leather gloves for welding.
- Do not replace torch tip elements before they cool off.

 CAUTION	<ul style="list-style-type: none">● If any parts are damaged, replace them with new ones for further safety and better quality.
----------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------

- Be sure to place an order for replacement at our sales office or our agency.


 CAUTION	<ul style="list-style-type: none">● Do not disassemble the shock sensor. If disassembled, gas leak and malfunction may be caused.
----------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------

3.4 Coolant

 CAUTION	<ul style="list-style-type: none">● Be sure to keep the flow of coolant. Insufficient flow of coolant may damage a welding torch.
----------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------

- NEVER apply air-cooling for water-cooled torch.
- NEVER use a welding torch that had a water leak because doing so might cause an electric shock.

3.5 Cable hose

 CAUTION	<ul style="list-style-type: none">● Never let cable hoses touch any heated part of the welded, put something heavy on top nor bend them excessively because the welding torch might become damaged.
----------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

1. Specifications of welding torch for robot

Table 1.1 Specifications

Model	MTXA-2531	MTXCA-2531	MTXAW-5031	MTXCAW-5031
Torch type	Straight	Curved	Straight	Curved
Welding process	MIG			
Max. operating current	250A		500A	
Rated duty cycle	70%		70%	
Applicable wire diameter	(ϕ 1.0) , ϕ 1.2		(ϕ 1.2) , ϕ 1.6	
Cooling system	Air cooling		Water cooling	
Wire used	Aluminum Welding wires			
Shock sensor	Built in			
Mass	1.5(kg)	1.6(kg)	1.6(kg)	1.7(kg)

Notes: 3. MTXAW-5031/MTXCAW-5031 should be used with feeding water with water pump (PU301).

4. Shock sensor: The welding torch of an arc welding robot may sometimes touch with a work or jigs to cause deformation of the torch or damage of the manipulator. To prevent such an accident, this welding torch is equipped with a built-in shock sensor. When the torch tip (nozzle) is pressed by external force beyond the specified value, the nozzle evades due to the external force with outputting the external force detection signal to stop the manipulator immediately.

2. Receiving inspection





MTXA-2531	MTXCA-2531
 <p>Welding torch main body Mounting bolt (M5×40) .4 pieces Spring washer (M5).....4 pieces</p>	 <p>Welding torch main body Mounting bolt (M5×40). 4 pieces Spring washer (M5) 4 pieces</p>
MTXAW-5031	MTXCAW-5031
 <p>Welding torch main body Mounting bolt (M5×40)4 pieces Spring washer (M5).....4 pieces Wrench1 piece Cooling water hose(6m) ... 2 pieces</p>	 <p>Welding torch main body Mounting bolt (M5×40)4 pieces Spring washer (M5).....4 pieces Wrench1 piece Cooling water hose(6m) ... 2 pieces</p>

Fig. 2.1 Receiving inspection

Note 1: MTXAW-5031/MTXCAW-5031 water-cooled torch requires to operate with water pump. The water pump should be purchased separately.

3. Outline drawing of welding torch for robot(for MIG welding)




Fig. 3.1 Outline drawing (1) Unit: mm

4. Mounting and adjusting welding torch

4.1 Mounting on DR-600,603,606,610,4000,4200,4200L,4300,4400

4.1.1 Mounting torch






Fig. 4.1 Mounting curved torch

4.1.2 Mounting torch gauge Tip gauge ASSY

L317X (for 350A torch) Extension 15mm	L317Z (for 500A torch) Extension 20mm
	
MTX-3531 MTXC-3531 MTXB-3531 MTXCB-3531	MTX-5031 MTXC-5031 MTXW-5031 MTXCW-5031




Fig. 4.2 Mounting torch gauge for curved torch

4.1.3 Adjusting torch




Fig. 4.3 Adjusting torch

4.2 Mounting on DR-3000,3200

4.2.1 Mounting torch






Fig. 4.4 Mounting torch

4.2.2 Mounting torch gauge

Tip gauge ASSY	
L317X (for 350A torch)	L317Z (for 500A torch)
Extension 15mm	Extension 20mm
	
MTX-3531 MTXC-3531 MTXB-3531 MTXCB-3531	MTX-5031 MTXC-5031 MTXW-5031 MTXCW-5031





Fig. 4.5 Mounting torch gauge

4.2.3 Adjusting torch




Fig. 4.6 Adjusting torch

4.4 Connecting water-cooled torch (for MTXAW-5031/MTXCAW-5031)




Fig. 4.8 Connecting water-cooled torch

4.4 Precautions in handling torch

- (1) Spatter on the nozzle or contact tip should be removed earlier.
- (2) DAIHEN special tip should be selected. Tip with a larger hole diameter may induce input power failure or wire deflection to cause unstable arc or target deviation. Replace it at an appropriate time.
- (3) Gas flow rate should be min. 15 l/min or more.
- (4) Wire cut dust or any other dust accumulated in the liner (in coaxial power cable), inner liner, tip nut may cause wire feeding failure and have a bad influence on welding. Clean it with compressed air every 10 days.
- (5) Direction to install inner liner (MTXAW-5031, MTXCAW-5031)

Insert the inner liner into the tip nut so that the tip of the inner liner made of copper faces the tip nut.

However, do the replacement work after the circulator of cooling water (PU-301) has been completely stopped, otherwise water will leak to the outside when the nozzle is removed.

- (6) If wire is caught at the tip end (wire stick), the wire may be buckled in the liner or cut at the feeding roll. If feeding wire is continued as it is, it may cause feeding failure or arc shortage. Remove the wire from the feeding roll to the tip end and renew the wire.
- (7) When it is taught to evacuate the torch from the work after welding, teach to pull up on the slant so that the shock sensor may work even if the wire and the base metal stick.




Fig. 4.9 Evacuating direction

- (8) Precautions in replacing O-ring

Take care to replace O-ring of water-cooled torch (MTXAW-5031/MTXCAW-5031) as the O-ring in the insulator may be easily damaged by the tip body screw.

The O-ring damaged may cause water leakage.




Fig. 4.10 Replacing O-ring

5. Coaxial power cable for robot

5.1 Types of coaxial power cables

Table 5.1 Types of coaxial power cables

Model	Nominal cable length	Robot applicable	Note
L-6611	1.1 m		△
L-6612	1.2 m	DR-4000,4200,4300,4400	●
L-6613	1.3 m		●
L-6614	1.4 m		△
L-6615	1.5 m	DR-606,610,4200L	●
L-6616	1.6 m		△
L-6618	1.8 m	DR-503P,R	●
L-6621	2.1 m	DR-3000,3200	●
L-6625	2.5 m	DR-503S,600,603	●

●Standard stock, △Make to order

Note: The liner and the outlet guide built in as standard are iron.

Arrange the liner and the outlet guide for aluminum.




Fig. 5.1 Outline drawing of coaxial power cable

5.2 Connecting coaxial power cable

5.2.1 Cut length of liner




Table 5.2 Cut length of liner

Torch (type)	L (mm)
MTXA-2531	151
MTXCA-2531	151
MTXAW-5031	158
MTXCAW-5031	158

Fig. 5.2 Cutting liner

- Cut the liner of coaxial power cable to the L-dimension depending on each torch to use.
- After removing burrs from the liner's cut plane by filing, cut the edge of the plane as shown in the right-hand figure.
- Be careful not to bend the liner nor clash the hole.

5.2.2 Connecting coaxial power cable




Fig. 5.3 Connecting

6. Setting robot control

6.1 Checking tool parameters

In delivering a robot, the welding data used (tool parameters) are already preset. These data do not have to be changed unless the torch or others are changed. Check if the following data are preset.

Table 6.1 Setting tool parameters

DR-4000,4200,4200L,4300,4400, DR-503,DR-600,603,606,610 series (DR CONTROL)

Model	MTXA-2531	MTXCA-2531	MTXAW-5031	MTXCAW-5031
Parameter 1	140.0	140.0	140.0	140.0
Parameter 2	0.0	0.0	0.0	0.0
Parameter 3	385.0	400.0	385.0	400.0
Parameter 4	0.0	0.0	0.0	0.0
Parameter 5	0.0	0.0	0.0	0.0
Parameter 6	180 (0)	180 (0)	180 (0)	180 (0)

* Values in () for Parameter 6 applies to Controls OSACOMsuper8700 (C² ROBOT CONTROL)

DR-3000,3200 (DR CONTROL)



Model	MTXA-2531	MTXCA-2531	MTXAW-5031	MTXCAW-5031
Parameter 1	-285.0	-285.0	-285.0	-285.0
Parameter 2	0.0	0.0	0.0	0.0
Parameter 3	Note)29.0	Note)29.0	Note)29.0	Note)29.0
Parameter 4	-90	-90	-90	-90
Parameter 5	-90	-90	-90	-90
Parameter 6	180 (0)	180 (0)	180 (0)	180 (0)



* Values in () for Parameter 6 applies to Controls α.ROBOT CONTROL


Important









Even if you select the inch unit by user parameters, the torch parameters 1 to 3 are set by millimeters.


If the data in Table 6.1 are not preset, change to them according to the following procedure.




1. Put the breaker handle mounted on the robot control door to the ON position to supply power. After initial diagnosis completed, the right display appears.
2. Press the servo ON button on the teach pendant or on the operation box, and servo power is supplied.
3. Press  key and next  key (Parameter), and the right display appears.






4. Press  key (System), and the right display appears.



TEACH	EACH AXIS	MH3	SERVO ON
System			
> Initial mode		Auto	1/7
Auto mode interlock		Disabled	
Teach mode interlock	Enabled		
Control system		Remote	
Application set			
Program list display		In order of date	
			>

5. Press  key (Next page) twice to move to the right display (Page 3/7).


TEACH	EACH AXIS	MH3	SERVO ON
System			
> Home position stop function set			3/7
Movable area set			
Startable area set			
Movable axis set			
Offset adjustment set			
> Tool parameter set			
			>


6. Press cursor keys   to move the cursor to Tool Parameter Set.


7. Press  key (Set).


TEACH	EACH AXIS	MH3	SERVO ON
Select mechanism.			
Tool parameter set			
			


8. Press  key (Mechanism 1).




TEACH	EACH AXIS	MH3	SERVO ON
Tool parameter			Mechanism 1
> Parameter 1	0.0		
Parameter 2	0.0		
Parameter 3	255.0		
Parameter 4	-45.0		
Parameter 5	0.0		
Parameter 6	180.0		
			

9. Check if the values in Table 6.1 are set. If the setting is correct, press  key to end operating. If the setting is different, correct according to the procedure on the next page.


10. Move the cursor to the data to change.
Change the sign with  key (+/-) and numerical values with Numerical key.

TEACH	EACH AXIS	MH3	SERVO ON
Tool parameter			
Parameter 1		0.0	Mechanism 1
Parameter 2		0.0	
> Parameter 3		400.0	
Parameter 4		-45.0	
Parameter 5		0.0	
Parameter 6		180.0	
			

11. When setting is ended, press  key.

TEACH	EACH AXIS	MH3	SERVO ON
System			
Home position stop function set			3/7
Movable area set			
Startable area set			
Movable axis set			
Offset adjustment set			
> Tool parameter set			
			 >

i Important

If ended without pressing  key, the changed data are not stored to be disabled.

6.2 Checking shock sensor for operation

6.2.1 External force to operate shock sensor




Fig. 6.1

Direction of operating external force






Table 6.2
Operating external force

Direction	External force (kg)
A	3.0
B	3.0
C	3.0
D	3.0

The left table shows the standard load to operate shock sensor when external force is applied to the torch tip. They may vary a little depending on torch type and torch length.

6.2.2 Checking shock sensor for operation

Push the torch tip by hand in Teach mode to check if the message as shown on the right appears. When the torch is unhandled, the message disappears. If no message appears, the cable may not be connected. Check it again.

TEACH	TOOL SEQUENCE=	MH3	SERVO ON
P777	132		
092	P WE	100%	MACHINE
> 093	L 150cm	AS ASC05	MACHINE
094	*C1 150cm	MACHINE	M1
I 00201-0101 SHOCK SENSOR → RELEASED			
			  >

7. Trouble shooting

Table 7.1

Troubles	Causes
No arc.	Contact failure or break of welding cable.
No smooth wire feeding.	Lack of wire pressuring at feeding roll. Wear of tip. Wear of liner. Wear of inner liner. The straightener has not been mounted
Wire stick on the tip.	No smooth wire feeding. Tip hole becomes larger. Too short distance between tip and base metal.
Shock sensor cannot be released.	Contact failure or break of the shock sensor code. Nozzle is bent. * When an contact accident occurs to stop the robot due to the detection signal of the shock sensor, first inspect the cause of the accident. If the robot is operated or the power is turned ON again without finding the cause, there may be danger. Take enough care. For releasing the contact, refer to the Instruction Manuals of Robot Control (Operation and Teaching).
The widths of the cleaning on both sides are not the same.	The tip body is eccentric with respect to the nozzle. (The eccentricity at the point of the tip exceeds $\pm 0.5\text{mm}$.)
The shield is bad.	The specified tip has not been mounted

8. Parts for replacement in changing welding wire diameter

The following parts may be required to change according to the wire diameter.

1. Tip
2. Inner Liner
3. Liner
4. Outlet guide

When the welding wire diameter is changed, correct parts should be selected according to the wire diameter. The following list shows the parts.

Note) For feeding roll, refer to the Instruction Manual of Wire Feeding Unit.




Fig. 8.1

Parts for replacement in changing wire diameter

Table 8.1 Combination Table of MIG tip

●Standard, △Option		
Wire diameter	φ1.0	φ1.2
Torch model		
Parts No.	U4167H13	U4167H12
Outline drawing		
MTXA-2531	△	●
MTXCA-2531	△	●
●Standard, △Option		
Wire diameter	φ1.2	φ1.6
Torch model		
Parts No.	K980B86	K980B88
Outline drawing		
MTXAW-5031	△	●
MTXCAW-5031	△	●

Table 8.2 Combination Table of MIG inner liner

●Standard, △Option				
Wire diameter	φ1.0 - φ1.2		φ1.6	
Torch model				
Parts No.	L7062D00	L7063C00	L7062E00	L7063D00
Outline drawing				
MTXAW-5031	△	-	●	-
MTXCAW-5031	-	△	-	●

Table 8.3 Combination Table of MIG liner

●Standard, △Option

Wire diameter	φ1.0 - φ1.2	φ1.6
Torch model		
Parts No.	U4432G02	L7062F01
Outline drawing		
MTXA-2531	●	△
MTXCA-2531	●	△
MTXAW-5031	△	●
MTXCAW-5031	△	●

Table 8.4 Combination Table of MIG outlet guide

●Standard, △Option

Wire diameter	φ1.0 - φ1.2	φ1.6
Torch model		
Parts No.	U2586F01	U2586F02
Outline drawing		
MTXA-2531	●	△
MTXCA-2531	●	△
MTXAW-5031	△	●
MTXCAW-5031	△	●

9. Parts list

Shock sensor unit, Hood ASSY, Nozzle holder, Power supply wire ASSY of the torch are common. Nozzle fitting element is interchangeable for all the models. It can be replaced.

Note) In replacing, torch gauge and tool Parameters should be changed.

When the parts of the torch are worn or Damaged in operating, order from our offices or representatives with referring to the following lists.

When ordering, specify parts name and parts No.(or specifications).




Fig. 9.1
Combination table of shock sensor and torch




Fig. 9.2 MTXA-2531 Parts drawing

Table 9.1 MTXA-2531 Parts list

No.	Parts No.	Parts name	Quantity required	
1	L6380B00	Shock sensor unit	1	
1-1	3574-017	O-ring	(1)	
2	L6380G00	Hood ASSY	1	
3	L6380C00	Nozzle holder ASSY	1	
4	L6380D00	Power supply wire ASSY	1	
5	L7060B00	Torch body ASSY	1	
5-1	3574-007	O-ring	(1)	
6	U4400G01	Tip body	1	
7	U4167H12	Tip (1.2)	1	
8	U4167H13	Tip (1.0)	(1)	Option
9	U4173L00	Insulator	1	
10	L6573C02	Spring washer	1	
11	U2774E03	Orifice	1	
12	U4432G01	Nozzle(No.10)	1	
13	L7060D01	Inner liner	1	




Fig. 9.3 MTXCA-2531 Parts drawing

Table 9.2 MTXCA-2531 Parts list

No.	Parts No.	Parts name	Quantity required	
1	L6380B00	Shock sensor unit	1	
1-1	3574-017	O-ring	(1)	
2	L6380G00	Hood ASSY	1	
3	L6380C00	Nozzle holder ASSY	1	
4	L6380D00	Power supply wire ASSY	1	
5	L7061B00	Torch body ASSY	1	
5-1	3574-007	O-ring	(1)	
6	U4400G01	Tip body	1	
7	U4167H12	Tip (1.2)	1	
8	U4167H13	Tip (1.0)	(1)	Option
9	U4173L00	Insulator	1	
10	L6573C02	Spring washer	1	
11	U2774E03	Orifice	1	
12	U4432G01	Nozzle(No.10)	1	
13	L7061C01	Inner liner	1	




Fig. 9.4 MTXAW-5031 Parts drawing

Table 9.3 MTXAW-5031 Parts list

No.	Parts No.	Parts name	Quantity required	
1	L6380B00	Shock sensor unit	1	
1-1	3574-017	O-ring	(1)	
2	L6380G00	Hood ASSY	1	
3	L6380C00	Nozzle holder ASSY	1	
4	L6380D00	Power supply wire ASSY	1	
5	L7062B00	Torch body ASSY	1	
5-1	3574-007	O-ring	(1)	
5-2	L7062B04	Spacer	(1)	
6	L6571D00	Cooling water hose(1)	1	6m
7	L6571E00	Cooling water hose(2)	(1)	8m, Option
8	L6571F00	Cooling water hose(3)	(1)	10m, Option
9	U4430P04	Cap nut	1	
10	U4430N00	Insulator	1	
10-1	3574-003	O-ring	(1)	
10-2	3574-006	O-ring	(1)	
11	BWW-625	Wave washer	1	
12	U4430P01	Nut	1	
13	U4430P02	Tip nut	1	
14	K980B88	Tip(1.6)	1	
15	K980B86	Tip(1.2)	(1)	Option
16	U4430H00	Nozzle ASSY	1	
16-1	U4430H06	Insulating sleeve	(1)	Option
17	L7062D00	Inner liner(1.2)	(1)	Option
18	L7062E00	Inner liner(1.6)	1	




Fig. 9.5 MTXCAW-5031 Parts drawing

Table 9.4 MTXCAW-5031 Parts list

No.	Parts No.	Parts name	Quantity required	
1	L6380B00	Shock sensor unit	1	
1-1	3574-017	O-ring	(1)	
2	L6380G00	Hood ASSY	1	
3	L6380C00	Nozzle holder ASSY	1	
4	L6380D00	Power supply wire ASSY	1	
5	L7063B00	Torch body ASSY	1	
5-1	3574-007	O-ring	(1)	
5-2	L7062B04	Spacer	(1)	
6	L6571D00	Cooling water hose(1)	1	6m
7	L6571E00	Cooling water hose(2)	(1)	8m, Option
8	L6571F00	Cooling water hose(3)	(1)	10m, Option
9	U4430P04	Cap nut	1	
10	U4430N00	Insulator	1	
10-1	3574-003	O-ring	(1)	
10-2	3574-006	O-ring	(1)	
11	BWW-625	Wave washer	1	
12	U4430P01	Nut	1	
13	U4430P02	Tip nut	1	
14	K980B88	Tip(1.6)	1	
15	K980B86	Tip(1.2)	(1)	Option
16	U4430H00	Nozzle ASSY	1	
16-1	U4430H06	Insulating sleeve	(1)	Option
17	L7063C00	Inner liner(1.2)	(1)	Option
18	L7063D00	Inner liner(1.6)	1	




Fig. 9.10 Coaxial power cable parts drawing

Table 9.9 Coaxial power cable parts list

Parts No.	Parts name	Qt.	Remarks	Parts No.	Parts name	Qt.	Remarks
1	Power cable ASSY	1		21	L7062F	Inserting part (1)	1
2	Refer to the right table. Shock sensor cable	1		21-1	U2586F02	Outlet guide (1)	(1)
3	L6611B Gas hose ASSY	1		21-2	L7062F01 (U4432G04)	Plastic liner (1.6)	(1)
4	L6611C01 Power adapter	1		22	L7062G	Inserting part (2)	1
5	U4167F01 Cable clamp (1)	1		22-1	U2586F01	Outlet guide (1)	(1)
6	U4167F02 Cable clamp (2)	1		22-2	U4432G02	Plastic liner	(1)
7	M4 × 16 Cross recessed round head screw	1		Shock sensor cable lists			
8	M4 × 16 Hexagon nut	1					
9	M4 × 8 Cross recessed round head screw	1					
10	L6611D04 Guide adapter	1		2	L 6 5 7 7 B	Shock sensor cable (1.1M)	1
11	U69B34 Outlet guide (0.9~1.2)	1			L 6 5 7 7 C	Shock sensor cable (1.2M)	1
12	U69B35 Outlet guide (1.2~1.6)	(1)			L 6 5 7 7 D	Shock sensor cable (1.3M)	1
13	U2770K01 Outlet guide (0.8)	(1)			L 6 5 7 7 E	Shock sensor cable (1.4M)	1
14	L6611D02 Liner(0.9~1.2)	1	For L-6611~L-6613		L 6 5 7 7 F	Shock sensor cable (1.5M)	1
15	U4170H02 Liner(0.9~1.2)	1	For L-6614~L-6625		L 6 5 7 7 G	Shock sensor cable (1.6M)	1
16	L6611D01 Liner(1.2~1.6)	(1)	For L-6611~L-6613		L 6 5 7 7 H	Shock sensor cable (1.8M)	1
17	U4173G04 Liner(1.2~1.6)	(1)	For L-6614~L-6625		L 6 5 7 7 J	Shock sensor cable (2.1M)	1
18	L6611D03 Liner(0.8~0.9)	(1)	For L-6611~L-6613		L 6 5 7 7 K	Shock sensor cable (2.5M)	1
19	U4353G01 Liner(0.8~0.9)	(1)	For L-6614~L-6625	Note) The liner and the outlet guide built in as standard are for iron.			
20	L6577B01 Cap	1		The liners and outlet guides listed in Table 9.9(No.21,22) are for aluminum and thus need to be arranged separately.			

Instruction Manual of welding torch

No. 1 L7060-E-1 First edition first printed on 1 September,1999

No. 1 L7060-E-2 Second edition first printed on 30 October,2015