

Upon contact, advise MODEL and MANUAL NO.

October 9, 2008

DAIHEN Corporation WELDING & MECHATRONICS DIVISION

**IMPORTANT:** Read and understand the entire contents of this manual, with special emphasis on the safety material throughout the manual, before installing, operating, or maintaining this equipment. This equipment and this manual are for use only by persons trained and experienced in the safety operation of cutting equipment. Do not allow untrained persons to install, operate or maintain this equipment. Contact your distributor if you do not fully understand this manual.

**DO NOT DESTROY**

MODEL: CTL-0151 H1040

# PLASMA CUTTING TORCH

FOR

## OWNER'S MANUAL



Notice : Machine export to Europe

This product does not meet the requirements specified in the EC Directives which are the EU safety ordinance that was enforced starting on January 1, 1995. Please make sure that this product is not allowed to bring into the EU after January 1, 1995 as it is.

The same restriction is also applied to any country which has signed the EBA accord.


Please ask us before attempting to relocate or resell this product to or in any EU member country or any other country which has signed the EBA accord.


17	8. SPECIFICATIONS
16	7. PARTS LIST
12	6. MAINTENANCE AND TROUBLESHOOTING
9	5. NOTICE AT OPERATION
8	4. TORCH DRAWING
8	3. ACCESSORIES
2	2. PLASMA ARC CUTTING SAFETY PRECAUTIONS
2	1. SAFETY INFORMATION

CONTENTS


1. SAFETY INFORMATION

The following safety alert symbols and signal words are used throughout this manual to identify various hazards and special instructions.


	<b>WARNING</b> gives information regarding possible personal injury or loss of life.
---	--

	<b>CAUTION</b> refers to minor personal injury or possible equipment damage.
---	--


2. PLASMA ARC CUTTING SAFETY PRECAUTIONS


	<b>WARNING</b>
<b>PLASMA ARC CUTTING can be hazardous.</b>	
<ol style="list-style-type: none"> <li>1. <b>PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH.</b> Be sure to: <ul style="list-style-type: none"> <li>• Keep children away.</li> <li>• Keep pacemaker wearers away until consulting a doctor.</li> </ul> </li> <li>2. Read and understand the summarized safety information given below and the original principal information that will be found in the PRINCIPAL SAFETY STANDARDS.</li> <li>3. Have only trained and experienced persons perform installation, operation, and maintenance of this equipment.</li> <li>4. Use only well-maintained equipment. Repair or replace damaged parts at once. <b>PLASMA ARC CUTTING is safe when precautions are taken.</b></li> </ol>	

2. PLASMARC CUTTING SAFETY PRECAUTIONS (continued)



<p>ELECTRIC SHOCK can kill.</p>	
<p>Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work equipment are electrically live whenever the output is on. The power line and internal circuits of this equipment are also live when the line disconnect switch is on. When plasma cutting all metal components in the torch and work circuits are electrically live.</p> <p>Leaving accretive dust in the cutting machine may cause an insulation deterioration and result in electrical shock and fire.</p> <ol style="list-style-type: none"> <li>1. Do not touch live electrical parts.</li> <li>2. Wear dry insulating gloves and other body protection that are free of holes.</li> <li>3. Insulate yourself from work and ground using dry insulating mats or covers.</li> <li>4. Be sure to turn off the line disconnect switch before installing, changing torch parts or maintaining this equipment.</li> <li>5. Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.</li> <li>6. Keep all panels and covers of this equipment securely in place.</li> <li>7. Do not use worn, damaged, undersized, or poorly spliced cables.</li> <li>8. Do not touch electrodes or any metal object if POWER switch is ON.</li> <li>9. Do not wrap cables around your body.</li> <li>10. Turn off POWER switch when not in use.</li> <li>11. Keep away from torch tip and pilot arc when trigger is pressed.</li> <li>12. Remove dust by blowing moisture-free compressed air on each part periodically.</li> </ol>	
<p>ARC RAYS can burn eyes and skin: FLYING SPARKS AND HOT METAL can cause injury. NOISE can damage hearing.</p>	
<p>ARC rays from the cutting process produce intense heat and strong ultraviolet rays that can burn eyes and skin.</p> <p>Noise from some plasma arc cutting applications can damage hearing.</p> <ol style="list-style-type: none"> <li>1. Wear face shield with a proper shade of filter ( See ANSI Z 49.1 listed in PRINCIPAL SAFETY STANDARDS) to protect your face and eyes when cutting or watching a cutter work.</li> <li>2. Wear approved safety goggles. Side shields recommended.</li> <li>3. Use protective screens or barriers to protect others from flash and glare: warn others not to look at the arc.</li> <li>4. Wear protective clothing made from durable, flame-resistant material (wool and leather) and foot protection.</li> <li>5. Use approved earplugs or earmuffs if noise level is high.</li> </ol>	

2. PLASMA ARC CUTTING SAFETY PRECAUTIONS (continued)


<p>FUMES AND GASES can be hazardous to your health.</p>	
<p>Cutting produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.</p>	
<ol style="list-style-type: none"> <li>1. Keep your head out of the fumes. Do not breathe the fumes.</li> <li>2. Ventilate the area and/or use exhaust at the arc to remove cutting fumes and gases.</li> <li>3. If ventilation is poor, use an approved air-supplied respirator.</li> <li>4. Read the Material Safety Data Sheets (MSDS) and the manufacturer's instructions on metals to be cut, consumables, coatings, and cleaners.</li> <li>5. Do not cut in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.</li> </ol>	


<p>CUTTING can cause fire and explosion.</p>	
<p>Sparks and cross fly off from the cutting arc. The flying sparks, hot metal, dross, hot base metal and hot equipment can cause fire and explosion.</p>	
<p>Leaving accretive dust in the cutting machine may cause an insulation deterioration and result in electrical shock and fire.</p> <ol style="list-style-type: none"> <li>1. Protect yourself and others from flying sparks and hot metals.</li> <li>2. Do not cut where flying sparks can strike flammable material.</li> <li>3. Remove all flammables within 10m (33ft) of the cutting arc. If this is not possible, tightly, cover them with approved covers.</li> <li>4. Be alert that cutting sparks and hot metals from cutting can easily pass through cracks and openings into adjacent areas.</li> <li>5. Watch for fire, and keep a fire extinguisher nearby.</li> <li>6. Be aware that cutting on a ceiling, floor, bulkhead, or partition can ignite a hidden fire.</li> <li>7. Do not cut on closed containers such as tanks or drums.</li> <li>8. Connect power cable for base metal as close to the cutting area as possible to prevent the cutting current from traveling along unknown paths and causing electric shock and fire hazards.</li> <li>9. Do not use the cutting power source for anything other than plasma cutting.</li> <li>10. Wear oil-free protective garments such as leather gloves, a heavy shirt, cuffless trousers, boots, and a cap.</li> <li>11. A loose cable connection can cause sparks and excessive heating.</li> <li>12. Tighten all cable connections.</li> <li>13. Wear approved face shield or safety goggles with side shields.</li> <li>14. Wear flame-resistant earplugs or earmuffs to prevent sparks from entering ears.</li> <li>15. Do not cut anything in an explosive dust-filled room or smoke-filled room.</li> <li>16. Do not cut any container which is likely to contain high pressure materials like gas cylinders or high pressure pipes.</li> <li>17. Do not cut containers which contains combustible material. Do not place the cutting machine on combustible material.</li> <li>18. Remove dust by blowing moisture-free compressed air on each part periodically.</li> </ol>	

2. PLASMA ARC CUTTING SAFETY PRECAUTIONS (continued)

<p>CYLINDER can explode if damaged.</p>	
<p>A shielding gas cylinder contains high-pressure gas. If damaged, a cylinder can explode. Since gas cylinders are normally part of the cutting process, be sure to handle them carefully. Use only correct shielding gas cylinders, gas regulator, hoses, and fittings designed for the specific application; maintain them in good condition.</p> <ol style="list-style-type: none"> <li>1. Use only correct shielding gas cylinders, gas regulator, hoses, and fittings designed for the specific application; maintain them in good condition.</li> <li>2. Protect compressed gas cylinders from excessive heat, mechanical shock, and arcs.</li> <li>3. Keep the cylinder upright and securely chained to a stationary support or a rack to prevent falling or tipping.</li> <li>4. Keep cylinders away from any cutting or other electrical circuit.</li> <li>5. Never touch cylinder with cutting electrode.</li> <li>6. Read and follow instructions on compressed gas cylinders, associated equipment, and the CGA publication P-1 listed in PRINCIPAL SAFETY STANDARDS.</li> <li>7. Turn face away from valve outlet when opening cylinder valve.</li> <li>8. Keep protective cap in place over valve except when gas cylinder is in use or connected for use.</li> <li>9. Do not disassemble or repair the gas regulator except if you are authorized by the manufacturer.</li> </ol>	
<p>PLASMA ARC can cause injury</p>	
<ol style="list-style-type: none"> <li>1. Keep away from the torch tip.</li> <li>2. Do not grip material near the cutting path.</li> <li>3. The pilot arc can cause burns. Keep away from tip when trigger is pressed.</li> <li>4. Wear proper flame-retardant clothing covering all exposed body areas.</li> <li>5. Point torch away from your body and toward work when pressing the torch trigger.</li> <li>6. Turn off the line disconnect switch and POWER switch on the front panel before disassembling torch or changing torch parts.</li> <li>7. Use only torch(es) specified in the Owner's Manual.</li> </ol>	

2. PLASMA ARC CUTTING SAFETY PRECAUTIONS (continued)

<p>Rotating parts may cause injuries. Be sure to observe the following.</p>	
<p>If hands, fingers, hair or clothes are put near the fan's rotating parts, injuries may occur.</p> <ol style="list-style-type: none"> <li>1. Do not use this equipment if the case and the cover are removed.</li> <li>2. When the case is removed for maintenance/inspection and repair, certified or experienced operators must perform the work. Erect a fence, etc. around the cutting machine to keep others away from it.</li> <li>3. Do not put hands, fingers, hair or clothes near the rotating fans.</li> </ol>	

<p>This equipment uses high frequency for arc starting.</p>	
---	---

<p>High-frequency may enter nearby units as shown below, causing electromagnetic trouble.</p> <ul style="list-style-type: none"> <li>* Input cables, signal cables, telephone cables</li> <li>* Radio sets, TV sets</li> <li>* Computers and other control equipment</li> <li>* Industrial detectors and safety units</li> <li>* Pacemakers, hearing-aid sets</li> </ul> <p>For preventing electromagnetic trouble,</p> <ol style="list-style-type: none"> <li>1. Make the cable as shortest as possible.</li> <li>2. Install cables along the floor or the ground as close as possible.</li> <li>3. Put the power cable for base metal together with the torch side cable.</li> <li>4. Do not use a common base metal ground with other machines.</li> <li>5. Tightly close all of the doors and covers of this equipment, and secure them.</li> <li>6. Do not press the torch switch other than when ready to start the arc.</li> <li>7. When electromagnetic trouble occurs, take the measures shown in this instruction manual until trouble is corrected.</li> </ol> <p>Please contact OTC-DAIHEN, when necessary.</p> <p>8. Pacemaker wearers must not come near this equipment during operation until consulting your doctor.</p> <p>Operation of the pacemakers will be affected badly by high frequency.</p>	
---	--

<p>PLASMA ARC CUTTING work areas are potentially hazardous.</p>	<p><b>FALLING or MOVING machine can cause serious injury.</b></p> <ol style="list-style-type: none"> <li>1. Use both eyebolts, if installed, to lift the cutting power source.</li> <li>2. Put this equipment solidly on a flat surface.</li> <li>3. Do not pull this equipment across a floor laid with cables and hoses.</li> </ol>
---	---



## PRINCIPAL SAFETY STANDARDS

Arc welding equipment – Installation and use, Technical Specification  
IEC 62081, from International Electrotechnical Commission

Arc welding equipment Part 1: Welding power sources IEC 60974-1, from International Electro  
technical Commission

Safety in Welding and Cutting, ANSI Standard Z49.1, from American Welding Society.

Safety and Health Standards, OSHA 29 CFR 1910, from Superintendent of Documents, U.S.  
Government Printing Office.

Recommended Practices for Plasma Arc Cutting, American Welding Society Standard AWS C5.2, from  
American Welding Society.

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers That Have  
Held Hazardous Substances, American Welding Society Standard AWS F4.1, from American Welding  
Society.

National Electrical Code, NFPA Standard 70, from National Fire Protection Association.

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas  
Association.

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association,  
Standards Sales.

Safe Practices For Occupation And Educational Eye And Face Protection, ANSI Standard Z87.1, from  
American National Standards Institute.

Cutting And Welding Processes, NFPA Standard 51B, from National Fire Protection Association.


NOTE: The codes listed above may be improved or eliminated. Always refer to the updated codes.

3. ACCESSORIES


● Check the quantity at open


Accessories		Plasma cutting torch
Q'ty	Description	
1	① Shield Cup	
3	② Tip	
3	③ Electrode	
1	④ Wrench	

4. TORCH DRAWING



5. NOTICE AT OPERATION


<b>WARNING</b>	
Observe the followings to prevent the electrical shock.	
<ul style="list-style-type: none"> <li>● Do not touch live electrical parts.</li> <li>● Do not touch tip, when power source is on.</li> <li>● Be sure to turn off the line disconnection switch before checking torch and exchanging parts</li> <li>● Operate the maintenance check periodically, and be sure to troubleshoot and repair immediately.</li> <li>● This cutting torch must be operated by persons who understand contents of this instruction manual and have knowledge and skills for cutting torch safety.</li> </ul>	

<b>CAUTION</b>	
If you touch plasma arc or pilot arc, you will be burned.	
<ul style="list-style-type: none"> <li>● Do not point torch in direction of personnel.</li> <li>● If you put torch down during operation, do not put torch switch downward, put torch at unstable place or turn torch switch on carelessly.</li> </ul>	

5.1 Rated duty cycle

<b>CAUTION</b>
<ul style="list-style-type: none"> <li>● Use at the rated duty cycle or less. If exceeding the rated duty cycle, the torch may be deteriorated and burned.</li> </ul>

- Rated duty cycle : 15A 50% (17A 40%)
- The duty cycle is expressed in 10 minutes cycles. A duty cycle of 50% is rated with output current for five minutes and off for five minutes, so that the temperature rise inside the torch will not exceed the allowable value.



- If exceeding the rated duty cycle, temperature rise of cutting power source and torch exceed the allowable temperature, and it can be cause of burning.

5.2 Precautions for cutting operation

CAUTION  
Observe followings when you use torch.

Do not touch the side of tip to the edge of base metal when starting. Strong arc generates and the hole of tip might be deformed outright.

Do not start with touching tip to base metal vertically. Arc generates inside of tip, and tip might be burned.


For cutting down, move torch to cutting direction with touching tip to the base metal slightly.

The proper torch angle to base metal should be within  $\pm 5^\circ$ .  
If forward angle is too large, upwash occurs forward of cutting direction.  
If torch leans to the right against cutting direction, spatters to the left, and spatters to the right, if torch leans to the left against cutting direction.  
Keep the correct torch angle to prevent spatter.



Plasma arc flows slightly backward with correct cutting speed, so cross can be easily taken off from base metal.  
If it is too fast, upwash occurs forward of cutting direction.

Do not cut down with touching tip to base metal. Strong arc generates, and a hole of tip can be deformed.  
At cutting terminal, keep tip away from base metal for 1mm, then cut down.


(1) Starting




(2) During cutting



(3) Ending



### 5.3 Insulating cover



The insulating cover serves to protect the detectable pin. Careless handling of the torch body may cause damage to the insulating cover. If the insulating cover has been removed, high frequency is emitted from the detectable pin and may cause damage to the torch body. If the insulating cover is damaged, replace it.

### 5.4 Clamping the torch for an automatic cutting

● With automatic cutting operation with mounting the torch on a carriage, clamp as follows.

<p>Clamping enable range</p>	<p>Angle type torch Clamping recommend zone</p>		
<p>If clamping recommend zone can not be used, clamp the torch body shown in left drawing. In such a case, insulating sleeve is needed. Refer to the left drawing, and order an insulating sleeve to branch office or nearest agent.</p>	<p>Torch body</p>		
<p>Caution</p>	<table border="1"> <tr> <td data-bbox="749 727 906 819"> <p>Part No. H705H01</p> </td> <td data-bbox="906 727 1149 819"> <p>Description Insulating sleeve</p> </td> </tr> </table>	<p>Part No. H705H01</p>	<p>Description Insulating sleeve</p>
<p>Part No. H705H01</p>	<p>Description Insulating sleeve</p>		

6. MAINTENANCE AND TROUBLESHOOTING


<b>WARNING</b>	
Observe followings to prevent electrical shock.	
<ul style="list-style-type: none"> <li>● Do not touch live electrical parts.</li> <li>● Do not touch tip when power source is on.</li> <li>● Be sure to turn off the line disconnection switch before checking torch and exchanging parts.</li> <li>● Operate the maintenance check periodically, and be sure to troubleshoot and repair immediately.</li> <li>● This cutting torch must be operated by persons who understand contents of this instruction manual and have knowledge and skills for cutting torch safety.</li> </ul>	

<b>CAUTION</b>	
Observe the followings to prevent burning.	
<ul style="list-style-type: none"> <li>● When operating, do not touch high temperature parts (tip, shield cup, and base metal) just after the operation).</li> <li>● Use protectors (leather gloves, etc.) when operating.</li> <li>● Exchanging torch tip parts must be done after cooling down.</li> </ul>	


<b>CAUTION</b>	
<ul style="list-style-type: none"> <li>● If parts are damaged, replace with new ones for safety and quality assurance.</li> </ul>	

● Only use OTC's genuine parts for replacing.

6.1 Replacing of shield cup, tip, and electrode



(1) Installation of shield cup









(2) Replacement of electrode and tip

When the following conditions exist replacement of the electrode and/or tip may be necessary.


Check part	Tip, Electrode	<ul style="list-style-type: none"> <li>Starting of pilot arc is impeded, and start is erratic.</li> <li>A loud popping sound is heard at time of starting.</li> <li>Soon after the tip is replaced the hole is deformed.</li> <li>The cut curt is excessively.</li> <li>Tip sticks to the base metal.</li> </ul>
Conditions	Tip, Electrode	



Check item	Tip	Electrode
Is the tip hole deformed?		
Is the tip of electrode consumed?		
Timing for replacing		
Normal	<p>● The hole is round and not deform.</p>	<p>● Consumption of the electrode center is less than 1 mm.</p> <p>The sinkage of center is less than 1mm.</p>
Tip	<p>● Is the tip hole deformed?</p>	<p>● Consumption of the electrode center is more than 1mm.</p> <p>If you keep using this, cutting operation will not work well.</p>
Electrode	<p>● Is the tip of electrode consumed?</p>	<p>● Consumption of the electrode center is less than 1mm.</p> <p>If you keep using this, it will be a cause of burn out.</p>

6.2 How to exchange torch body  
Disassembly

- (1) Unscrew four attaching screws from torch body and open handle.
- (2) Fix torch body, and move hose sheath backward until you see connection terminal of lead wire (about 30mm).
- (3) Cut lead wire at backward of Connection terminal.
- (4) For disassembling of power cable, move tube backward, fix spanner to a hole for spanner and turn nut of power cable to anti-clockwise.






Notices for assembling

1. Since high voltage with high frequency is applied on this torch, be sure to insulate each part.
2. Be sure to connect power cable properly.

Assembly is in reverse order of disassembly.



(1) Connect power cable to torch body.

(2) Move tube backward to the edge of torch body.


(3) Tape lead wire together with tube to prevent from pulling into handle.

(4) Insert black detection lead wire into black butt connect or in torch body and crimp with crimper. Connect and crimp the rest of wires with the same color butt connector.

(5) Move hose sheath back in position per drawing and tie it with cable tie and put it into under handle. Do not tie power cable and lead wire together.

(6) Adjust wires to prevent from squeezing into handle, then close and screw handle.

7. PARTS LIST



. Standard accessories

No.	Part No.	Description	Q'ty	Spare	Remarks
1	H705F03	Shield cup	1	1	
2	H1002F01	Tip	1	3	
3	H705F05	Electrode	1	3	
4	H1040B00	Torch body	1		Includes 4-1 and 4-2.
4-1	H690F01	Protection cover	(1)		
4-2	H999R00	Body cover kit	(1)		
5	H1040C00	Handle	1		Includes 5-1 and 5-2.
5-1		Screw	(4)		M4×12
5-2	3361-808	Nut	(4)		M4
6	H999J00	Torch switch	1		
7	H999F01	Hose sheath	1		
8	H999D00	Power cable assembly	1		
9	H1002E00	Control wire assembly	1		Includes 9-1.
9-1	4730-069	Plug socket	(1)		
10	H690G01	Wrench	—	1	

. Optional accessories

Part No.	Description	Q'ty	Remarks
0302-001	Circle cutting compass	1	Not be usable with long tip
0302-010	Easy torch guide	1	and long electrode.
H705H01	Insulating sleeve	1	
H1002H01	Long tip	1	
H999K02	Long electrode	1	※ Must be used together



**Upon contact, advise MODEL and MANUAL NO.**

11B/L Hyeongok Industrial Complex, 463-1 Hyeongok-ri,  
Cheongbuk-myeon, Pyeongtaek, Gyeonggi-do, 451-831, Republic of Korea  
Phone: +82-31-686-7459, Fax: +82-31-686-7465

**OTC DAIHEN Korea Co.,Ltd**

23 Soi 63 Sukhumvit Road,  
23/43, 16th Fl. Sorachai Building,  
Klongtonnua, Wattana, Bangkok 10110, Thailand  
Phone: +66-2-714-3201, Fax: +66-2-714-3204

**OTC DAIHEN Asia Co.,Ltd.**

2F No. 153, Huanbei Rd., Chung Li City,  
Taoyuan Hsien, Taiwan R.O.C.  
Phone: +886-3-461-3962, Fax: +886-3-434-2394

**OTC (Taiwan) Co.,Ltd.**

17F Majesty Building, 138 Pu Dong Da Dao Shanghai  
The People's Republic of China  
Post Code: 200120  
Phone: +86-21-5882-8633, Fax: +86-21-5882-8846

**OTC Industrial (Shanghai) Co.,Ltd.**

Krefelder Strasse 675-677,  
D-41066 Mönchengladbach, GERMANY  
Phone: +49-2161-6949710, Fax: +49-2161-6949711

**OTC DAIHEN EUROPE GmbH.**

1400 Blauser Drive  
Tipp City, Ohio 45371, USA  
Phone: +1-937-667-0800, Fax: +1-937-667-0885

**DAIHEN, INC. DAYTON OFFICE**

4-1, Koyochon-nishi, Higashimada-ku,  
Kobe, Hyogo 658-0033  
Phone: +81-78-275-2006, Fax: +81-78-845-8159

**DAIHEN Corporation**

