



OWNER'S MANUAL

Welbee M350 II M500 II





July, 2021

Manual No.: P30355-1

DAIHEN Corporation

Forward

Thank you for your purchase of OTC's welding power source.

This Owner's Manual (hereafter referred to as "this manual") explains the following points for safe use of the product.

- · Caution regarding the product
- · Welding operation/setting method
- · Daily maintenance (cleaning, inspection)
- Troubleshooting


Store this manual in a safe place so that it can be referred whenever necessary.

Service and Support

See the back cover for contact numbers and mailing addresses. When contacting your dealer for service, you are required to provide the following information:

- · Name, address, telephone number
- Product model, manufacture year, serial number, and software version number (Refer to the diagram below for product information. Attachment location and content of nameplate may vary depending on the purchased product.)

<Example> Attachment location of the nameplate



No.	Serial No.		
1	(Same number as the nameplate in the rear)		
		#X#####X ##########	
	Product model	XX-X###X	
2	Manufacture y	ear #### year	
	Serial number	#X#####X ##########	
3	Software version	on number	
3		X##### Ver ###.###.###	

Important Information

Use of the Product

This product is a power supply unit designed and manufactured for use in arc welding.

Do not use the product for any other purposes.

Safe Use of the Product

For safe use of the product (hereafter referred to as welding power source), ensure to follow the instructions below:

- This manual is intended for workers who are familiar with the listed terminologies. If this product is going
 to be operated or serviced by workers who are not familiar with the terminology, the responsibility falls
 on the customer to provide thorough training on operation and safety.
- This equipment and this manual are for use only by persons trained and experienced in the safety
 operation of welding equipment. Untrained persons must complete the "Special workshop for arc
 welding".
- For protection from possible injury or damage in the equipment, be sure to read and follow the safety information in this manual. Do not use it for purposes not indicated in the manual.
- Make sure that installation/operation/maintenance of the welding power source and welding machine is performed by qualified personnel with sufficient knowledge and skills.
- If this manual is lost or damaged, immediately contact your dealer.

Copyright

This manual is copyrighted and all rights are reserved by OTC. Any part of the manual shall not be copied, photocopied, or reproduced without the prior consent of OTC.

When Exporting the Product

The following conditions are to be observed and met when exporting the product outside of the country.

- The product is designed and manufactured according to the Japanese laws/specification and industrial standards. The product may not conform to laws/specification and standards in other countries.
- When shipping or reselling the product outside of the country, make sure to contact our distributor or customer service in advance.

Disposal of the Product

For disposal of welding equipment including the welding power source and welding material, confirm the regulation of the country/region in which the equipment is located and follow the rules. When disposing, arrange consignment contract for waste disposal with an authorized waste collectors and manage the disposal processes.

TABLE OF CONTENTS

Forwa		4.2.		Connection of welding torch	
	ce and Support rtant Information1	4.2. 4.2.		Connection at TIG welding Connection at DC STICK welding	32
•	of the Product	4.2. 4.2.		Connection of shield gas	
	Use of the Product			-	
Copy	yright	4.3		Grounding and Connection of Input Pow	
	n Exporting the Product			Supply	
Disp	osal of the Product	4.4	(Confirmation of Connection	38
		4.5	(Connection of External Equipment	
CHA	PTER 1 SAFETY INFORMATION	4.5.		Connection of robot	
1.1	Warning Symbols	4.5.	.2	Connection of automatic machine	39
	Safety Precaution	4.6		Wiring of Voltage Detection Cable at Bas	
1.2.1	•		ľ	Wetal Side	42
1.2.2		4.6.		Wiring to wire feeder	
1.2.3		4.6.		Wiring to welding power source	
1.2.4	· · · · · · · · · · · · · · · · · · ·	4.6.	.3	Wiring example of voltage detection cable	44
405	modifying the welding power source	СП	A [DTED E WEI DING ODERATION	
1.2.5	5 Precautions for air discharge and use of respiratory protective equipment	СПА	ΑI	PTER 5 WELDING OPERATION	
1.2.6		5.1	F	Precaution at Welding Operation	45
1.2.7		5.1.	.1	Precautions for air discharge and use of respiratory	/
1.2.8	Precautions for gas cylinder and gas regulator 10			protective equipment	
1.2.9	Precautions for rotating part	5.1.		• • • •	
1.3	Principal Safety Standards11	5.1.		0.1	
				Check before Welding	
CHA	PTER 2 PRODUCT SPECIFICATION			Power ON and Gas Supply	
ΔΝΠ	CONFIGURATION	5.4	١	Nire Inching	49
		5.5	(Check and Setting of Welding Condition	50
	Specification	5.5.		Reading welding condition	
2.1.1		5.5.	.2		
2.1.2 2.1.3	11 0	5.6	F	Performing Welding Operation	51
2.1.4		5.6.		Operation of welding start	
2.2	Product Configuration	5.6.	.2	Operation during welding	52
2.2.1	<u>-</u>	5.6.	.3	Operation at welding end	54
2.2.2	•				
2.2.3	7 (11 /	CHA	ΑI	PTER 6 WELDING CONDITION	
2.2.4		6.1	ı	List of Welding Conditions	55
2.3	Part Names	6.1.		Parameter (Welding parameter)	
2.3.1	•	6.1.	.2	Function	
2.3.2	2 Rear panel	6.1.		Internal function	
	DTED A TRANSPORTATION AND	6.2	F	Function on Operation Panel	
	PTER 3 TRANSPORTATION AND	6.2.		Operation panel	
INST	TALLATION	6.2.		3	
3.1	Required Equipment22	6.3	١	Welding Conditions	
3.1.1		6.3.		Basic welding conditions	
3.1.2	• • • • • • • • • • • • • • • • • • • •	6.3.		Useful functions	
3.2	Installation Environment	6.4		Preparing Welding Conditions	
3.2.1		6.5	ľ	Memory Function of Welding Conditions	65
3.2.2	2 Electromagnetic interference	6.5.		Memory registration of welding conditions	
3.3	Transportation Procedure	6.5.		Read out of welding conditions	
3.3.1	Transportation with lifting lug	6.5.		Deletion of memory registration	
3.3.2				Setting Welding Conditions	
		6.6. 6.6.		Welding mode settingSetting welding conditions	
CHA	PTER 4 CONNECTION	6.6.		Setting welding conditions	
4.1	Precautions for Connection Procedure and	6.6.		Crater setting	
	Grounding	6.6.		Arc spot time	
	Connecting the Welding Power Source28	6.6.		Welding voltage adjustment	
4.2 4.2.1	•	6.6. 6.6.		Arc characteristics adjustment	
4.2.1	·	6.6.		Welding guide	
		0.0.	. •		

6.7	Setting Internal Functions8	
6.7.		
6.7.		1
6.8	Operation of Analog Remote Control	_
	(Optional)	9
$C \square A$	APTER 7 ADMINISTRATOR	
FUN	CTIONS	
7.1	Protection of Welding Conditions 10	
7.1.		
7.1.		
7.2	Welding Result Control Function 10	
7.2. 7.2.	3 3	
	Data Backup (Utilization of data) 110	
7.3.		
7.3.	2 Simplified data log function	2
7.3.	•	
7.3. 7.3.	· · · · · · · · · · · · · · · · · · ·	
7.3.		
7.4	Initializing Welding Conditions and	
	Internal Functions	6
7.5	Checking the Software Version and	
	Serial Number	7
7.6	Calibration Mode	8
7.6.	, ,	
7.6.	, , ,	
	2 Adjustment of output voltage	
7.7	System Setting12	
7.7 CH <i>A</i>	System Setting12	
7.7 CHA	System Setting126 APTER 8 MAINTENANCE AND PECTION	
7.7 CH <i>A</i>	System Setting	1
7.7 CHA INSI 8.1	System Setting	1
7.7 CHA INSI 8.1	System Setting	1 2 4
7.7 CHAINSI 8.1 8.2 8.3	System Setting	1 2 4 4
7.7 CHA INSI 8.1	System Setting	1 2 4 4
7.7 CHAINSI 8.1 8.2 8.3	APTER 8 MAINTENANCE AND PECTION Precautions for Maintenance and Inspection	1 2 4 4
7.7 CHAINSI 8.1 8.2 8.3 8.4	System Setting	1 2 4 4 6
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5	APTER 8 MAINTENANCE AND PECTION Precautions for Maintenance and Inspection	1 2 4 4 6
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5	APTER 8 MAINTENANCE AND PECTION Precautions for Maintenance and Inspection	1 2 4 4 6 7
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5	APTER 8 MAINTENANCE AND PECTION Precautions for Maintenance and Inspection	1 2 4 4 6 7 8
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5	APTER 8 MAINTENANCE AND PECTION Precautions for Maintenance and Inspection	1 2 4 4 6 7 8
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5 CHAI 9.1	APTER 8 MAINTENANCE AND PECTION Precautions for Maintenance and Inspection	1 2 4 4 6 7 8
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5 CHAI 9.1	APTER 8 MAINTENANCE AND PECTION Precautions for Maintenance and Inspection	1 2 4 4 6 7 8
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5 CHAI 9.1 9.2	APTER 8 MAINTENANCE AND PECTION Precautions for Maintenance and Inspection	1 2 4 4 6 7 8 2
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5 CHAI 9.1 9.2 CHAI	APTER 8 MAINTENANCE AND PECTION Precautions for Maintenance and Inspection	1 2 4 4 6 7 8 2
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5 CHAI 9.1 9.2 CHAI 10.2	APTER 8 MAINTENANCE AND PECTION Precautions for Maintenance and Inspection	1 2 4 4 6 7 8 2 4 6 6 7
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5 CHA 9.1 9.2 CHA 10.1 10.2	System Setting	1 2 4 4 6 7 8 2 4 6 6 7
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5 CHA 9.1 9.2 CHA 10.1 10.2	System Setting	1 2 4 4 6 7 8 2 4 6 6 7 1
7.7 CHAINSI 8.1 8.2 8.3 8.4 8.5 CHA 9.1 9.2 CHA 10.2 10.2 10.2	System Setting	1 2 4 4 6 7 8 2 4 6 7 1 3

Chapter 1 Safety Information

This chapter explains the precautions on the welding power source and welding operation.

1.1 Warning Symbols

The following safety warning symbols and signs are used throughout the manual to ensure proper operation of the product and to prevent from various hazards that cause serious injury and damages. Indication and explanation for the symbols are as follows:

Make sure to fully understand the content before beginning operation.

The below symbols are categorized by the degree of possible hazard and damage.

Symbols	Explanation			
<u></u> ∴ WARNING	Gives information regarding possible personal injury or loss of life if the product is used improperly.			
⚠ CAUTION	Refers to minor personal injury or possible equipment damage if the product is used improperly.			

The below symbols are categorized according to the content to be followed.

Symbols Explanation				
0	Instruction: indicates "Instruction" matters to be followed.			
Prohibited: indicates "Prohibited" matters.				

1.2 Safety Precaution

This section explains the safety precautions regarding operation of the welding power source.

1.2.1 Operating precautions

To prevent serious injury or accidents, ensure to follow the instructions below:

- Be sure to read and understand the information in the manual before operating the product. Have only trained and experienced personnel perform operation of welding power source or welding power source.
- Perform construction work on primary power source in the facility, selection of
 installation space, operation/storage/piping of high pressure gas, storage of welded
 products, and disposal of waste in accordance with local law and/or regulation at the
 customer's facility.
- Be sure to take appropriate measures during welding so that no person is allowed unauthorized access near the welding power source or work areas.
- Only authorized personnel or person with full understanding and experience of the welding power source must perform installation, maintenance and repair of welding power source.
- Make sure to attach a safety belt when working at high locations.
- For those with pacemaker, avoid being close to the machine during operation or work area until obtaining physician's approval. Machine at operation will generate magnetic field nearby that may cause influence upon the working of pacemaker.
- Do not use the welding power source for purpose other than welding such as thawing a frozen pipe.
- Do not use the welding power source when the case and the cover are removed.
- Removing the cases for maintenance, inspection and repair should be performed by qualified persons or persons familiar with the welding power source. Also put up a barrier around the welding power source or take other necessary measure to prevent other people from getting in the nearby area.

1.2.2 Precautions for power supply and electric shock

To prevent electric shock or burn injury, ensure to follow the instructions below:



⚠ WARNING

- Do not touch the input and output terminals and the internal live electrical parts of the welding power source.
- Have a qualified electrical engineer ground the case of the welding power source and base metal or jig electrically connected in accordance with local regulation.
- Before starting maintenance and inspection, make sure to cut the input power with the
 disconnect switch in the box connected with the welding power source and wait three
 minutes or more.

The capacitors may be still charged even after the input power is cut. Make sure that there is no charged voltage before starting the work.

- Wear dry insulating gloves for protection. Do not use damaged or wet gloves.
- Tighten all cable connections and insulate them.
- · Do not wrap cables around the body.
- Perform periodical maintenance and repair damaged parts if any before use.
- Turn off POWER switch of all the related equipment when not in use.
- Periodically blow the parts of welding power source with dry compressed air to remove dust.

Powder dust accumulating inside may cause insulation deterioration, resulting in electric shock or fire.

 Do not use a cable with insufficient capacity, serious damage or cable without grounding.

⚠ CAUTION

• When the power switch is tripped, never turn it on again and contact your dealer.

1.2.3 Precautions for handling of plastic parts

Front panel, rear panel and fan of the welding power source is made from polycarbonate resin. To prevent from electric shock or fire caused by the damage on polycarbonate resin, ensure to follow the instructions below.

- Do not apply external force or shock to the front panel, rear panel and fan.
 Otherwise, damage and malfunction may occur.
- If there is dirt on plastic parts, soak a soft cloth in water, alcohol or neutral detergent, wring it well and wipe off the dirt.
 - Do not use organic detergent or chemical agent. Doing so may cause crack (breaking) and degrade the strength.
- If there is any abnormality in the plastic parts such as front panel, rear panel and fan, immediately stop the use and contact your dealer.
- Do not use the welding power source at location in which organic solvent, chemicals, cutting oil and composition oil adhere or atmosphere containing the above.
 Doing so may cause crack (breaking) and deterioration in the plastic part.

1.2.4 Precautions for disassembling and modifying the welding power source

To prevent electrical shock, fire, injury from malfunction and error in the welding power source, ensure to follow the instructions below:

MARNING

Do not disassemble/modify the welding power source.
 Disassembling/modifying by customer is out of the warranty scope.

1.2.5 Precautions for air discharge and use of respiratory protective equipment

To prevent suffocation or gas poisoning in the welding operation, ensure to follow the instructions below:



MARNING

- When welding is required in tank, boiler, reaction tower, or hold of a ship, closed space, or any other places of poor ventilation, ensure to provide ventilation equipment.
- Gas of larger gravity than that of oxygen, such as carbon dioxide gas or argon gas, retains at the bottom part.
 To prevent anoxia due to the retention gas, provide ventilation equipment.
- When it is difficult to provide ventilation equipment or the ventilation equipment does
 not give sufficient performance, ensure to use respiratory protective equipment.
 For preventive measure from falling due to anoxia, apply lifelines such as a safety belt.
- For the welding operation in a narrow space, perform the operation with the trained supervisor.
- Periodically inspect the ventilation equipment to ensure correct and proper performance of ventilation.

To prevent any health damage due to poisonous gas or particle substances (fume) emitted in the welding operation, ensure to follow the instructions below:



- To reduce the dust concentration, install a partial exhaust facility such as fume suction device, or install the collective ventilation equipment.
- When it is difficult to provide a partial exhaust facility or the ventilation or exhaust facility does not give sufficient performance, ensure to use the respiratory protective equipment.
- In performing welding or cutting the coating steel plate or galvanized steel sheet, provide a partial exhaust facility or let the welding operator as well as the surrounding operators use respiratory protective equipment. (Welding or cutting the coating steel plate or galvanized steel sheet will cause toxic gas or fume.)
- Do not perform welding operation in the vicinity of degreasing, cleansing, or spraying operation. Performing the welding operation in such places may generate poisonous gas.

1.2.6 Precaution for protective equipment

For protection from arc ray generated from welding, spattering dross and hearing disorder from noise, observe the following:



- When welding or watching a welder work, wear face shield with a proper shade of filter (See ANSI Z 49.1 listed in PRINCIPAL SAFETY STANDARDS) to protect the face and eyes.
- Wear safety goggles in the work area and the surrounding.
 Ignoring the above may cause injury in the eye or burn from spatter and spattering dross.
- Wear protective equipment such as protective leather gloves, long-sleeve clothes, leg covers, and leather apron.
 Ignoring the above may cause electrical shock and burn.
- Install protective screens or barriers to protect the eyes of others in the work area from arc ray.
- Wear an ear protector when noise level is high.
 Ignoring the above may cause hearing disorder.

1.2.7 Precautions for flammable materials

To prevent fire, explosion and rupture, ensure to follow the instructions below:




- Remove all flammables within 33 ft (10 m) of the welding arc so that sparks and spatter do not strike flammable materials. If this is not possible, tightly cover them with noncombustible covers.
- When welding on a ceiling, floor, bulkhead or partition, remove all flammable materials in hidden places.
- Tighten all cable connections and insulate them.
 Loose connection in the cable and current path of the base metal such as steel frame may cause electric shocks and fire hazards from energization.
- Connect power cable for base metal as close to the welding area as possible.
- · Do not weld on gas pipe and closed containers such as tanks or drums.
- Performing arc welding on flammable object such as fuel tank may cause explosion. Furthermore, welding on closed container such as tanks and pipes may cause burst.
- Watch for fire and keep a fire extinguisher near the welding area.
- Periodically blow the parts of welding power source with dry compressed air to remove dust.
 - Powder dust accumulating inside may cause insulation deterioration, resulting in electric shock or fire.
- Do not place hot base metal after welding near flammable materials.
 Spatter and hot base metal after welding can cause fire.
- · Do not place the welding power source near combustible materials or flammable gas.
- Do not place the welding torch near the wire feeder or the frame of wire reel stand.
- When there is an electrical connection between a workpiece and the frame of wire feeder or the wire reel stand, arc may be generated and cause damage by a fire if the wire contacts the frame or the workpiece.


1.2.8 Precautions for gas cylinder and gas regulator

To prevent falling of gas cylinder, gas regulator explosion and accident caused by gas, ensure to follow the instructions below:



MARNING





- Read and follow instructions on compressed gas cylinders, associated equipment, and the CGA publication P-1 listed in PRINCIPAL SAFETY STANDARDS.
- Keep the cylinder upright and securely chained to a stationary support or a rack.
 Falling or tipping of cylinder may cause serious injury.
 In opening the valve of gas cylinder, keep your face away from the gas discharge port.
- Keep protective cap in place over valve except when gas cylinder is in use or connected for use.
- Do not place the gas cylinder under high temperature.
- Protect compressed gas cylinders from excessive heat, mechanical shock, and arcs.
- Do not set welding torch to the cylinder or touch the cylinder with welding electrode.
- For the gas regulator, make sure to use a device for compressed gas cylinder that conforms to the specific application of the shield gas.
 Using an inappropriate gas regulator may cause explosion.

1.2.9 Precautions for rotating part

To prevent being caught/pinched by the rotating parts, ensure to follow the instructions below:



MARNING

 Keep your hands, fingers, hairs and clothes away from the rotating cooling fan, open parts around the cooling fan and feed roll of the wire feeder.

1.3 Principal Safety Standards

Arc welding equipment – Installation and use, Technical Specification IEC 62081, from International Electro technical Commission

Arc welding equipment Part 1: Welding power sources IEC 60974-1, from International Electro technical Commission

Safety in Welding and Cutting, ANSI Standard Z49.1, from American Welding Society.

Safety and Health Standards, OSHA 29 CFR 1910, from Superintendent of Documents, U.S. Government Printing Office.

Recommended Practices for Plasma Arc Cutting, American Welding Society Standard AWS C5.2, from American Welding Society.

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers That Have Held Hazardous Substances, American Welding Society Standard AWS F4.1, from American Welding Society.

National Electrical Code, NFPA Standard 70, from National Fire Protection Association. Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association.

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association, Standards Sales.

Safe Practices For Occupation And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute.

Cutting And Welding Processes, NFPA Standard 51B, from National Fire Protection Association.



· The codes listed above may be improved or eliminated. Always refer to the updated codes.

Chapter 2 Product Specification and Configuration

This chapter explains the specification, name of each parts and configuration of the welding power source.

2.1 Specification

This section explains the specification and external dimension of the welding power source.

2.1.1 Specifications

This chapter explains the specification of the welding power source.

			Welbe	e M350 II			Welbee M500 II		I
Specification/Model/ Number of phase/	Thre	ee phase		Si	ngle phase		Thr	ee phase	
Welding method	DC	DC TIG	DC STICK	DC	DC TIG	DC STICK	DC	DC TIG	DC STICK
Model			WE	3-M352			WB-M502		
Rated frequency				50/60 Hz			_1		
Rated input voltage	20	8/230 V		2	08/230 V			460 V	
Rateu Iliput voitage		460 V			460 V			460 V	
la acido calda da canada	208/2	230 V ±10°	%	208/	/230 V ±10	%	400		
Input voltage range	460) V ±10%		46	60 V ±10 %		460) V ±10 %	
D. I. J. I.	15.3 kVA	, 13.1 kW	(*1)	11.3 k	VA, 8.4 kW ((*1)			
Rated input	15.0 kVA	, 13.3 kW	(*2)	10.9 k	VA, 8.3 kW	(*2)	25.2 k	VA, 22.9 k	W
	42.5/	37.4 A (*1	•			L)			
Rated input current	18.	.8 A (*2)		23.7 A (*2)		31.7 A			
Rated output current	350 A	١	300 A		250 A		500 A	40	0 A
Rated output voltage	31.5 V	24 V	32 V	26.5 V	20 V	30 V	39 V	26 V	36 V
Marrian na land rakawa (#2)	78	3 V (*1)	I		78 V (*1)	1		04.77	
Maximum no-load voltage (*3)	70	0 V (*2)			70 V (*2)		- 81 V		
Rated duty cycle	60 %		80 %	60 %			100 %		
Number of welding condition			,	•	100				
Temperature rise				+32	0°F (+160°	C)			
Operating temperature range				+14 to +1	.04°F (-10 t	o 40°C)			
Operating humidity range			up to 5	50% at 104°F (4	<i>,,</i> .		(20°C)		
Storage temperature range				-4 to 13	1°F (-20 to	55°C)			
Storage humidity range				50% at 104° F (40° C), up to 90% at 68° F			, ,		
External dimensions (W×D×H)	15.6" × 28.0" × 31.9" (395 mm × 710 mm × 810 mm) (w/o e) (w/o eyebolt)			
Mass			187.0	lbs (85 kg)			170 lbs (77 kg)		1
Static characteristic	Constant voltage characteristic		t current teristic	Constant voltage Constant current		Constant voltage characteristic		t current eteristic	
IP Rating					IP23				

^{*1:} Rated input voltage is 208/230 V.

 $^{^{*}2}$: Rated input voltage is 460 V.

^{*3:} In some countries, Maximum no-load voltage is also known as U₀ or OCV (see CAN/CSA-W117.2).

2.1.2 Applicable welding method

This section explains the applicable welding method (shield gas/wire type/welding type) and wire diameter. Standard specification $\frac{1}{2}$

WELDING	GAS (*1)	WIRE MATERIALS	WIRE [TRAVEL SPEED	Penetration		
METHOD GAS (1		WINE MATERIALS	WB-M352 WB-M502		TRAVEL SI LED	adjustment	
	CO ₂	MILD STEEL	.030 / .035 / .040 / .045 (0.8/0.9/1.0/1.2)	.035/.040/.045/.052/1/16 (0.9/1.0/1.2/1.4/1.6)	STANDARD (*2)/HIGH	Enable	
		MILD STEEL	.030 / .035 / .040 / .045 (0.8/0.9/1.0/1.2)	.035/.040/.045/.052/1/16 (0.9/1.0/1.2/1.4/1.6)	STANDARD (*2)/HIGH	Enable	
	MAG (20% CO ₂)	MILD STEEL CORED	.045 / .052 (1.2/1.4)	.045 / .052 / 1/16 (1.2/1.4/1.6)	STANDARD (*2)	Enable	
DC		METAL CORED	.045/.052 (1.2/1.4)	.045 / .052 / 1/16 (1.2/1.4/1.6)	STANDARD (*2)	Enable	
		STAINLESS CORED	.045 (1.2)	.045 / 1/16 (1.2/1.6)	STANDARD (*2)	Enable	
	MIG	STAINLESS STEEL	.030 / .035 / .040 / .045 (0.8/0.9/1.0/1.2)	.040 / .045 / 1/16 (1.0/1.2/1.6)	STANDARD (*2)/HIGH	Enable	
	(2% O ₂)	STAINLESS FERRITE	.030 / .035 / .040 / .045 (0.8/0.9/1.0/1.2)	.045 (1.2)	STANDARD (*2)/HIGH	Enable	
	MIG	SOFT ALUMINUM	.045 / 1/16 (1.2/1.6)	.045 / 1/16 (1.2/1.6)	STANDARD (*2)/HIGH	-	
	(100% Ar)	HARD ALUMINUM	.045 / 1/16 (1.2/1.6)	.045 / 1/16 (1.2/1.6)	STANDARD (*2)/HIGH	-	
DC TIG	-	-	-	-	-	-	
DC STICK	-	-	-	-	-	-	

^{*1:} Note that the "collective" voltage adjustment may not meet the appropriate condition if a mixing gas other than those with the following mixing ratios is used.

MAG gas: Argon (Ar) 80 % + Carbon dioxide (CO₂) 20 %

MIG gas: Argon (Ar) 98 % + Oxygen (O $_{\!\scriptscriptstyle 2})$ 2 %


MIG gas: Argon (Ar) 100%


(6.7.2.1 F1: Standard/Extended cable mode)

^{*2:} For "STANDARD" mode, the standard mode or extended cable mode (extended mode of power cable) is available.

2.1.3 External dimensions

This section explains the external dimensions of the welding power source.






2.1.4 Rated duty cycle

This section explains the rated duty cycle of the welding power source.

CAUTION


- Use this welding power source at or under the rated duty cycle.
 Exceeding the rated duty cycle may result in deterioration and damage to the welding power source.
- Periodically blow moisture-free compressed air to clean dust and dirt accumulated on the transistor and radiation fin of the diode.
 If dust and dirt accumulate on the radiation fin, it may not only reduce the duty cycle but also result in degradation or burnout of the welding power source.
- The rated duty cycle of the welding power source is the following:
 (Rated duty cycle of 60% means the power source must be rested for 4 minutes after 6 minutes of continuous welding at the rated current.)


Welding power source	Number of phase	Welding method	Rated output	Rated duty cycle	
	Three	DC DC TIG	350 A	60%	
WB-M352	phase	DC STICK	300 A	80%	
WB-W332	Single phase	DC			
		DC TIG	250 A	60%	
	pilase	DC STICK			
	Thron	DC	500 A		
WB-M502	Three phase	DC TIG	400 A	100%	
	pridae	DC STICK	400 A		




<Operation cycle at duty cycle of 60 %>

- Use the welding power source within its usable range by observing the duty cycle for the welding current.
 <Relationship between welding current and duty cycle (WB-M352)>
 - Three phase







- Single phase



<Relationship between welding current and duty cycle (WB-M502)>





· Use the welding power source within the lowest rated duty cycle of combined accessories such as welding torches.

2.2 Product Configuration

This section explains the standard or optional composition of the welding power source and parts to be prepared by customers.


2.2.1 Standard composition

This section explains the standard composition of the welding power source.

For equipment used in combination with the welding power source connected to robot, refer to the instruction manual of the robot controller.

CAUTION


- Use this welding power source in combination with the specified wire feeder.
 Connecting to any equipment other than specified may cause failure of the welding power source.
- · When air-cooled welding torch is used



No.	Name	Required component	Optional accessories	Remarks
1	Gas regulator			To be prepared by the customer. (2.2.3 Accessory (not supplied))
2	Wire feeder	✓		
3	Welding torch	✓		
4	Gas hose [10 ft (3 m)]	✓		(*1) Included in feeder
5	Control cable for wire feeder [5 ft (1.5 m)]	✓		(*1) Included in feeder
6	Power cable for torch side	✓		(*1)
7	Power cable for base metal side	✓		(*1)
8	Shield gas			To be prepared by the customer. (2.2.3 Accessory (not supplied))
9	Digital remote control (optional)		✓	E-2454 (2.2.4 Optional accessories)
10	Analog remote control [10 ft (3 m)] (optional)		✓	K5804S00 (*1)

^{*1:} Optional extension cable and hose [16 ft/33 ft/50 ft/66 ft (5 m/10 m/15 m/20 m)] are also available. (2.2.4 Optional accessories)

· At TIG welding:




No.	Name	Required component	Optional accessories	Remarks
1	Gas regulator			To be prepared by the customer.
2	Welding torch			(2.2.3 Accessory (not supplied))
3	Gas hose [10 ft (3 m)]	✓		(*1) Included in feeder (*2)
4	Power cable for base metal side	✓		(*1) Included in feeder
5	Shield gas			To be prepared by the customer. (2.2.3 Accessory (not supplied))
6	Digital remote control (optional)		✓	E-2454 (*1)
7	Analog remote control [10 ft (3 m)] (optional)		✓	K5804S00 (*1)
8	TIG valve kit (optional)		✓	K8197A00
9	Analog foot control (optional)		✓	KM3022


- *1: Optional extension cable and hose [16 ft/33 ft/50 ft/66 ft (5 m/10 m/15 m/20 m)] are also available. (2.2.4 Optional accessories)
- *2: The TIG valve kit, which is an optional accessory item, enables you to lay piping in the welding power source. (3 2.2.4 Optional accessories)

/ TIPS

- The TIG valve kit, which is an optional accessory item, enables you to lay piping in the welding power source. When using this kit, turn ON F81.
 6.7.2.48 F81: TIG Mode torch switch setting)
- For the procedure for installing the TIG valve kit (optional accessory) to the welding power source, refer to the instruction manual of the TIG valve kit. Connect the kit to the torch as shown in the following figure.
- For WB-M502, in order to use the TIG valve kit, the power cable for torch side (BKPJT-60R2) is necessary.



• At DC STICK welding:



No.	Name	Required component	Optional accessories	Remarks
1	Welding electrode holder			To be prepared by the customer. (\$\sigma 2.2.3 \text{ Accessory (not supplied))}\$
2	Power cable for welding electrode holder [AWG2 (38mm²) or more]	✓		
3	Power cable for base metal side	✓		(*1)
4	Digital remote control (optional)		✓	E-2454 (*1)
5	Analog remote control [10 ft (3 m)] (optional)		✓	K5804S00 (*1)

^{*1:} Optional extension cable and hose [16 ft/33 ft/50 ft/66 ft (5 m/10 m/15 m/20 m)] are also available. (3 2.2.4 Optional accessories)

2.2.1.1 Wire feeder and welding torch

Wire feeder and welding torch are provided as standard component of the welding power source. Refer to the instruction manuals for details.

2.2.2 Accessory (supplied)

The section explains the accessories for the welding power source. Check for the warranty, instruction manual (this publication), and the quantity of parts when opening the package.

Welding power source	Product name	Part No.	Q'ty	Remarks
WB-M352	-	-	-	
	Feed roll [Φ0.045-3/64 / 1/16 (Φ1.4/1.6 mm)]	K5439B01	2	
WB-M502	Outlet guide [Φ 0.045 - 1/16 (Φ 1.2 - 1.6 mm)]	K5977J03	1	
	Allen wrench No.8	-	1	Fixing of the output terminal screws

2.2.3 Accessory (not supplied)

This section explains the accessories to be prepared by the customer before operating the welding power source. Prepare the following:

· Gas regulator

For the gas regulator, make sure to use a device for compressed gas cylinder that conforms to the specific application of the shield gas.

· Shield gas

Use a shield gas suitable to the welding method.

Name	Remarks	
CO ₂ gas	Carbon dioxide (CO ₂) 100 %	
MAG gas	Argon (Ar) 80 % + Carbon dioxide (CO ₂) 20 %	
MIG gas (stainless)	Argon (Ar) 98 % + Oxygen (O ₂) 2 %	
MIG gas (aluminum/aluminum-bronze/silicon-bronze)	Argon (Ar) 100 %	

Cooling water circulation device

In using the water-cooled welding torch, prepare a cooling water circulation device.

Welding torch (for TIG welding)

For TIG welding, prepare a torch for TIG welding as well as a gas hose.

Welding electrode holder (for DC STICK welding)

For DC STICK welding, prepare a welding electrode holder and a welding electrode.

WB-M352: Use a cable connector for connection (Specification: DIX SK 50/Part No.: 4734-016) to the welding power source

WB-M502: Use a crimp-style terminal for connection (Specification: R80-10/Part No.: 100-1298) to the welding power source.

2.2.4 Optional accessories

This section explains the optional accessories used with the welding power source.

2.2.4.1 Remote control, voltage detection cable and other optional items

Following items are optionally available including remote control and voltage detection cable.

Product name	Part No. (Model)	Remarks	
Analog remote control	K5804S00	Includes 10 ft (3 m) cable	
Analog foot control	KM3022		
Conversion cable	K8116E00	Used when the conventional analog remote control (K5416Z00) is used	
Digital remote control	E-2454	CAN communication cable and BKCAN conversion connector are separately required.	
CAN communication cable	BKCAN-0405	16 ft (5 m)	
	BKCAN-0410	33 ft (10 m)	
BKCAN conversion connector	K5810B00		
Welding interface unit	IFR-101WB	For robots by other manufacturer	
CAN communication module	K5422C00	For using both the digital remote control and servo feeder for CAN.	
PC welding monitor	K-7496		
Voltage detection cable	K5416N00	Base metal side, 33 ft (10 m)	
Voltage detection cable	K5416G00	Base metal side, 99 ft (30 m)	
Fieldbus connection tool	IFR-800	(*1)	
TIG valve kit	K8197A00	For WB-M502, in order to use the TIG valve kit, the power cable for torch side (BKPJT-60R2) is necessary.	

*1: IFR-800El (EtherNet/IP connection type)

IFR-800PB (PROFIBUS connection type)

IFR-800DN (DeviceNet connection type)


IFR-800PN (PROFINET connection type)

2.2.4.2 Details on extension cables and hoses

Following extension cables and hoses are optionally available. For extending the working radius, use extension cable and hose according to the working radius.

CAUTION

- When using extension cables, roll them out.
 Winded extension cable may cause an unstable arc.
- Use extension cables with suitable length.
 Unnecessarily long extension cable may cause an unstable arc.



Product name	Model				
	16 ft (5 m)	33 ft (10 m)	50 ft (15 m)	66 ft (20 m)	
Gas hose	BKGG-0605	BKGG-0610	BKGG-0615	BKGG-0620	
Control cable for wire feeder	BKCPJ-1005	BKCPJ-1010	BKCPJ-1015	BKCPJ-1020	
3 Power cable (torch side)	BKPDT-6007 (*1)	BKPDT-6012 (*1)	BKPDT-8017 (*1)	BKPDT-8022 (*1)	
Tower cable (toron side)	BKPT-8007 (*2)	BKPT-8012 (*2)	BKPT-8017 (*2)	BKPT-8022 (*2)	
4 Power cable (base metal side)	BKPDT-6007 (*1)	BKPDT-6012 (*1)	BKPDT-8017 (*1)	BKPDT-8022 (*1)	
	BKPT-8007 (*2)	BKPT-8012 (*2)	BKPT-8017 (*2)	BKPT-8022 (*2)	
Control cable for remote control	BKCPJ-0605	BKCPJ-0610	BKCPJ-0615	BKCPJ-0620	
	Gas hose Control cable for wire feeder Power cable (torch side) Power cable (base metal side)	16 ft (5 m) Gas hose	Product name 16 ft (5 m) 33 ft (10 m)	Product name 16 ft (5 m) 33 ft (10 m) 50 ft (15 m) Gas hose BKGG-0605 BKGG-0610 BKGG-0615 Control cable for wire feeder BKCPJ-1005 BKCPJ-1010 BKCPJ-1015 Power cable (torch side) BKPDT-6007 (*1) BKPDT-6012 (*1) BKPDT-8017 (*1) BKPT-8007 (*2) BKPT-8012 (*2) BKPT-8017 (*2) BKPDT-6007 (*1) BKPDT-6012 (*1) BKPDT-8017 (*1) BKPT-8007 (*2) BKPT-8012 (*2) BKPT-8017 (*2)	

*1: WB-M352


*2: WB-M502

2.3 Part Names

This section explains the part names of the welding power source.


2.3.1 Front panel

The section explains the front section of the welding power source.



2.3.2 Rear panel

The section explains the rear section of the welding power source.



Chapter 3 Transportation and Installation

This chapter explains the necessary equipment, installation environment and transportation method for installing the welding power source.

3.1 Required Equipment

This section explains the necessary power supply equipment for installing the welding power source and equipment for preventing lack of oxygen and dust hazard during welding.

3.1.1 Welding power source equipment

For installing the welding power source, power source equipment and protective device that meet the following ratings are required.



MARNING

 When the welding power source is used in a humid environment such as construction site, or location with highly conducting material such as steel plate or on steel structure, install a leakage breaker.

Otherwise, electric shock due to leakage of electricity may occur.

 Be sure to install a switch with fuse or a circuit breaker to the input side of each welding power source.

Otherwise, electric shock and fire due to overcurrent or damage to the welding power source may occur.

Equipment		Rating		
	Supply voltage		WB-M352	Three phase/Single phase: 208/230/460 V±10%
Welding power source equipment			WB-M502	460 V±10%
	Installed	Installed capacity		Three phase: 16 kVA or more Single phase: 12 kVA or more
			WB-M502	26 kVA or more
Swit Protective device			WB-M352	Three phase: 60 A or more for 208/230 V 30 A or more for 460 V
		Switch capacity		Single phase: 70 A or more for 208/230 V 40 A or more for 460 V
	Contacts outstandings		WB-M502	50 A or more
	Switch with fuse	Fuse	WB-M352	Three phase: 60 A for 208/230 V 30 A for 460 V
				Single phase: 70 A for 208/230 V 40 A for 460 V
			WB-M502	50 A
	No-fuse breaker (or leakage breaker) (*1)		WB-M352	Three phase/Single phase: 75 A
			WB-M502	50 A

^{*1:} High sensitivity type leakage breaker is recommended for installing a leakage breaker. (Consult the breaker manufacturer for details)

3.1.1.1 Use of the engine generator and auxiliary power

CAUTION

• To prevent the welding power source from being damaged or arc loss, follow the instructions below.

When using an engine generator for the welding power source, pay attention to the following.

- Set the output voltage of the engine generator to the voltage range between 400 and 420 V at no-load welding operation.
 - Setting to an extremely high output voltage may result in damage to the welding power source.
- Use an engine generator with a damper winding that has a capacity of more than twice the rated input (kVA) of the welding power source.
 - Generally, the recovery time of the engine generator's voltage for load change is slower than that of the commercial power source. If the engine generator does not have sufficient capacity, sudden current change such as arc start will occur and this may result in an abnormal decrease in output current or arc loss.
- Be sure to use a single welding power source with a single engine generator. If more than two welding power sources are combined, output voltage will become unstable with a likely result of arc loss.

Use the auxiliary power of engine welder with an improved voltage waveform. Some engine welders have poor electricity that may cause product damage on the welding power source.

3.1.2 Ventilation equipment/partial exhaust facility

This section explains the ventilation equipment and partial exhaust facility in welding work area.

3.1.2.1 Ventilation equipment

When welding is required in tank, boiler, reaction tower, or hold of a ship, closed space, or any other places of poor ventilation, ensure to provide ventilation equipment.

Condition of ventilation equipment:

Oxygen concentration of 18 % or more must be maintained in the welding work area.



MARNING

- Gas of larger gravity than that of oxygen, such as carbon dioxide gas or argon gas, retains at the bottom part.
 - To prevent anoxia due to the retention gas, provide ventilation equipment.
- When it is difficult to provide ventilation equipment or the ventilation equipment does not give sufficient performance, ensure to use respiratory protective equipment.
- Periodically inspect the ventilation equipment to ensure correct and proper performance of ventilation.

3.1.2.2 Partial exhaust facility

To prevent any health damage due to poisonous gas or particle substances (fume) emitted in the welding operation, provide partial exhaust facility.



⚠ WARNING

 When it is difficult to provide a partial exhaust facility or the ventilation or exhaust facility does not give sufficient performance, ensure to use the respiratory protective equipment.

3.2 Installation Environment

This section explains the installation environment of the welding power source.

⚠ WARNING

 For prevention from fire or damage to the welding power source, be sure to install in a location that satisfies the following environment:

3.2.1 Installation environment

- Location with no combustible materials or flammable gas
 If combustible materials cannot be removed, cover them with noncombustible covers.
- Location with no scattering of organic solvent, chemicals, cutting oil, and composition oil or atmosphere
 containing the above
 Such materials cause crack (breaking) and deterioration in the plastic part.
- Location with no exposure to direct sunlight or rain
- Robust and flat floor surface such as concrete pavement
 Assure sufficient floor face strength to ensure that the weight of welding power source can withstand.

 Face the surface with the eyebolt on upside to prevent from falling.
- Location with an ambient temperature of +14 to +104°F (-10 to 40°C)
- No condensation at location with an ambient humidity of 50% or lower (ambient temperature of 104°F (40°C)), and 90% or lower (ambient temperature of 68°F (20°C))
- Location with an incline of 10° or less (For the welding power source with wheels, use chock to prevent from sliding.)
- Location with no metallic foreign body such as spatter entering the welding power source
- Installation distance of 11.8" (30 cm) or more between the welding power source and the wall or other
 welding power source
 Ensure not to block the ventilation hole.
- Location with no wind on the arc section Install a wind shield to protect arc from wind.

3.2.2 Electromagnetic interference

To prevent electromagnetic troubles, read the following. Also, if electromagnetic troubles occur, check the following again.

- Shorten the input / power cable or keep it away from other cables and equipment.
- Change the installation place of the welding power source.
- · Mount an input cable in the grounded metallic conduit.
- Shield the whole welding places from electromagnetic trouble. If electromagnetic troubles are still not solved after following the above instructions, consult your nearest dealer.
- Add an appropriate line filter on the equipment or welding power source side.

3.3 Transportation Procedure

This section explains the procedure for transportation of the welding power source.



MARNING

- Do not touch the input and output terminals and the internal live electrical parts of the welding power source.
 - It may cause electric shock.
- Shut off the input power with the disconnect switch all turned off even the distance of transportation is short.
 - If work is performed while the input power is on, electric shock may occur.

CAUTION

- During transportation, be careful not to get the hand, leg or other body part caught between the welding power source and floor.
- Do not apply strong shock to the welding power source when placing it on the floor. It may cause damage to the welding power source.

Since large current abruptly flows inside the welding power source during welding, other machine near the welding power source may be failed due to electromagnetic noise. Follow the instructions below:

- Do not ground the welding power source commonly with other machines.
- Close and fix all doors and covers of the welding power source.
- · Do not use an unnecessarily long cables.
- Place a base metal cable and a torch side cable as closely as possible.

In the event of electromagnetic problems, follow the instructions below:

- Change the installation place of the welding power source.
- Keep the machines which may be affected away as far from the welding power source, cables, and welding site as possible.
- Add a noise filter to the input cables.

3.3.1 Transportation with lifting lug

This section explains the procedure for transportation with lifting lug such as a crane.



⚠ WARNING

For preventing falling of the welding power source and resulting accidents, be sure to observe the following:

- For operation of a crane or hoisting, make sure that a qualified personnel operate them with attention to the surrounding area for safety.
- Use the lifting tool such as wire and shackle suitable for the weight of the welding power source. Hoist according to the specified procedure.
- Lift the welding power source alone with two wires using all of the eyebolts.
- Do not hoist with tools and other devices placed on the welding power source.
- Make sure beforehand that the eyebolts on the surface of welding power source are not loose. Tighten the eyebolts when they are loose.



1. Attach the lifting lug with the eyebolts.



2. Lift the welding power source carefully paying attention to the balance by using lifting lug.

3.3.2 Manual transportation with carts


This section explains the manual procedure for transportation using equipment such as a cart.

MARNING

- When lifting the welding power source, make sure to hold the bottom of the welding power source by more than one person.
 - If attempting to lift by holding the front plastic part, top cover, side plates, it may cause back pain, deformation or damage to the welding power source.
- When using a tool such as carriers, it must be suitable for the weight of the welding power source.
 - Otherwise, falling of the welding power source may occur.



1. For welding power source with wheels, use the wheel and push it carefully to prevent it from falling.



2. When using a tool such as carriers, secure the welding power source and carrier with a rope before transporting.

Chapter 4 Connection

This chapter explains the procedure for connecting the welding power source.

4.1 Precautions for Connection Procedure and Grounding

This section explains the precautions for connection and grounding procedure. For protection from serious injury or fire, observe the following:



MARNING

For protection from electric shock, observe the following points:

- Wear protective equipment such as protective gloves, safety shoes and long-sleeve clothes.
- Do not touch the input and output terminals and the internal live electrical parts of the welding power source.
- Have a qualified electrical engineer ground the case of the welding power source and base metal or jig electrically connected in accordance with local regulation.
- Make sure to cut the input power with the disconnect switch in the box connected to the
 welding power source. Do not turn on the input power before confirming the completion
 of connection.
- Use a cable with specified thickness. Do not use damaged cable or cable with stripped conductor.
- Ensure to tighten and insulate the connection of cables.
- Securely attach the case and cover of the welding power source after connecting the cables.
- When extending the cable, use only the specified extension cable. Do not extend the cable by connecting the round terminals.


4.2 Connecting the Welding Power Source

This section explains the procedure for connecting the welding power source. Follow the steps below for connection of the welding power source.



MARNING

Do not turn on the input power of the welding power source until confirming the completion of connection work. Otherwise, electric shock may occur.




4.2.1 Connection of cable at output side

This section explains the procedure for connecting of cable at output side.



MARNING

- Use a grounding cable for the case, of welding power source and perform grounding.
 Otherwise, voltage may increase in the case or base metal which could cause electric shock.
- WB-M352




STEP

- 1. Connect the power cable for base metal side to the output terminal (base metal side) and base metal.
 - At the welding power source side, fit the convex part of the connector and concave part of the output terminal for secure connection and tighten them in the clockwise direction.
- 2. Connect the power cable for torch side to the output terminal (torch side).
 - Connect the connectors as same as above.

Connection for cable at output side is complete. Procedure is followed by "4.2.2 Connection of wire feeder".

• WB-M502



STEP

- 1. Remove the output terminal cover.
- 2. Connect the power cable for base metal side to the output terminal (base metal side) and base metal.
 - At the welding power source side, remove the fixing screws of the output terminals. Fix firmly the round terminals of the power cable for base metal side with the fixing screws.
- 3. Connect the power cable for torch side to the output terminal (torch side).
 - Connect the connectors as same as above.
- 4. Restore the output terminal cover.
 - Connect the connectors as same as above.

Connection for cable at output side is complete. Procedure is followed by "4.2.2 Connection of wire feeder".

4.2.2 Connection of wire feeder


This chapter explains the connecting procedure of the wire feeder. Refer also to the instruction manual of wire feeder.

CAUTION

 When not using an analog remote control (optional accessory), do not remove the cap for the analog remote control.

/ TIPS

• When using the voltage detection cable, the wiring for the wire feeder or welding power source needs to be changed. (4.6 Wiring of Voltage Detection Cable at Base Metal Side)




STEP

- 1. Remove the right side panel of the wire feeder.
- 2. Connect the power cable for wire feeder (torch side) to the M10 terminal.
 - Secure it with a nut so that there is no looseness at the terminal.
 - Avoid any washer or spring washer from getting caught between the crimp terminals.
- 3. Remove the cap of the socket of wire feeder and insert the control cable (10 cores) to the socket for the wire feeder.
 - Fit the concave part of the connector and convex part of the socket for secure connection and tighten the knurled screws in the clockwise direction.
 - When using an analog remote control (optional accessory), remove the cap of socket for analog remote control and insert the control cable (6 cores).
- 4. Restore the right side panel of the wire feeder.

Connection for wire feeder is complete. Procedure is followed by "4.2.3 Connection of welding torch".

4.2.3 Connection of welding torch

This section explains the procedure for connecting the welding torch.



- 1. Connect the torch cable to the wire feeder.
 - Fit the form of the connector with that of the terminal, fully insert the connector.
- 2. When using the water-cooled welding torch, connect the water feeding hose and condensing hose of the welding torch to the wire feeder.
 - Fully insert the hose end to the connection port of wire feeder.For disconnection, hold the hose end, and press the collar part to the arrow mark direction shown in the figure.


Connection for welding torch is complete. Procedure is followed by "4.2.6 Connection of shield gas".

4.2.4 Connection at TIG welding

A CAUTION

- In using the welding power source for TIG welding, prepare a welding torch by the customer.
- Contrary to the normal connection, the TIG welding requires connection of the welding torch to the output terminal (base metal side). Also, connect the power cable for base metal side to the output terminal (torch side).
- After five seconds have passed, the safety voltage (approx.15 V) is automatically provided.

CHAPTER




STEP

- 1. Connect the power cable for torch side to the output terminal (base metal side).
 - At the welding power source side, fit the convex part of the connector and concave part of the output terminal for secure connection and tighten them in the clockwise direction.
- 2. Connect the power cable for base metal side to the output terminal (torch side) and base metal.
 - Connect the connectors as same as above.
- Connecting TIG valve kit

TIPS

- For the procedure for installing the TIG valve kit (optional accessory) to the welding power source, refer to the instruction manual of the TIG valve kit. Connect the kit to the torch as shown in the following figure.
- For WB-M502, in order to use the TIG valve kit, the power cable for torch side (BKPJT-60R2) is necessary.




4.2.5 Connection at DC STICK welding

⚠ CAUTION

- In using the welding power source for DC STICK welding, prepare a welding electrode holder by the customer.
- After five seconds have passed, the safety voltage (approx. 15 V) is automatically provided.
- WB-M352

/ NOTE


 When using the welding electrode holder, the specified connector needs to be attached to the welding electrode holder side in the same way as the base metal side cable.



STEP

- 1. Connect the power cable for base metal side to the output terminal (base metal side) and base metal.
 - At the welding power source side, fit the convex part of the connector and concave part of the output terminal for secure connection and tighten them in the clockwise direction.
- 2. Pass the cable (welding electrode holder side) through the grip of the specified connector.
 - The length of the conductor shall be about the same as the length of the sleeve.
- 3. Attach the sleeve to the conductor of the cable.
- 4. Insert the sleeve into the connector terminal, and fix the sleeve using a screw.
 - Tighten the screw at 12 N•m using a hexagonal wrench.
- 5. Fit the grip onto the connector terminal.
- 6. Connect the power cable for welding electrode holder side to the output terminal (torch side).
 - Connect the connectors as same as above.

• WB-M502



STEP

- 1. Remove the output terminal cover.
- 2. Connect the power cable for base metal side to the output terminal (base metal side) and base metal.
 - At the welding power source side, remove the fixing screws of the output terminals. Fix firmly the round terminals of the power cable for base metal side with the fixing screws.
- 3. Connect the power cable for welding electrode holder side to the output terminal (torch side).
 - Connect the connectors as same as above.
- 4. Restore the output terminal cover.

4.2.6 Connection of shield gas

This section explains the procedure for connecting the shield gas. Refer also to the instruction manual of wire feeder.




MARNING

 Be sure to observe the following points to prevent from suffocation due to gas leakage or explosion.



- -Be sure to turn off the shield gas at the main tap when the welding power source is not in use.
- -Securely connect the gas hose and attach the gas regulator with a wrench so that there is no gas leakage.
- For the gas regulator, make sure to use a device for compressed gas cylinder that conforms to the specific application of the shield gas.
 Using an inappropriate gas regulator may cause explosion.
- Keep the cylinder upright and securely chained to a stationary support or a rack.
 Falling or tipping of cylinder may cause serious injury.
- · After five seconds have passed, the voltage is automatically provided.





- Before mounting the gas flow meter, open and close the valve of the gas cylinder, and blow off the dust at the connections.
- 2. Attach the gas regulator to the gas cylinder.
- 3. Connect the gas hose to the gas regulator and the wire feeder.
 - For TIG welding, connect the gas hose to the welding torch for TIG welding.

Connection for shield gas is complete.

In using the air-cooled welding torch, continue to perform the step described in "4.3 Grounding and Connection of Input Power Supply".


4.3 Grounding and Connection of Input Power Supply

This section explains the procedure for performing grounding work, connecting the welding power source and input power supply (power supply at facility side).



MARNING

- When the welding power source is used in a humid environment such as construction site, or location with highly conducting material such as steel plate or on steel structure, install a leakage breaker.
 - Otherwise, electric shock due to leakage of electricity may occur.
- Be sure to install a switch with fuse or a circuit breaker to the input side of each welding power source.
 - Otherwise, electric shock and fire due to overcurrent or damage to the welding power source may occur.
- If the welding power source which is not grounded is used, voltage will be generated in
 the case through the capacitor between the welding power source input circuit and the
 case or floating capacity (electrostatic capacity naturally generated between the input
 conductor and the case metal). If you touch the case, you may suffer from electric
 shock. Be sure to ground the case of the welding power source.
- Be sure to connect the input cable (3 pcs) in the correct position and securely tighten them to the terminal block.
 Improper connection may cause electric shock, fire and damage to the welding power source.



STEP

- 1. Check that input power is turned off with the disconnect switch connected to the welding power source.
- 2. Perform grounding work for welding power source.
 - Grounding cable: AWG6 (13.3 mm²) with 0.4"Φ (10 mmΦ) terminal×1
 - ⇒ The grounding cable is a striped pattern in yellow and green or solid green.
- 3. Connect the power cables (3 pcs) to the output terminals of power source at facility side.
 - Input cable: AWG6 (13.3 mm²) with 0.4"Φ (10 mmΦ) terminal×3

Grounding and connection of input power supply is complete. Procedure is followed by "4.4 Confirmation of Connection".

4.4 Confirmation of Connection

This section explains the point of confirmation after completing all of the connections. Check for the following after the connection is complete.

- No looseness in the cable connections
 If looseness is found, tighten it to secure the connection.
- No cable of other equipment is connected to the breaker to which input cable of the welding power source is connected.
 - Connect only the cable of the welding power source to the breaker.
- Capacity of the disconnect switch and the rating of fuse and circuit breaker are appropriate. (3.1.1 Welding power source equipment)
- Perform grounding for the case of the welding power source.
 Ground terminal is properly grounded when grounding cable of the welding power source is connected to the breaker's ground terminal.
- No tools or equipments are left placed on the surface of the welding power source.

 Do not place any material on the surface of the welding power source.


4.5 Connection of External Equipment

This section explains the method for connecting the welding power source with automatic machines.

4.5.1 Connection of robot

This section explains the configuration example of connecting the welding power source with robots made by other manufacturer. When connecting with robots made by OTC, refer to the instruction manual of the robot controller.

4.5.1.1 Configuration example for connection



No.	Produc	ct name/Model	Remarks
1	Welding power source		
2	Interface: IFR-101WB		Connection robot controller cable (optional) is also available.
3	Wire feeder		 ✓ Refer to instruction manual of Interface) Wiring for wire feeder needs to be changed. ✓ 4.6.1 Wiring to wire feeder)
4	Welding torch: K2331 type curved	torch	
5	Uni-cord power cable: K5369 [3.6	ft (1.1 m)], K5370 [4 ft (1.2 m)]	
6	Control cable for wire feeder: BKC	PJ-1010 [33 ft (10 m)]	
7	Dawar aabla (tarab aida)	BKPDT-6012 [33 ft (10 m)] (*1)	
'	Power cable (torch side):	BKPT-8012 [33 ft (10 m)] (*2)	For details on cables, see: (2.2.4.2 Details on extension
8	Power cable (base metal side):	BKPDT-6012 [33 ft (10 m)] (*1)	cables and hoses)
0	Power cable (base metal side):	BKPT-8012 [33 ft (10 m)] (*2)	
9	Gas hose: BKGG-0610 [33 ft (10 i	n)]	
10	Gas regulator		To be prepared by the customer.
11	Conduit: Z318P50 (Guide adaptor attachment part: 9)/16-18UNF)	When using the conduit 7/16-20UNF, guide adaptor L7810D04 is also required.


^{*1:} WB-M352

4.5.2 Connection of automatic machine

This section explains the procedure for connection of automatic machine with the welding power source.

4.5.2.1 Wiring for connecting automatic machine


The welding power source is equipped with terminal block for external connection inside the cover for external connection at the rear. When connecting to the automatic machine, use this terminal block for external connection.



				T					
Termi	nal No.	Signal name			Function				
TM1	1-2	۸	Output for	Output terminal to connect a	WB-M352	Ammeter (400 A/60 mV) Part No. :4403-057			
IIVII	1-2	Α	ammeter	separately sold ammeter	WB-M502	Ammeter (600 A/60 mV) Part No. :4403-054			
TM2	1-2	V	Output for	Output terminal to connect a	WB-M352	Voltmeter (75 V F.S.) Part No. : 4401-016			
TIVIZ	1-2	v	voltmeter	separately sold voltmeter	WB-M502	Voltmeter (100 V F.S.) Part No. : 4401-019			
	1-2	READY	Power ready output	closes.	Then the welding power source side is ready to start welding, the contact between the terminals oses. When an error is detected, the contact opens.				
тмз	3-4	STOP	Operation stop input	Disconnecting the terminals stops output of the welding power source. When combining switches, use a push-lock, turn-reset switch for preventing accidental reset.					
	5-9	IN-EXT1	External input 1	Reserve inputs for expanding terminal functions. Setting the internal functions (Function) allows you to externally open and close the gas valve and					
	6-9	IN-EXT2	External input 2						
	7-9	IN-EXT3	External input 3	perform inching operation. (6.7 Setting Internal Functions)					
	8-9	IN-EXT4	External input 4	seriorin moning operation. (== 0.7 Octaing meanail tunctions)					
	1-2	24 V 0.2 A	24 V power source	Outputs power supply of 24 V. Current capacity: 0.2 A (Maxim	um)				
	3-4	OUT EXT1	External output 1	Extra outputs for expanding fu	Extra outputs for expanding functions				
TM4	5-6	OUT EXT2	External output 2	Setting the internal functions (Function), all	ows you to output the signal of the welding condition			
	7-8	OUT EXT3	External output 3	error.					
	9-10	OUT EXT4	External output 4	6.7.2.20 F25 to F28: External output terminal setting)					
	11-12	WCR	WCR output	When welding current is detect	ted, the conta	act between the terminals closes.			


^{*2:} WB-M502

Input signal of the external connection terminal block.
 Use switches and relays with contact capacity of 24 V/10 mA or more for connecting with the input terminal.



Output signal of the external connection terminal block
 Output signal is open collector output. Ensure to keep the maximum rated power of the transistor.


Maximum rated power of transistor READY: DC50 V/100 mA OUT EXT1 to 4: DC50 V/100 mA



WCR output signal

WCR signal is the output of relay contact. Ensure to keep the maximum rated power of the contact.

Maximum rated power of relay contact WCR: 125 VAC / 0.5 A, 30 VDC / 1 A at resistance load As a rough indication, use at 80% of the ratings.



/ NOTE

- Connect welding power source and target device after carefully read the instruction manual
 of target device. Add current limiting resistor if capacitor is connected to the contact of
 target device.
- If an ammeter is accidentally connected to the output-terminal for voltmeters, the ammeter and/or the wiring will be burnt. Fully confirm to which the ammeter is to be connected.
- When connecting a voltmeter and/or a voltmeter, be careful for short-circuit between the
 positive wiring (+) and the negative wiring (-).

4.5.2.2 Connection of terminal for external connection

This section explains the procedure for connection to the terminal for external connection.



MARNING

To prevent electric shock, ensure to follow the instructions below:

- Wiring should be performed by qualified persons or persons familiar with the welding machine.
- Do not touch the input and output terminals and the internal live electrical parts of the welding power source.
- Before starting the work, make sure to cut the input power with the disconnect switch
 connected to the welding power source and wait three minutes or more. In addition, do
 not turn on the primary power until the work is complete.
- · Do not use damaged cable or cable without grounding.
- Securely attach the case and cover of the welding power source after connecting the cables.


Use the following cable for connecting to the terminal for external connection:

- Cable thickness: AWG22 to AWG16 (0.33 to 1.3 mm²)
- Using a cable or terminal not specified will be a cause of heat generation and fire.
 Furthermore, cable other than specified cannot be connected to the terminal for external connection.

A CAUTION

- The control cable drawn out from the terminal for external connection should be kept away from the welding power cable or the torch cable as much as possible.
 Otherwise, failure may occur due to noise during use.
- Do not pull out the cables other than the cable that is connected with the terminal block on the printed circuit board.

 Malfunction or error may occur.



- (STEP)
- 1. Check that input power is turned off with the disconnect switch connected to the welding power source.
- 2. Remove the attaching screws and open the cover for external connection.
- 3. Remove the blind bush and pass the cable through.
 - Process any given blind bush among the several available types.
- 4. Connect the cable to the terminal for external connection.
 - Strip the cable cover by 25/64 to 7/16" (10 to 11 mm) from the end while pressing the button on the terminal block and insert the cable.
 - Fix the cable with cable ties so that no gap may be created between the cable and the blind bush.

5. Check the wiring and place the cover for external connection back to the welding power source.

4.6 Wiring of Voltage Detection Cable at Base Metal Side

When the extension cable is 99 ft (30 m) or more in length in total, use of the voltage detection cable at the base metal side is recommended.

The voltage detection cable needs to be wired so that the correct feedback of the arc voltage can be obtained. Connect the voltage detection cable as near as possible to the base metal to avoid detection of voltage decrease.

Use the voltage detection cable at base metal (optionally available: K5416N00 or K5416G00) by connecting with the wire feeder or to the voltage direct detection terminal at the base metal side on the front of welding power source.

When using the voltage detection cable, set the internal function F38 to "1". (\$\infty\$ 6.7.1 Setting procedure) Details on the internal function F38 (\$\infty\$ 6.7.2.23 F38: Arc voltage direct detection switching)




MARNING

 Ensure to start the operation only after shutting off the input power by the contactor of the power distribution box connecting the welding power source. Otherwise, electric shock may occur.

4.6.1 Wiring to wire feeder

This section explains how to connect the voltage detection cable at the base metal side to the wire feeder.



STEP


- 1. Check that input power is turned off with the disconnect switch connected to the welding power source.
- 2. Remove the right side panel of the wire feeder.
- Connect the voltage detection cable at the base metal side to the terminal board in the wire feeder (wire No. 310).
 - Use the voltage detection cable at the base metal side via the blind bush with film.
- 4. Restore the right side panel of the wire feeder.

Wiring of voltage detection cable is complete.

4.6.2 Wiring to welding power source

This section explains how to connect the voltage detection cable at the base metal side to the voltage direct detection terminal at the base metal side of the welding power source.

WB-M352




STEP

- 1. Check that input power is turned off with the disconnect switch connected to the welding power source.
- Connect the voltage detection cable at the base metal side to the voltage direct detection terminal at the base metal side.

Wiring of voltage detection cable is complete.

WB-M502



STEP

- 1. Check that input power is turned off with the disconnect switch connected to the welding power source.
- 2. Remove the output terminal cover.
- Connect the voltage detection cable at the base metal side to the voltage direct detection terminal at the base metal side.
- 4. Restore the output terminal cover.


Wiring of voltage detection cable is complete.

4.6.3 Wiring example of voltage detection cable

This section shows the wiring examples of the voltage detection cables at the base metal side to the base metal.

4.6.3.1 Wiring examples for plural welding stages

Connect the base metal side voltage detection cable cable to the stage farthest from the base metal side power cable which connects to the base metal terminal of the welding power supply, away from the base metal side cable.




4.6.3.2 Wiring example when power is supplied with a power feeding brush to the positioner

Insulate the power feeding brush from the jig base and connect the voltage detection cable (base metal side) to the jig base.

/TIPS

 Before wiring the voltage detection cable, check that conduction between the jig base and the base metal is stable.



/ NOTE

• If the voltage detection cable is tightened together with the cable terminal on the base metal side connected to the power supply brush, welding will become unstable.

Chapter 5 Welding Operation

This chapter explains the procedures from preparation to completion of the welding operation.

5.1 Precaution at Welding Operation

This section explains the safety precautions for welding operation.

5.1.1 Precautions for air discharge and use of respiratory protective equipment

To prevent suffocation or gas poisoning in the welding operation, ensure to follow the instructions below:



! WARNING

- When welding is required in tank, boiler, reaction tower, or hold of a ship, closed space, or any other places of poor ventilation, ensure to provide ventilation equipment.
- Gas of larger gravity than that of oxygen, such as carbon dioxide gas or argon gas, retains at the bottom part.
 To prevent anoxia due to the retention gas, provide ventilation equipment.
- When it is difficult to provide ventilation equipment or the ventilation equipment does not give sufficient performance, ensure to use respiratory protective equipment.
- For preventive measure from falling due to anoxia, apply lifelines such as a safety belt.
- For the welding operation in a narrow space, perform the operation with the trained supervisor.
- Periodically inspect the ventilation equipment to ensure correct and proper performance of ventilation.

To prevent any health damage due to poisonous gas or particle substances (fume) emitted in the welding operation, ensure to follow the precautions below:



MARNING

- To reduce the dust concentration, install a partial exhaust facility such as fume suction device, or install the collective ventilation equipment.
- When it is difficult to provide a partial exhaust facility or the ventilation or exhaust facility does not give sufficient performance, ensure to use the respiratory protective equipment.
- In performing welding or cutting the coating steel plate or galvanized steel sheet, provide a partial exhaust facility or let the welding operator as well as the surrounding operators use respiratory protective equipment. (Welding or cutting the coating steel plate or galvanized steel sheet will cause toxic gas or fume.)
- Do not perform welding operation in the vicinity of degreasing, cleansing, or spraying operation. Performing the welding operation in such places may generate poisonous gas.

5.1.2 Precaution for protective equipment

For protection from arc ray generated from welding, spatter and spattering dross and hearing disorder from noise, observe the following:



MARNING

- Wear safety goggles with sufficient blocking effect or face shield in the work area and the surrounding.
 - Ignoring the above may cause inflammation and burn from arc ray.
- Wear safety goggles in the work area and the surrounding.
 Ignoring the above may cause injury in the eye or burn from spatter and spattering dross.
- Wear protective equipment such as protective leather gloves, long-sleeve clothes, leg covers, and leather apron.
 - Ignoring the above may cause electrical shock and burn.
- Install protective screens or barriers to protect the eyes of others in the work area from arc ray.
- Wear an ear protector when noise level is high.
 Ignoring the above may cause hearing disorder.

5.1.3 Precautions on welding place

To avoid poor welding, ensure to follow the instructions below:



 When the welding is performed outside with wind or when wind is caused by the indoor ventilation facility (including fan), provide a partition to avoid the arc generating part being exposed to wind.

5.2 Check before Welding

This section explains the check parameters before welding. To avoid welding problems beforehand, check the parameters below when the welding environments are prepared. (These are the check parameters recommended by OTC. They also contain check parameters after power ON or after shield gas supply.)

For handling the cooling water circulation device, refer to the instruction manual of the cooling water circulation device. (When using the water-cooled welding torch)

	Check parameter	Countermeasures	Check
1	There should be no loose connections of the cables.	Use a proper tool to ensure connection.	
2	There should be no dirt such as oil or spatter adhering on the connection terminals or connection part of cables.	Wipe off dirt so that the metal face of connection terminal or connection part is fully exposed. Using a metal brush is effective.	
3	There should be no tightening together of the voltage detection cable (base metal side) and the cable at the base metal side.	Connect the voltage detection cable (base metal side) and the cable at the base metal side separately to a different location. Each cable should be connected to the position near to the workpiece to be welded.	
4	The voltage detection cable should be adequately wired.	The voltage detection cables at the base metal side and the torch side should be wired along each other. Keep the voltage detection cable (base metal side) at least 3.9" (10 cm) away from the cable at the base metal side.	
5	The voltage detection cable should not be damaged.	If any damage is suspected, use a tester to measure the resistance between the voltage detection cables. When the resistance is high, replace the voltage detection cable with a new one. (Reference value: 15.5 m Ω/m)	
6	The contact part of jig and welding work piece should not be painted.	Painted contact part could cause increased contact resistance, resulting in decrease in arc voltage. Polish the painted contact part using a grinder to expose the metal face.	
7	The contact part of jig and welding work piece should be free from unevenness due to influence of burn through, spatter, or aging deterioration.	Polish the surface of the jig using a grinder so that the welding workpiece and the jig can fully contact each other.	
8	The shield gas should be adequate. The mixing ratio of mixed gas should be adequate.	For shield gas, follow the mixing ratio as follows: CO_2gas : Carbon dioxide (CO_2) 100 % MAG gas : Argon (Ar) 80 % + Carbon dioxide (CO_2) 20 % MIG gas (Stainless) : Argon (Ar) 98 % + Oxygen (O_2) 2 % MIG gas (aluminum) : Argon (Ar) 100 %	
9	The shield gas should be correctly mixed.	Use a mixer. If welding is unstable, use pre-mix gas to check if the welding condition is improved. High ${\rm CO_2}$ concentration could increase spatter generation.	
10	The flow rate of shield gas should be adequate.	Ensure the adequate shield gas flow rate as follows: CO ₂ /MAG gas : 21 to 53 CFH (10 to 25 L/min) MIG gas : 32 to 53 CFH (15 to 25 L/min) TIG welding : 11 to 32 CFH (5 to 15 L/min)	
11	When the shield gas is mixed, each gas pressure should be the same.	Set pressures of the respective gas to the same level.	
12	Oil or other dirt should not be adhered on the welding wire.	Consider a measure to wipe off the dirt and to perform degreasing.	
13	In the CO ₂ - and MAG welding, the particle diameter of wire tip at the welding completion should not excessively be large or small.	Adjust anti-stick voltage so that the wire tip particle size becomes 1.2 to 1.5 times of the wire diameter. If the particle size is smaller than the above, set the anti-stick voltage to a higher value, whereas if the particle size is larger than the above, set the anti-stick voltage to a lower value.	
14	At start point of welding, the tip of welding wire and the welding workpiece should not be contacted. (When using a robot, operate several times with "welding OFF" and confirm that the welding wire and the welding workpiece do not contact each other.)	If the wire tip contacts with the welding workpiece, set anti-stick voltage to a higher value to increase meltage of the welding wire at the end of welding. If anti-stick voltage is set to a value higher than the appropriate range, the wire tip particle size becomes excessively large, resulting in poor start performance of the next welding.	
15	The tip of the welding torch should not be worn.	Visually check the hole diameter of the tip. If it is 1.2 times or larger than the hole diameter of a new tip, or when the tip is discolored, replace it with a new one.	
16	In wire feeding, pressure roll should not be idled and the wire reel should rotate smoothly.	Adjust the pressure level of wire feeder. If it is not improved, check for other factor that generates overload on wire feeding. See parameter 12, 17, 18)	
17	The groove of feed roll should not be dirty.	Clean the dirty groove with a wiry tool.	
18	There should be no large feeding resistance of wire. (With the pressurized holder of the wire feeder held up, hold the tip of welding wire with a plier, and try pulling it out; if smoothly pulled out, it is adequate.)	Ensure that the torch cable has no bending at a sharp angle. If the liner is clogged with dirt or when inched wire has flaw, replace the liner with a new one. (In replacing the liner, follow the precautions on the attached manual of welding torch for appropriate handling.) In cutting the liner, take care for the followings: If the liner is too long: feeding resistance increases, resulting in shorter life of wire feeder. If the liner is too short: feeding failure occurs.	


5.3 Power ON and Gas Supply

This section explains how to supply power and shield gas.



MARNING

- Handle the gas cylinder according to the related laws or regulations as well as the internal standard of the customer.
 - Note that the gas cylinder contains a high-pressure gas. Wrong operation may cause gas explosion, resulting in serious physical injury.
- In opening the valve of gas cylinder, keep your face away from the gas discharge port. If the connection should be loose, high-pressure gas may burst out.
- Keep your hands, fingers, hairs and clothes away from the rotating cooling fan and the open parts around the cooling fan; it could result in entanglement with the internal fan.





- 1. Supply the input power.
 - Operate the disconnect switch to supply the input power.
 - ⇒ The power LED switch lights up.
- 2. Turn ON the power switch of the welding power supply.
- 3. Check that the flow rate adjustment knob is set to "SHUT", and press the GAS CHECK key.
 - \Rightarrow The LED of the GAS CHECK key lights up, turning to the gas check status (shield gas is discharged).
 - ⇒ The gas check status continues for approximately 2 minutes, and automatically stops. To stop the gas check during the sequence, press the GAS CHECK key again to turn off the LED light.
- 4. Open the main tap of shield gas.
 - When the gas regulator is equipped with a pressure gauge, open the main tap by checking the pressure gauge until the appropriate pressure is obtained.
- 5. Turn the flow rate adjustment knob to "OPEN", and adjust the flow rate of shield gas.
- 6. Press the GAS CHECK key.
 - ⇒ The LED of the GAS CHECK key lights off, to stop gas check.


5.4 Wire Inching

This section explains the inching operation (feeding operation) of the wire.



MARNING

- Do not look into the tip of the welding torch during the inching operation. Do not bring the tip of the welding torch to face, eyes, or body.
 The wire may abruptly burst out, resulting in an injury.
- Keep hands, fingers, hair and clothes away from the feed roll of the wire feeder.
 It may cause an entanglement.



STEP

- 1. Straighten the torch cable.
 - ⇒ Bent cable may cause feeding failure of the wire or wire bending.
- 2. Press the WIRE INCH key to feed the wire.
 - Keep pressing the WIRE INCH key until the wire protrudes from the end of the tip in approximately 0.4" (10 mm). Releasing the WIRE INCH key will stop the wire feeding. For excessive wire, cut the wire using a plier.
 - \Rightarrow Turning the parameter adjusting knob during the wire feeding can adjust the feed speed.

/ TIPS

 Wire feeding is also enabled by a remote control (optional). Turning the welding current adjustment knob can adjust the feed speed. (\$\iiint\$ 6.8 Operation of Analog Remote Control (Optional))

5.5 Check and Setting of Welding Condition

This section explains how to check the welding condition as well as how to prevent erroneous operation on the operation panel (Erroneous operation prevention function).

5.5.1 Reading welding condition

Before starting the welding operation, it is necessary to set the welding conditions (such as welding current/voltage, type of shield gas, and wire type/wire diameter). (6.4 Preparing Welding Conditions)

When the welding conditions are registered to memory, it can be read out. (6.5 Memory Function of Welding Conditions)

When the condition is read, confirm that the welding conditions are correct.

5.5.2 Preventing erroneous operation on operation panel

This section explains how to prevent erroneous operation on the operation panel.

To prevent accidental change of the welding conditions, the erroneous operation prevention function is equipped for the operations other than inching, gas check, or reading/saving of the welding condition. In using the analog remote control, however, the adjustment of current/voltage by the analog remote control is available.


The erroneous operation prevention function does not need any password to release the lock. To allow only selected personnel to change the welding conditions, use the protection function of the welding conditions which requires a password. (**\textit{?}\textit{7.1}\text{ Protection of Welding Conditions})

5.5.2.1 Activating erroneous operation prevention function




1. Display "KEY LOCK" in the MENU screen.

- Turn the screen operation knob and point the cursor to KEY LOCK.
- Press the screen operation knob.



2. Press the screen operation knob.

- ⇒ This function becomes enabled, and the color of "ON" of the KEY LOCK in the MENU screen becomes inverted.
- ⇒ The key mark is displayed in the HOME screen while this function is enabled.



/ TIPS

- Turning the power switch OFF does not deactivate the erroneous operation prevention function.
- Initializing the welding condition and the internal function deactivates the erroneous operation prevention function.

(7.4 Initializing Welding Conditions and Internal Functions)

5.5.2.2 Deactivating erroneous operation prevention function



- 1. Turn the screen operation knob again to place the cursor on "KEY LOCK", and press the knob.
 - ⇒ The KEY LOCK will be released, and the color of "OFF" of the KEY LOCK in the MENU screen becomes inverted.
 - ⇒ The key mark in the HOME screen will disappear.

5.6 Performing Welding Operation

This section explains the procedure from the start to the end of the welding operation.

5.6.1 Operation of welding start

CO₂/MAG welding



- Check that the welding conditions are correctly set and operate the torch switch to start the welding. (\$\infty\$ 6.6.3 Crater setting)
 - During the welding, the welding current is displayed on the left digital meter and the welding voltage is displayed on the right digital meter both in a real time basis. This indication is the average value of the output per approximately one second.
 - ⇒ During the welding, the "Welding time", "Heat input", and "Motor current" are displayed on the LCD panel in a real time basis.
 - ⇒ During the welding, the LED for the welding sequence being carried out flashes.
- 2. A series of welding operation is completed by the torch switch operation. ($\ \odot$ 6.6.3 Crater setting)
 - ⇒ At the end of welding, the average value of the welding current and the welding voltage at the last second of the welding sequence is displayed (result display) on the digital meter in a flashing mode. (except for the output at crater-filler)
 - At the end of welding, the "Welding time", "Total welding time", "Total wire consumption", "Heat input", and "Motor current" are displayed on the LCD panel.
 - ⇒ The LED for the welding sequence changes to the light-up mode.

/ TIPS

- Pressing any key on the operation panel during the flashing display will change the indication to the set value.
- The duration of flashing display can be changed by the internal function (F8).
- When the welding time is short such as in the tack welding, accurate value may not be displayed.
- The displayed average value is processed by the software.
 The display accuracy is equivalent to an ordinary pointer-type meter (equivalent to class 2.5).
 Note that the value cannot be guaranteed as the control data for a measurement instrument.
- The wire consumption may be different from the actual wire consumption due to reasons such as slipping of wire.
- The displayed motor current value has been smoothed out. Therefore, the displayed value may not be able to trace a sudden change in the motor current.

Other welding methods



MARNING

 If the TIG valve controller will not be used in TIG welding, be sure to shut off the gas after completion of welding.

There is a risk of suffocating if closing the gas is forgotten in case opening/closing of the gas is done manually.



A CAUTION

 After five seconds have passed after switching the welding method to "DC TIG" or "DC STICK", the safety voltage (approx. 15 V) is automatically provided. Before switching the operation, make sure that the torch electrode (welding electrode) is not in contact with the base metal.



- 1. Check that the welding conditions are correctly set and carry out the following operation to start the welding.
 - For TIG welding: Contact the torch electrode with the base metal, and then raise the torch.
 - For DC STICK welding: Contact the electrode with the base metal, and then raise the electrode.
 - ⇒ During the welding, the "Welding time" and "Heat input" are displayed on the LCD panel both in a real time basis.
 - ⇒ During the welding, the LED for the welding sequence being carried out flashes.
- 2. Welding operation is completed by the following operation.
 - For TIG welding: Complete the operation by separating the torch electrode from the base metal.
 - For DC STICK welding: Complete the operation by separating the electrode from the base metal.
 - ⇒ The LED for the welding sequence changes to the light-up mode.

/TIPS


If the TIG valve controller (optional accessory) is used, the start and completion of the
welding operation can be controlled by the torch switch operation. (\$\infty\$ 6.7.2.48 F81: TIG
Mode torch switch setting)

5.6.2 Operation during welding

This section explains the operation requiring adjustment of welding current/voltage during the welding. The welding current/voltage can be adjusted during each sequence such as welding under initial condition, welding condition, or crater condition.

<u>/ TIPS</u>

 When the analog remote control (optional) is connected, the welding current/voltage under the welding condition cannot be adjusted on the operation panel. Adjust the welding current/voltage for the welding condition at the analog remote control.



STEP

1. Press the DISPLAY CHANGE key.

- ⇒ The displays of the left/right digital meter switches to the set values.
- ⇒ The LED for the welding sequence changes to the light-up mode.

2. Adjust the welding current.

- When the LED above the left digital meter is off, press the parameter adjustment knob to light up the LED. (In the adjustment by the remote control, this operation is not necessary.)
- Turn the parameter adjustment knob (for the remote control, the welding current adjustment knob) to adjust the welding current.

3. Adjust the welding voltage.

- •There is no voltage adjustment for DC TIG welding and DC STICK welding.
- When the LED above the right digital meter is off, press the parameter adjustment knob to light up the LED. (In the adjustment by the remote control, this operation is not necessary.)
- Turn the parameter adjustment knob (for the remote control, the welding voltage adjustment knob) to adjust the welding voltage.

4. Press the DISPLAY CHANGE key.


- ⇒ The displays on the left/right digital meters return to the display of current/voltage in welding.
- \Rightarrow The LED for the welding sequence returns to the flashing mode.

/ TIPS

- When no operation is performed for approximately 5 seconds, the display will return to the one showing current/voltage in welding.
- Using the internal function (F48) enables to increase/decrease the welding current by the torch switch operation. (It is available only with the crater set to on and in the welding condition.) (6.7 Setting Internal Functions)
- When "SYN." is selected in the VOLT. ADJUST menu, the voltage is automatically set to the value according to the current.

5.6.3 Operation at welding end

This section explains the supply stop procedure of power/shield gas after the welding end.



STEP

- 1. Close the main tap of the shield gas.
- 2. Press the GAS CHECK key.
 - ⇒ The LED of the GAS CHECK key lights up, and the shield gas remained in the gas piping is discharged.
- 3. After the shield gas is discharged, press the GAS CHECK key.
 - ⇒ The LED of the GAS CHECK key lights off, to stop gas check.
- 4. Set the flow adjustment knob to "SHUT", to adjust the shield gas flow rate to zero.
- 5. Turn OFF the power switch of the welding power supply.
 - ⇒ The power LED switch lights off.
- 6. Shut off the input power.
 - Operate the disconnect switch to shut off the input power.

Chapter 6 Welding Condition

This chapter explains the functions on the operation panel as well as how to set the welding conditions.

6.1 List of Welding Conditions

This section explains the parameters/functions settable in the welding power source.

6.1.1 Parameter (Welding parameter)

Paramete	er		Set Range	Initial Value	Descriptions
Pre-flow tir	Pre-flow time		0 to 10 sec 0.1 sec		Set the gas discharge time before welding starts.
		WB-M352	Three phase: 20 to 400 A 10 to 400 A (for DC TIG welding) 20 to 300 A (for DC STICK welding)	150 A 100 A (initial/ crater)	
Initialized condition/	Current	WB-IVI352	Single phase: 20 to 250 A 10 to 250 A (for DC TIG welding) 20 to 250 A (for DC STICK welding)		Initial Condition: set the current and voltage value soon after the welding.
Main condition/ Crater condition		WB-M502	20 to 550 A 10 to 400 A (for DC TIG welding) 20 to 400 A (for DC STICK welding)		Welding condition: set the current and voltage value during the welding. Crater condition: set the current and voltage value a the end of welding.
	Voltage (INDIVIDUAL) (*1)	oltage WB-M352	Three phase: 12.0 to 38.0 V	23.5 V	
		WD-WI332	Single phase: 12.0 to 34.0 V	21.5 V (initial/ crater)	
		WB-M502	12.0 to 50.0 V		
	Voltage (SYNERGY) (*1)		-100 to 100	0	
Post-flow time			0 to 10 sec	0.4 sec	Set the gas discharge time after the welding ends.
Arc spot tir		(0.1 to 10 sec	3 sec	Set the welding time at arc spot.
Arc character			-10 to 10	0	Set the arc to the condition from soft to hard.
Welding condition r	nemory No.		1 to 100	1	Register the welding conditions (storable up to 100).

^{*1:} There is no voltage adjustment for DC TIG welding and DC STICK welding.

6.1.2 Function

Function	Initial value	Setting parameter			
CRATER-FILL	CRATER-FILL-OFF	CRATER-FILL-OFF/CRATER-FILL-ON/CRATER-FILL-ON (Repeat)/ARC SPOT			
GAS	MAG (20% CO ₂)		CO ₂ /MAG (20% CO ₂) / MIG (2% O ₂) / MIG (100% Ar)		
WIRE MATERIALS	MILD STEEL	MILD STEEL/MILD STEEL CORED/METAL CORED/STAINLESS CORED/STAINLES STAINLESS FERRITE/SOFT ALUMINUM/HARD ALUMINUM			
WELDING METHOD	DC	DC/DC TIG/DC STICK			
WIRE DIA.	.045 (1.2)	WB-M352	.030 / .035 / .040 / .045 / .052 / 1/16 (0.8/0.9/1.0/1.2/1.4/1.6)		
[in. (mm)]	.043 (1.2)	WB-M502	.035 / .040 / .045 / .052 / 1/16 (0.9/1.0/1.2/1.4/1.6)		
INITIAL CONDITION	OFF		ON/OFF		
VOLT. ADJUST	INDIV.	SYNERG. /INDIV.			
CONSTANT PENETRATION	OFF	ON/OFF			

6.1.3 Internal function

Details of internal function (\mathfrak{S} 6.7 Setting Internal Functions) The functions with check mark (\checkmark) on the Memory row can be stored with the welding conditions.

No.	Function Name	Setting range	Initial value	Explanation	Memory
F1	Standard/Extended cable mode	OFF/ON	OFF	Sets the waveform control mode for voltage detection when using the welding power source in the STANDARD mode. OFF: STANDARD mode (standard mode) ON: Extended cable mode (extended mode of power cable)	-
F2	Switching functions with remote control	0/1/2/3/4/5/6	0	Sets the functions to be allocated to the switching knob of the analog remote control. 0: No functions 1: Crater setting 2: Gas check 3: Constant penetration 4: Tack Start 5: Read out of welding conditions 6: No functions	~
F3	No function	OFF (fixed)	OFF	No functions are provided.	-
F4	Auto/Semi-auto mode	0/1/2/3/4	0	Switches the I/O settings of the welding power source: 0: Semi-automatic machine 1: Automatic machine 1 2: Automatic machine 2 3: Almega (OTC's robots) specification 4: Almega (OTC's robots) specification (for high speed communication)	-
F5	Maximum external command voltage	10.0/14.0/15.0	15.0 (V)	Sets the maximum value of voltage supplied when current/voltage command is externally input.	-
F6	Up slope time	0.0 to 10.0	0.0 (s)	Sets the slope time from the initial condition to the welding condition.	✓
F7	Down slope time	0.0 to 10.0	0.0 (s)	Sets the slope time from the welding condition to the crater condition.	✓
F8	Welding result display time	0 to 60	20 (s)	Sets the display time for the current/voltage after completion of welding.	-
F9	Analog remote control scale	200/350 (*1) 200/350/500 (*2)	350 (A) 500 (A)	Configures the settings of scale plate of the analog remote control.	-
F10	Motor over current detection level	20 to 150	70 (%)	Sets the over current warning level for the rated current of the wire feed motor.	-
F11	Fine adjustment of welding conditions memory	OFF/1 to 30	OFF	Allows fine tuning the current and voltage of welding conditions stored on the memory using the analog remote control. OFF: No fine adjustment 1 to 30 (%): Fine adjustment is performed (Maximum adjustment range at this time can be set in percentage)	-
F12	Operation time of water-cooled pump	20 to 60/0N	ON	Sets the operation time of water-cooled pump after welding ends. Set the time in the range of 20 to 60 minutes or set to ON (always ON).	-
F13	Turbo start	OFF/ON	ON	Set effective and ineffective of the turbo start function. OFF: ineffective ON: effective	-
F14	Start control time adjustment	-50 to 50	0 (%)	Adjusts the control time of current at the time of start.	-
F15	Start control current adjustment	-100 to 100	O (A)	Adjusts the control of current at the time of start.	-
F16	Slow-down speed adjustment	-39 to 39 (-1.0 to 1.0)	0.0 [IPM (m/min)]	Adjusts slowdown speed.	✓
F17	Anti-stick time adjustment	-50 to 50	0 (10 ms)	Allows fine tuning meltage of the wire at the end of welding based on the anti-stick process time.	✓
F18	Anti-stick voltage adjustment	-9.9 to 9.9	0.0 (V)	Allows fine tuning meltage of the wire at the end of welding based on the anti-stick process voltage.	✓

No.	Function Name	Setting range	Initial value	Explanation	Memory
F49	Current increase and decrease by single-clicking	-100 to 100	O (A)	Sets current increase/decrease volume by single clicking of the torch switch. (available when "ON" is selected in F48)	√
F50	Current increase and decrease by double-clicking	-100 to 100	O (A)	Sets current increase/decrease volume by double clicking of the torch switch. (available when "ON" is selected in F48)	√
F51	Special crater repeat	OFF/ON	OFF	With the setting of "Crater," sets whether to switch the welding condition and crater condition by the click operation of the torch switch: OFF: not to use torch switch ON: uses the torch switch	✓
F52	Data type of data log function	0 to 8	0	Sets sample data on the data log: 0: No sampling 1: Welding current / Welding voltage / Sequence information 2: Current command / Voltage command / Feeding command 3: Current command / Welding current / Welding voltage 4: Current command / Welding current / Sequence information 5: Welding current / Voltage command / Welding voltage 6: Voltage command / Welding voltage / Sequence information 7: Welding current / Feeding command / Sequence information 8: Welding voltage / Feeding command / Sequence information	-
F53	Sampling speed of data log function	1/2/3	1	Sets sampling interval of the data log function: 1: 10 ms 2: 100 ms 3: 1 s	-
F54	Tack start process	OFF/ON	OFF	Sets whether to feed the wire with the slowdown speed at the time of welding start: OFF: Feeds with slow down speed ON: Feeds without slow down speed	-
F55	Arc loss detection time			·	
F56	Arc start error detection time WCR output ON			Used when connecting with automatic machine made by	
F57	delay time WCR output OFF	OFF (fixed)	OFF	other manufacturer.	-
F58 F59	delay time Analog setting switch				
F60 to F66	No function	OFF (fixed)	OFF	No functions are provided.	-
F67	Setting change of current value (initial condition, crater condition)	OFF/ON	OFF	When "CRATER ON" is selected, sets the current value of the initial condition and crater condition in the percentage based on the current value of the welding condition. OFF: invalid ON: settable with percentage	✓
F68	Setting of current value (initial condition)	10 to 300	100 (%)	Sets the current value of the initial condition in the percentage based on the current value of the welding condition.	✓
F69	Setting of current value (crater condition)	10 to 300	100 (%)	Sets the current value of the crater condition in the percentage based on the current value of the welding condition.	✓
F70	Setting of upper limit of analog remote control	20 to 400 (*1) 20 to 550 (*2)	400 (A) 550 (A)	Sets the upper limit (the value when the knob is turned clockwise all the way) of the welding current adjustable by the analog remote control (optional accessory).	-
F71	Interval welding function	OFF/ON	OFF	This function repeats arc ON/OFF to control the heat input.	✓


No.	Function Name	Setting range	Initial value	Explanation	Memory
F72	Setting arc-ON time (Interval function)	0.20 to 9.99	1.00 (s)	Sets the arc-ON time in the Interval welding function.	√
F73	Setting arc-OFF time (Interval function)	0.20 to 9.99	1.00 (s)	Sets the arc-OFF time in the Interval welding	√
F74 to F76	No function	OFF (fixed)	OFF	No functions are provided.	-
F77	Welding source identification numbers	1 to 999	1	Sets whether power source identification numbers of Welding result control function.	-
F78	Prevention of unintended torch switch operation	OFF/ON	OFF	An error code is displayed when welding is not performed for five seconds after the pre-flow.	-
F79	Switching of CAN communication connection device	0/1/2/3	0	Sets the connection device to be used for the CAN communication. 0: Digital Remote Control Box 1: Digital panel (Attached to the wire feeder) and Intelli torch 2: Push-Pull torch 3: Inline assist feeder	-
F80	Switching of CAN communication speed	0/1/2/3	0	Sets the connection speed of the CAN connection. 0: 500 kbps 1: 1 Mbps 2: 125 kbps 3: 250 kbps	-
F81	TIG Mode switch setting	OFF/ON	OFF	During TIG MODE, operating the torch switch can control the welding start and end.	-
F82	No function	OFF (fixed)	OFF	No functions are provided.	-
F83	Arc length adjustment right after starting	-20 to 10	0	Adjusts the arc length right after starting the welding operation.	-
F84, F85	No function	OFF (fixed)	OFF	No functions are provided.	-
F86	Current display adjustment (GAIN)	-20 to 20	0 (%)	These functions are for adjusting current value	
F87	Current display adjustment (OFFSET)	-20 to 20	O (A)	displayed on the digital meter.	-
F88	Voltage display adjustment (GAIN)	-20 to 20	0 (%)	These functions are for adjusting voltage value	_
F89	Voltage display adjustment (OFFSET)	-2.0 to 2.0	0.0 (V)	displayed on the digital meter.	-

*1: WB-M352 *2: WB-M502

6.2 Function on Operation Panel

This section explains the function of displays and keys arranged on the operation panel.

6.2.1 Operation panel



No.	Name	Function
1	Left digital meter	Displays various information. The welding current is displayed in welding, and the LED of "A" lights up. In each setting, corresponding setting values are displayed, and the LED lit position automatically switches.
2	Right digital meter	Displays various information. The welding voltage is displayed in welding. In each setting, corresponding setting values are displayed, and the LED lit position automatically switches.
3	Parameter adjustment knob	Pressing this knob switches the digital meter (left/right) that needs to be set. Turning this knob changes the value of the selected parameter. Sets the welding current / wire feeder speed when the left digital meter is selected. Switching between welding current / wire feeder speed is enabled by pressing the UNIT CHANGE key. Sets the welding voltage when the right digital meter is selected. If the knob is turned faster, the amount of change will be 10 times larger.
4	UNIT CHANGE key	Switches between welding current / wire feeder speed when the left digital meter is selected. When the right digital meter is selected and when the SYNERGIC mode is selected as the welding voltage adjustment method, pressing this key switches the value displayed on the right digital meter between "fine adjustment value" and "actual voltage value". (In the SYNERGIC mode, the welding voltage appropriate for the welding current is regarded as ±0, based on which the welding voltage is finely adjusted.)
5	DISPLAY CHANGE key	Switches the welding sequence that need to be set. During the welding, the display can be switched to display the value set as the welding condition.
6	LCD panel	The LCD panel can be used to display the welding conditions that have been set, change the welding conditions, and make settings for other various types of menu. (5.3 Power ON and Gas Supply)
7	MENU key	Switches between the welding condition setting screens and the MENU screen.
8	CANCEL key	Cancels the operation of various settings and returns to the previous settings.


No.	Name	Function
9	Screen operation knob	Used for selecting the functions and changing the settings of the setting screens displayed on the LCD panel.
10	CONSTANT PENETRATION key	Activates the penetration control. (6.6.8 Penetration control adjustment) Press this key makes the LED lit, and automatically adjusts the wire feed speed so that the welding current becomes always constant even with the wire feeding length changed. This function is available only when the "MILD STEEL CORED", "MILD FLUX CORED", "STAINLESS STEEL SOLID" or "STAINLESS STEEL CORED" is selected by the WIRE MATERIALS menu.
11	ARC CONTROL key	Set the arc characteristics (soft to hard). (6.6.7 Arc characteristics adjustment) Pressing this key makes the LED lit, enabling to adjust the arc characteristics by the parameter adjustment knob. The arc characteristic in adjustment is displayed on the right digital meter.
12	WAVE FRQ key	Not used on this model.
13	EN ratio key	Not used on this model.
14	WIRE INCH key	Feeds the wire. (5.4 Wire Inching) The LED lights during when the key is pressing, allowing the wire to be fed. The feeding speed can be adjusted by the parameter adjustment knob. When the analog remote control (optional) is connected, the speed can be adjusted by the welding current setting knob.
15	GAS CHECK key	Discharges the shield gas. (5.3 Power ON and Gas Supply) Pressing this key makes the LED lit, allowing the shield gas to be discharged. After discharging the gas for approximately 2 minutes automatically stops the discharge. Pressing this key again lights off the LED, stopping the shield gas discharge.
16	TORCH key	Select air-cooled welding torch or water-cooled welding torch to be used. Switching the mode is enabled by pressing the key. When the LED is ON: water-cooled welding torch mode When the LED is OFF: air-cooled welding torch mode
17	Terminals for service use	Terminals for the OTC service use.
18	USB connector	For variety of registered data, writes to or reads from the USB memory. (© Chapter 7 Administrator Functions)

6.2.2 Setting screen

This section explains the functions of the setting screens displayed on the LCD panel as well as the basic operation methods.

6.2.2.1 Constructions and switching of setting screen

If the welding power source starts normally, the HOME screen will usually be displayed.



/ TIPS

 The setting of "Font Size" and "LCD Background" are available on the HOME screen. Refer to "7.7 System Setting".

6.2.2.2 Functions of setting screen

• HOME screen

Item	Functions
WELDING METHOD	 Select the type of welding method. Some welding method is invalid depending on the combination of the wire diameter, wire material, gas, and travel speed. The invalid welding method will not be displayed. (6.6.1 Welding mode setting) If other welding conditions are changed, and if combination of the changed welding conditions makes the currently set welding method invalid, the color of the WELDING METHOD parameter will become inverted on the LCD panel display, and "" will flash on the left/right digital meters.

Item	Functions
	Select the gas to use.
GAS	Some gas cannot be used depending on the combination of the wire material, wire diameter, welding method, and travel speed. The gas that cannot be used will not be displayed. (6.6.1 Welding mode setting)
	• If other welding conditions are changed, and if combination of the changed welding conditions makes the currently set welding method invalid, the color of the WELDING METHOD parameter will become inverted on the LCD panel display, and "" will flash on the left/right digital meters.
	Select the wire material to use.
WIRE MATERIALS	Some wire material cannot be used depending on the combination of the wire diameter, gas, welding method, and travel speed. The wire material that cannot be used will not be displayed.
	• If other welding conditions are changed, and if combination of the changed welding conditions makes the currently set wire diameter to become invalid, the color of the wire diameter parameter will become inverted on the LCD panel display, and "" will flash on the left/right digital meters.
	Select the wire diameter to use.
	Some wire diameter cannot be used depending on the combination of the wire material, gas, welding method, and
WIRE DIA. [in. (mm)]	travel speed. The wire diameter that cannot be used will not be displayed. (6.6.1 Welding mode setting)
	 If other welding conditions are changed, and if combination of the changed welding conditions makes the currently set wire diameter to become invalid, the color of the wire diameter parameter will become inverted on the LCD panel display, and "" will flash on the left/right digital meters.
	Select the travel speed to apply.
TRAVEL SPEED	Some option is invalid depending on the combination of the wire diameter, wire material, gas, and welding method.
	The invalid option will not be displayed. (6.6.1 Welding mode setting)
	Select the crater treatment method or arc spot at the end of welding.
CRATER-FILL	For details of the crater treatment (6.6.4 Crater setting)
	For details of arc spot (6.6.5 Arc spot time)
SPOT TIME	Sets the arc spot time.
SI OT TIME	This item is displayed when "ARC SPOT" is selected by the CRATER-FILL menu. (6.6.5 Arc spot time)
	When "CRATER-FILL ON" is selected by the CRATER-FILL menu, the sequence of initial condition is added before the
INITIAL CONDITION	welding. (6.6.4 Crater setting) Pressing the screen operation knob makes the turning ON/OFF.
	Sets welding voltage. Switching the mode is enabled. Switching the mode is enabled by pressing the screen operation knob.
VOLT. ADJUST	SYNERGIC: SYNERGIC mode. (The welding voltage is automatically set according to the set welding current. To fine-tune welding voltage, adjust the synergic fine adjustment knob.)
	INDIVIDUAL: INDIVIDUAL mode. (In the individual adjustment setting, welding current and welding voltage are adjusted respectively.)
WELDING GUIDE	By setting the "WELD JOINT" and "PLATE THICKNESS", the welding current will be set automatically according to each
	parameter. (6.6.9 Welding guide)

• MENU screen

Item	Functions		
FUNCTIONS	Sets the internal function of welding power source. (6.7 Setting Internal Functions)		
LOAD JOB	Reads the registered welding condition from the internal memory. (6.5 Memory Function of Welding Conditions)		
SAVE JOB	Registers the set welding condition in the internal memory. (6.5 Memory Function of Welding Conditions)		
WELD MONITOR	Sets welding control function. (Chapter 7 Administrator Functions))		
KEY LOCK	Switches between KEY LOCK ON/OFF. (7.1.2 Disabling erroneous operation prevention)		
BACKUP	Backs up the data such as welding conditions in USB flash drive. (7.3.5 Backup operation)		
RESTORE	Imports the backed-up data to this welding power source. (7.3.6 Importing backup data)		
PRODUCT INFO	Displays the information on the software and serial number of this welding power source. (7.5 Checking the Software Version and Serial Number)		
SYSTEM SETTING	Sets the "Font Size" of the HOME screen, the "LCD Background" and the language of all screens.		

6.3 Welding Conditions

This section explains basic welding conditions with useful functions.

6.3.1 Basic welding conditions

This section explains the basic welding conditions. To carry out the welding operation, the followings should be considered:

- Plate thickness and materials of welding material
- · Type and flow rate of shield gas
- Wire type and wire diameter, and welding method (type of welding)
- · Welding current and welding voltage


6.3.2 Useful functions

This section explains the useful functions for the welding power source.

- Registration of welding conditions (\$\sigma\$ 6.5 Memory Function of Welding Conditions)
 Using the memory function of the welding condition enables to register the welding current/voltage, shield gas type, and wire type/wire diameter currently set, and reads them out for use.
- Synergic adjustment of voltage (\$\sigma\$ 6.2 Function on Operation Panel)
 Using the VOLT. ADJUST menu enables to automatically set the welding voltage according to the welding current.
 Fine adjustment of the welding voltage automatically set is also available.
- Penetration control (\$\sigma\$ 6.6.8 Penetration control adjustment)
 Using the penetration control function can automatically adjust the wire feed speed so that the constant welding current is always kept even with the wire feeding length changes. (Available only for MILD STEEL SOLID, MILD STEEL CORED, STAINLESS STEEL SOLID or STAINLESS STEEL CORED)
- Welding current adjustment by torch switch (\$\sigma\$ 6.7 Setting Internal Functions)
 Using the internal function (F48) enables to increase or decrease the welding current set by the torch switch operation.
 (Available only with the CRATER-FILL ON is selected and with welding condition)

6.4 Preparing Welding Conditions

This section explains the setting process of basic welding conditions.



6.5 Memory Function of Welding Conditions

This section explains the memory function of welding conditions.

The welding power source is equipped with the function to register the welding conditions and reads them out for use. The number of welding conditions that are able to be registered are 100 at maximum. Single welding condition can contain the following information at registration:

- Welding mode selected by the keys on operation panel (Shield gas/Wire/Crater/Penetration control, etc.)
- Welding current/voltage for each welding sequence (\$\sigma\$ 6.6.3 Setting welding parameter)
- Part of internal function (\$\sigma\$ 6.1.3 Internal function)

CAUTION

- The welding conditions (electronic data) stored by this function are susceptible to
 occurrence of static electricity, impact, repair, etc., and there is a possibility that the stored
 contents may be changed or lost. BE SURE TO MAKE A COPY FOR IMPORTANT DATA.
- Please note that OTC will not be liable for any alteration or loss of electronic information.
- The memory function of welding condition is not available if the welding method is "DC TIG" or "DC STICK".

/ NOTE

When the analog remote control (optional) is connected to the machine, even if the stored welding
condition is read, the set values of the analog remote control apply to the welding current and welding
voltage of welding condition.

/ TIPS

- Use of the internal function (F44) enables to read out the registered welding condition by the analog remote control (optional). (67 Setting Internal Functions)
- Use of the internal function (F11) enables to finely adjust the current/voltage values read out from the memory by the analog remote control (optional). (6.7 Setting Internal Functions)


6.5.1 Memory registration of welding conditions

This section explains how to register the current welding condition set on the operation panel to the memory.




- 1. Display "SAVE JOB" in the MENU screen.
 - Turn the screen operation knob and point the cursor to SAVE JOB.
 - Press the screen operation knob.
 - ⇒ The JOB No. (registration No.) is displayed on the right digital meter in a flashing mode, and the LED of JOB lights up.
 - ⇒ On the left digital meter, the setting value of the welding current registered to the JOB No. if any is displayed (if there is no registration, "- - " is displayed), and the "A" LED lights up.
 - ⇒ If the welding condition corresponding to the selected JOB No. is not registered, "no data" is displayed on the LCD panel, and "---" will flash on the left digital meter.






2. Turn the screen operation knob (or parameter adjustment knob), and select a JOB No.

- ⇒ When there is no registration data on the selected JOB No, "no data" is displayed on the LCD panel, and "---" is displayed on the left digital meter.
- ⇒ When there is a registration data on the selected JOB No., the set welding current value is displayed on the left digital meter.



3. Press the screen operation knob.

- \Rightarrow "- - -" is displayed on the left and right digital meters in a flashing mode.
- To cancel the memory registration, press the CANCEL key. The "SAVE JOB" mode is terminated.



4. Press the screen operation knob.

 \Rightarrow The welding condition is registered with the selected JOB No., and the storage function mode is terminated. The registered welding condition can be read out for use.

6.5.2 Read out of welding conditions

This section explains how to read out the welding conditions registered in the memory.

/ TIPS

• The current welding condition set on the operation panel is overwritten by the welding conditions read out. To save the current welding condition, ensure to register it to the memory.

STEP

1. Display "LOAD JOB" in the MENU screen.

- Turn the screen operation knob and point the cursor to LOAD JOB.
- Press the screen operation knob.
- ⇒ The JOB No. (registration No.) is displayed on the right digital meter in a flashing mode, and the LED of JOB lights up.
- ⇒ On the left digital meter, the setting value of the welding current registered to the JOB No. if any is displayed (if there is no registration, "- - " is displayed), and the "A" LED lights up.
- ⇒ If the welding condition corresponding to the selected JOB No. is not registered, "no data" is displayed on the LCD panel, and "---" will flash on the left digital meter.




2. Turn the screen operation knob (or parameter adjustment knob), and select the JOB No. to read out.

- ⇒ When there is no registration data on the selected JOB No., "no data" is displayed on the LCD panel and "----" is displayed on the left digital meter.
- ⇒ When there is any registration data on the selected JOB No., the setting value of the welding current is displayed on the left digital meter. At this time, the setting values of crater or wire material also display on the LCD panel.



3. Press the screen operation knob.

- ⇒ The setting values are displayed on the left/right digital meters in a flashing mode.
- ⇒ Pressing the DISPLAY CHANGE key enables to check the set values of welding conditions (welding parameters) to read out. The setting values are displayed on the left/right digital meters in a flashing mode.
- To change the JOB No. to read out, pressing the CANCEL key to return to the status described in step 1.



4. Press the screen operation knob.

- \Rightarrow The welding condition is registered with the selected JOB No., and the read mode is terminated.
- ⇒ The selected position on the operation panel and the current/voltage values are overwritten to those read out.

6.5.3 Deletion of memory registration


This section explains how to delete the welding conditions registered to the memory.

/ NOTE

 The deleted data cannot be restored. Before deleting the stored welding condition, carefully check the welding JOB No. to delete.

STEP


- 1. Turn OFF the power switch.
- 2. With the two DISPLAY CHANGE keys depressed together, turn ON the power switch.
 - Depress these two keys until USER MENU is displayed on the LCD panel. Release the keys after USER MENU is displayed.



3. Select "Delete JOB".

- Turn the screen operation knob and point the cursor to Delete JOB.
- Press the screen operation knob.
- ⇒ "dEL" is displayed when the system transits to the DELETE mode.
- ⇒ The JOB No. (registration No.) is displayed on the right digital meter in a flashing mode, and the LED of JOB lights up.






4. Turn the screen operation knob (or parameter adjustment knob), and select the JOB No. to delete.


 To delete all the registration at the same time, turn the parameter adjustment knob counterclockwise, to display "ALL" on the right digital meter.

When "ALL" is selected, the current welding condition set on the operation panel is also deleted, and the welding parameters including the internal functions return to the initial values.




5. Press the screen operation knob.

- ⇒ The display "dEL" on the left digital meter starts flashing.
- To cancel the deletion, turn off the power switch.



6. Press the screen operation knob.

⇒ The welding condition of the selected JOB No. is deleted, and "End" is displayed on the left/right digital meters.



7. Check that "End" is displayed on the left/right digital meters and turn off the power switch.

 \Rightarrow The power LED switch lights off. The status returns to normal when the power switch is turned on.

6.6 Setting Welding Conditions

This section explains how to set the welding conditions (welding mode or welding parameters).

6.6.1 Welding mode setting

Depending on the type of shield gas, wire material, etc., there are modes that can be combined and modes that cannot be combined.

Available combination of the welding mode is listed in the table below.

WELDING METHOD	GAS (*1)	WIRE MATERIALS	WIRE DIA. [in. (mm)]		TRAVEL SPEED	Penetration
			WB-M352	WB-M502	TRAVEL SPEED	adjustment
DC	CO ₂	MILD STEEL	.030 / .035 / .040 / .045 (0.8/0.9/1.0/1.2)	.035/.040/.045/.052/1/16 (0.9/1.0/1.2/1.4/1.6)	STANDARD (*2)/HIGH	Enable
	MAG (20% CO ₂)	MILD STEEL	.030 / .035 / .040 / .045 (0.8/0.9/1.0/1.2)	.035/.040/.045/.052/1/16 (0.9/1.0/1.2/1.4/1.6)	STANDARD (*2)/HIGH	Enable
		MILD STEEL CORED	.045 / .052 (1.2/1.4)	.045 / .052 / 1/16 (1.2/1.4/1.6)	STANDARD (*2)	Enable
		METAL CORED	.045/.052 (1.2/1.4)	.045 / .052 / 1/16 (1.2/1.4/1.6)	STANDARD (*2)	Enable
		STAINLESS CORED	.045 (1.2)	.045 / 1/16 (1.2/1.6)	STANDARD (*2)	Enable
	MIG (2% O ₂)	STAINLESS STEEL	.030 / .035 / .040 / .045 (0.8/0.9/1.0/1.2)	.040 / .045 / 1/16 (1.0/1.2/1.6)	STANDARD (*2)/HIGH	Enable
		STAINLESS FERRITE	.030 / .035 / .040 / .045 (0.8/0.9/1.0/1.2)	.045 (1.2)	STANDARD (*2)/HIGH	Enable
	MIG (100% Ar)	SOFT ALUMINUM	.045 / 1/16 (1.2/1.6)	.045 / 1/16 (1.2/1.6)	STANDARD (*2)/HIGH	-
		HARD ALUMINUM	.045 / 1/16 (1.2/1.6)	.045 / 1/16 (1.2/1.6)	STANDARD (*2)/HIGH	-
DC TIG	-	-	-	-	-	-
DC STICK	-	-	-	-	-	-

^{*1:} Note that the "collective" voltage adjustment may not meet the appropriate condition if a mixing gas other than those with the following mixing ratios is used.

MAG gas: Argon (Ar) 80 % + Carbon dioxide (CO₂) 20 %

MIG gas: Argon (Ar) 98 % + Oxygen (O_{\circ}) 2 %

MIG gas: Argon (Ar) 100%

(6.7.2.1 F1: Standard/Extended cable mode)


6.6.2 Setting welding conditions

Set the welding conditions with HOME screen and screen operation knob.



1. Select "WELDING METHOD" on the HOME screen.

- Turn the screen operation knob and point the cursor to the WELDING METHOD (e.g. DC).
- Press the screen operation knob.
- ⇒ The setting screen of welding conditions of WELDING METHOD will be displayed.



^{*2:} For "STANDARD" mode, the standard mode or extended cable mode (extended mode of power cable) is available.

2. Select "WELDING METHOD" to be changed.

- Turn the screen operation knob and point the cursor to the changing item.
- Press the screen operation knob.
- ⇒ Change of the welding method is confirmed, and the screen returns to the HOME screen.



- 3. For other parameters (gas, wire material, wire diameter, travel speed, crater, initial condition, volt. adjust), display the setting screens of the respective welding conditions, select the options, and set the values.
- 4. Press the CONSTANT PENETRATION key and select ON or OFF for the constant penetration.
 - ⇒ LED ON: the penetration control is valid. LED OFF: the penetration control is invalid
 - ⇒ Details of the penetration control (☞ 6.6.8 Penetration control adjustment)




6.6.3 Setting welding parameter

This section explains how to set the welding parameter (gas discharge time, welding current/voltage). The welding parameters are set according to the welding sequence.

6.6.3.1 Welding sequence

The basic welding sequence is the process of PRE FLOW, MAIN CONDITION, and POST FLOW. To this sequence, initial condition and crater-fill condition can be added depending on the crater setting. The welding parameters such as gas discharge time, welding current and voltage should be set to this sequence.




Each sequence process has the following description:

Process	Description
PRE FLOW	It is the sequence to discharge gas before the welding starts.
INITIAL CONDITION	It is the sequence to process the welding start.
MAIN CONDITION	It is the welding sequence.
CRATER -FILL CONDITION	It is the sequence to process the crater part.
POST FLOW	It is the sequence to discharge gas after the welding completes.

6.6.3.2 Welding parameter setting

This section explains how to set the welding parameters (gas discharge time, welding current/voltage) according to the welding sequence.



STEP

1. Set the gas discharge time.

- Press the DISPLAY CHANGE key, and select the LED of "PRE FLOW" (or "POST FLOW").
- Turn the parameter adjustment knob to set the gas discharge time.
- \Rightarrow The set parameter is displayed on the left digital meter.

2. Set the welding current.

- Press the DISPLAY CHANGE key, and select the LED of "MAIN CONDITION" (or "INITIAL CONDITION" or "CRATER-FILL CONDITION").
- When the LED above the 7-segment display (for current adjustment) is off, press the parameter adjustment knob to light up the LED.
 (The welding current can also be set based on the wire feed speed. In this case, refer to "6.7.2.19 E24: Wire feeding."
 - (The welding current can also be set based on the wire feed speed. In this case, refer to "6.7.2.19 F24: Wire feeding speed setting")
- Turn the parameter adjustment knob to set the welding current.
- ⇒ The set parameter is displayed on the left digital meter.

/ TIPS

In the setting of welding current, the wire feed speed automatically set according to the
welding current can be checked. Press the UNIT CHANGE key to light off the LED ("IPM":
On, "A": Off), and the value displayed on the left digital meter switches to the display of
wire feed speed. Pressing the UNIT CHANGE key again to light on ("IPM": Off) returns the
display to the one of welding current.

3. Set the welding voltage.

- When the LED above the 7-segment display (for voltage adjustment) is off, press the parameter adjustment knob to light up the LED.
- Turn the parameter adjustment knob to set the welding voltage.
 At SYNERGIC mode: fine adjustment is carried out based on the welding voltage automatically set according to the welding current.
 At INDIVIDUAL mode: voltage setting is made in regardless of the welding current.
- ⇒ The set value is displayed on the right digital meter.

/ TIPS

- Switch the mode by the VOLT. ADJUST menu. (6.6.6 Welding voltage adjustment)
- The mode set by the VOLT. ADJUST menu is applied all of the conditions (INITIAL CONDITION/ MAIN CONDITION/CRATER-FILL CONDITION).
- 4. Register to the memory as necessary. (6.5 Memory Function of Welding Conditions)

6.6.4 Crater setting

This section explains the details of crater treatment and torch switch operation.

There are modes listed below for the crater setting. For initialization conditions, select availability by the INITIAL CONDITION menu.

Mode	Initial condition	Description	
CRATER-FILL OFF	-	In the welding process, only available process is the main welding. (© 6.6.4.1 Crater "OFF")	
	Unavailable	After the main welding, the welding process on the "Crater" condition available.	
CRATER-FILL ON	onavanasio	(6.6.4.2 Crater "ON" (no initial condition))	
ON TENTILE ON	Available	Adding to the above, the welding process is available by the initial condition before the	
		main welding. (6.6.4.4 Crater (Repeated))	
	Unavailable	After the main welding, the welding process on the "Crater" condition is available.	
		Furthermore, even after the CRATER phases, turning ON the torch switch within 2 seconds	
CRATER-FILL ON (Repeat)		enables to carry out the welding process on the "Crater" condition again. (\$\overline{\Pi}\$ 6.6.4.2 Crater "ON" (no initial condition))	
(**************************************		Adding to the above, the welding process is available by the initial condition before the	
	Available	main welding. (6.6.4.4 Crater (Repeated))	
ARC SPOT	-	The welding process by the arc spot is available. © 6.6.5 Arc spot time)	


/ TIPS

• Even in the Crater-fill off mode, using the internal function (F45) enables to carry out the welding process in the initial condition before the main welding, and the welding process in the Crater condition after the main welding. (6.7.2.28 F45/F46/F47: Special crater sequence (effective/initial standard time setting/crater standard time setting))

6.6.4.1 Crater "OFF"

Select "CRATER OFF" by the CRATER-FILL menu.


• In synchronous to the ON/OFF operation of the torch switch, the welding starts/stops.



6.6.4.2 Crater "ON" (no initial condition)

Select "CRATER-FILL ON" by the CRATER-FILL menu and select "INITIAL CONDITION OFF" by the INITIAL CONDITION menu.


- Carry out twice the ON/OFF operation of the torch switch and carry out the welding operation. In the second ON
 operation, the welding sequence is carried out by the crater current.
- Even if the torch switch is switched off during welding, the signal will be self-hold. (The torch switch should remain depressed and held during the CRATER phrases.)



6.6.4.3 Crater "ON" (with initial condition)

Select "CRATER-FILL ON" by the CRATER-FILL menu and select "INITIAL CONDITION ON" by the INITIAL CONDITION menu.


- Carry out twice the ON/OFF operation of the torch switch and carry out the welding operation. The operation from the first ON to OFF enables the welding by the initial current, and the second ON operation enables the welding by the crater current.
- Even if the torch switch is switched off during welding, the signal will be self-hold. (The torch switch should remain depressed and held during the INITIAL and CRATER phrases.)
- Welding method in the initial condition is the same with the main welding.



6.6.4.4 Crater (Repeated)

Select "CRATER-FILL ON (Repeat)" by the CRATER FILL menu.


- The torch switch operation until the crater treatment is the same with the welding of "CRATER-FILL ON". (\$\infty\$ 6.6.4.2 Crater "ON" (no initial condition))
- In the crater treatment, if the torch switch is turned on again within 2 seconds, the machine starts on the "Crater" condition and continues operation. Repeating this allows crater process to be carried out as many times as needed.



6.6.5 Arc spot time

This section explains the details of arc spot and torch switch operation. Selecting "ARC SPOT" by the CRATER-FILL menu allows the machine in the main mode.

- In this mode, the torch switch remains to be ON for welding operation. When the arc spot time elapses, the welding automatically stops.
- The arc spot time is displayed on the left digital meter when pressing the SPOT TIME menu, and is adjustable by the parameter adjustment knob.
- Turning OFF the torch switch before reaching the arc spot time starts the anti-stick treatment from then.



/ TIPS

• In carrying out the arc spot welding, purchase the nozzle especially for arc spot (optionally available). For details on the nozzle for arc spot, see the instruction manual of the torch.

6.6.6 Welding voltage adjustment

This section explains how to adjust the welding voltage. The adjustment of welding voltage can be carried out either by the SYNERGIC mode or INDIVIDUAL mode.

/ TIPS

- Some conditions such as synergic condition does not meet the appropriate level if a mixing gas ratio
 of shield gas is not the specified value. (6.6.1 Welding mode setting)
- Even when the base material side/torch side cable or torch cable is extended, adjust to a higher voltage setting beforehand in consideration of voltage decrease.
- The voltage displayed during the setting or welding is the voltage of output terminal (base metal side) between the wire feeder and welding power supply.



■ SYNERGIC mode

Press the VOLT. ADJUST menu. When the SYNERGIC is selected, it means the SYNERGIC mode is applied.

- · The welding voltage is automatically set to the values corresponding to the welding current.
- The voltage value automatically set can be finely adjusted by the parameter adjustment knob. (Welding voltage on the
 positive side: high, negative side: low.)

■ INDIVIDUAL mode

 $Press\ the\ VOLT.\ ADJUST\ menu.\ When\ the\ INDIVIDUAL\ is\ selected,\ it\ means\ the\ INDIVIDUAL\ mode\ is\ applied.$

• The welding voltage can be adjusted by the parameter adjustment knob.

6.6.7 Arc characteristics adjustment

This section explains the adjustment procedure of arc characteristics (arc status). Using this function enables to adjust the arc status into soft or hard condition.

Press the ARC CONTROL key. When the LED of the key is ON, it means the arc control is ON.

The setting value is displayed on the right digital meter, and can be adjusted by the parameter adjustment knob. (Positive value: soft arc condition, negative value: hard arc condition)

/ TIPS

- It is likely that good weld can be obtained by adjusting it to "hard" in low current region and "soft" in high current region.
- When using an extended cable for the base material side / torch side or using an extended torch cable, it is likely that good welding can be performed by adjusting it to "hard."

6.6.8 Penetration control adjustment

This section explains how to adjust the penetration control. Using the constant penetration function enables to automatically adjust the wire feed speed so that the constant welding current can be assured even when the wire feeding length changes.

Press the CONSTANT PENETRATION key. When the LED of the key is ON, it means the penetration control is ON. This results in reduction of changes in penetration depth and bead width of the base material. Especially for welding where you desire to make penetration depth constant, use the welding power source with this penetration control function enabled.



/ TIPS

- The penetration control function is available when "MILD STEEL SOLID", "MILD STEEL CORED",
 "STAINLESS STEEL SOLID" or "STAINLESS STEEL CORED" is selected by the WIRE MATERIALS menu.
- The penetration control functions only during the production weld while it does not during the initial and crater processes. Also, the function cannot be used in arc spot.

6.6.9 Welding guide


By setting the "WELD JOINT" and "PLATE THICKNESS", the welding current will be set automatically according to each parameter.



- Select "WELDING GUIDE" on the HOME screen.
 - Turn the screen operation knob and point the cursor to WELDING GUIDE, then press the screen operation knob.
 - ⇒ WELDING GUIDE screen is displayed.




- 2. Turn the screen operation knob and select "WELD JOINT", then press the screen operation knob.
 - ⇒ The color of the selected parameter will be inverted on the display.




3. Select the weld joint that needs to be changed.

- Turn the screen operation knob to place the cursor on the parameter that needs to be set, and press the knob.
- ⇒ Change of the weld joint is confirmed, and the screen returns to the WELDING GUIDE screen.
- To cancel the setting, press the CANCEL key.




4. Turn the screen operation knob to select the plate thickness value, and press the knob.

- \Rightarrow \triangle and ∇ will be displayed above and below the plate thickness value, and the value becomes adjustable.
- ⇒ Welding current will be set automatically according to the WELD JOINT and plate thickness.
- ⇒ The welding current is displayed on the left digital meter.



5. Turn the screen operation knob to adjust the plate thickness, and press the knob.

- \Rightarrow **\(\Lambda \)** and **\(\Vec{\Vec{\Vec{V}}} \)** displayed above and below the plate thickness value, will disappear.
- ⇒ The plate thickness setting is confirmed, and the screen returns to the WELDING GUIDE screen.



6. Press the MENU key or CANCEL key.

 \Rightarrow It returns to HOME screen.

/ TIPS

- · There is an upper and lower limit for the plate thickness that can be set.
- The WELDING GUIDE function cannot be used depending on the combination of welding conditions.
- The WELDING GUIDE function cannot be used when an analog remote control (optional accessory) is connected.

6.7 Setting Internal Functions

This section explains how to set the internal functions with the details.

The internal functions can be customized according to the using environment of the customer for further convenient use of the welding power source.

6.7.1 Setting procedure

This section explains how to set the internal functions.


Details of internal function (67.2 Detailed information on internal functions)

/ TIPS


The internal function is activated at the point when the setting value is changed. To change the set
values of internal functions, ensure that there is no mistake in the function No. as well as in the
function setting.

STEP

- 1. Display "FUNCTIONS" in the MENU screen.
 - Turn the screen operation knob and point the cursor to FUNCTIONS.
 - Press the screen operation knob.
 - ⇒ The contents of the previously displayed function No. will be displayed on the LCD panel.
 - ⇒ The function No. is displayed on the left digital meter in a flashing mode.
 - ⇒ The setting value of each function No. is displayed on the right digital meter.
- 2. Turn the screen operation knob, to display the function No. to set.




- 3. Press the screen operation knob.
 - \Rightarrow The display on the right digital meter changes to a flashing mode.



4. Turn the parameter adjustment knob, and change the setting value.

 \Rightarrow The set value is activated as it is changed.



5. Press the CANCEL key.

⇒ The setting of internal function completes, and the LCD display returns to the MENU screen.

6.7.2 Detailed information on internal functions

This section explains the detailed information of internal functions in the order of function No.

6.7.2.1 F1: Standard/Extended cable mode

Sets the welding control status for extended cables for the application of STANDARD mode. This function is available when travel speed is set to "STANDARD" and WELDING METHOD is set to "DC".

Extending the cables at the base metal side/torch side or power cables such as torch cables can cause extraordinary volume of spatter. When this happens, turning this function ON (extended cable mode) can improve the status.

- "ON": Extended cable mode
 Set to "ON" for the length of extension cable longer than 99 ft (30 m). The LED of STANDARD starts flashing when setting to "ON".
- "OFF": Standard mode

<u>/ TIPS</u>

- In using the welding power source in the "HIGH" mode, the setting of this function is set to "OFF" and cannot be changed.
- When the status is not improved even by setting of this function to "ON", combined use of the voltage detection cable is recommended.

When using the voltage detection cable, set the internal function F38 (Arc voltage direct detection switching) to "1". (6.7.2.23 F38: Arc voltage direct detection switching)

6.7.2.2 F2: Switching functions with remote control

Sets the functions to be allocated to the switching knob of the analog remote control.

The selectable functions are "1" through "6" as shown in the below table. No function will

The selectable functions are "1" through "6" as shown in the below table. No function will be allocated if set at "0".

Setting	Function	
0	No function	
1	Crater setting (6.6.4 Crater setting)	
2	Gas check (5.3 Power ON and Gas Supply)	
3	Constant penetration (6.6.8 Penetration control adjustment)	
4	Tack start (6.7.2.35 F54 Tack start process)	
Reading welding conditions with remote control 6.7.2.27 F44: Reading welding conditions with remote control)		
6	No function	

6.7.2.3 F4: Auto/Semi-auto mode

In combining the welding power source with a robot or an automatic machine, set I/O (interface) of the welding source according to the application.

For the settings "0" to "2", refer to the table below. The settings "3" and "4" are the modes specifically for the use with OTC robots. For details, refer to the instruction manual of the robot controller.

Parameter	Setting			
Falailletei	0 (Semi-automatic)	1 (Automatic machine 1)	2 (Automatic machine 2)	
Cancellation of operation stop	After short-circuiting the pins [3]- [4] operation stop terminals on the external connection terminal block TM3, and turn the power on again. (*4)	Short-circuit the operation stop terminal pins [3]-[4] on the externation terminal block TM3 (*4)		
Stuck wire removal voltage (*1)	Voltage is not output.	Voltage is output for approx. 0.2 se process.	conds after completion of anti-stick	
Welding current/voltage setting	Set by operation panel or remote control.	Set by external command voltage(*2)	Set by operation panel or remote control.	
Inching	Operation by operation panel or remote control.	Set on the operation panel or short-circuit the pins [1]-[5]- analog remote control receptacle (CON2).		
Retract function (*3)	Disabled	bled Enabled		
Error reset After removing the cause of error, the power is restored.		After removing the cause of error, the power is restored. Or open/short-circuit the deactivated terminal pins [3]-[4] of the external connection terminal block TM3. (*4)		


^{*1:} In the "Auto" mode, voltage to release welding is output for approx. 0.2 seconds after the anti-stick process. This voltage is output even if the wire is not welded.

Relationship between input and output is as the charts provided in "F5: Maximum external command voltage ". (6.7.2.4 F5: Maximum external command voltage)

Ensure that the command voltage is input at least 100 ms before the start signal is input. Use the external power source with current capacity of 0.5 mA or more.

A CAUTION

Supply 0V to 15 V to E1 and E2.
 Exceeding 15 V may result in damage to the control circuit of the welding power source.



- *3: In the "Auto" mode, "3" (Retract) can be allocated to the functions of external input terminals of F29 F32. For more information on the retract function, refer to 6.7.2.22 F29 to F32: External input terminal setting)
- *4 : For the details of external connection terminal block; ($^{\textcircled{3}}$ 4.5.2 Connection of automatic machine)
- *5: For the applicable plug of analog remote control receptacles: See specification DPC25-6A-1H-Z/Part No. 4730-009.


^{*2:} If an external command voltage is input, it should be input to the terminal pins ([1]-[3], [1]-[4]) of the remote control receptacle as shown in the below figure.


When the internal function F4 (Auto/Semi-auto mode) is used with the setting of "1", set the maximum value of command voltage input from outside.

Select either from 10 V, 14 V, or 15 V.


The below charts show the relationship between current/voltage command voltage and welding current/voltage. (Use these charts as a rough indication. Welding current/voltage against the welding conditions setting voltage may differ from the indications on the charts depending on the external input (command voltage), wire length or routing of the cable at base material side/torch side.)


WB-M352





WB-M502





6.7.2.5 F6: Upslope time

When the difference between the initial current and welding current is large, the wire may burn up at the change of the conditions. In this case, adjust the time period changing from the initial current to the welding current (upslope time) longer.

• Setting range of upslope time: 0.0 to 10.0 [sec]

6.7.2.6 F7: Downslope time

When the difference between the welding current and crater current is large, the wire may plunge into weld pool at the change of the conditions (the wire is fed by inertia because the speed reduction is too late). In this case, adjust the time period changing from the welding current to the crater current (downslope time) longer.

• Setting range of downslope time: 0.0 to 10.0 [sec]

6.7.2.7 F8: Welding result display time

Set the time period for the output current and voltage to be displayed on the left/right digital meters in a flashing mode after the completion of welding. Set the display time in the flashing mode.

The value of display time is the average value for 1 second immediately before the completion of welding.

• Setting range of welding result display time: 0 to 60 [sec]

6.7.2.8 F9: Analog remote control scale

Change the setting of the scale plate of analog remote control when using the optional analog remote control.

Rated output current of welding power source	Applicable scale and scale plate
350 A	350/200
500 A	500/350/200

- Scale plate is available separately for 500 A, 350 A, and 200 A. According to the selected scale of analog remote control, replace the scale plate as necessary. (6.8 Operation of Analog Remote Control (Optional))
- When using the remote control in a low current region, set the scale plate to 200A.

6.7.2.9 F10: Motor overcurrent detection level

Set the over current detection level for the current flowing to the wire feed motor.

If contact resistance of the wire feeding line section increases due to liner wear / tip defect, etc., motor current increases (when the feeding roller does not slip). Monitoring this motor current enables to identify faults of the feeding line.

Set the detection level in the range of 20 to 150 % of the motor rated current.


- The factory default setting is 70 % of 2.8 A (continuous).
 If the current flows to the motor exceed the set value, the alarm display of "E-820" is displayed; output of the welding power source is not stopped.
- According to the use environment such as wires and torches and the customer's judgment criteria, adjust the detection level at your discretion.

6.7.2.10 F11: Fine adjustment of welding conditions memory

When the analog remote control (optionally available) is used, fine adjustment of the welding current and welding voltage of welding condition stored on the welding condition memory is available. This function is effective when the internal function F4 (Auto/Semi-auto mode) is set to "0".

- [OFF]: disables the function.
- [1] to [30]: enables the function. Turning the welding current adjustment knob on the analog remote control enables to fine adjust the current, and turning the voltage knob enables to fine adjust the voltage.
 - Setting range: 1 to 30 %
 - Turning both of the current and voltage knobs to the center of scales sets the welding conditions to those stored
 on the welding condition memory. Adjust the current/voltage with the standard of the center of scales. To
 increase the welding current or voltage, turn the knob counterclockwise and to reduce the welding current or
 voltage, turn the knob clockwise.

Place these knobs in the center positions.



- In the following cases, this function cannot be used:
 - Welding conditions are not registered to the memory;
 - Analog remote control (optional) is not connected to the welding power source;
 - Internal function F44 (Reading welding condition with remote control) is set to "ON" (enabled);
 - Internal function F45 (Special crater sequence) is set to "ON" (enabled);
 - Internal function F48 (Adjusting current with torch switch) is set to "ON" (enabled); or
 - Internal function F51 (Special crater repeat) is set to "ON" (enabled); or
 - Either of the internal functions F29 to F32 (External input terminal setting) is set to either "4" (Start) or "5" (Loading welding condition).
 - Internal function F4 (Auto/Semi-auto mode) is set to a value other than "0" (Semi-auto mode).

6.7.2.11 F13: Turbo start

The welding power source has the turbo start function using capacitor discharge in order to obtain smooth welding start.

- [ON]: enables the function.
- [OFF]: disables the function.



 If wire burning is too strong at the welding start, set this function to [OFF] to disable the turbo start function (disables the function).

6.7.2.12 F14/F15: Start control (time/current) adjustment


Set the time and current for start control to be performed at the time of welding start.

Depending on the welding conditions and set current value, the appropriate time and current for start control are determined; if proper burning of the wire does not occur at the time of start, adjust the time and current for start control.

For more intense burning, increase the time and current.

For less intense burning, reduce the time and current.

- Set the time from -50 to 50 % through F14 (Start control time adjustment).
- Set the current in the range from -100 to 100 A through F15 (Start control current adjustment).



6.7.2.13 F16: Slowdown speed adjustment

Slow-down speed is the speed to slowly feed the wire from the time of the machine start to the time of arc start. The slowdown speed is automatically set to an appropriate speed depending on the welding method and wire diameter; meanwhile, it can be adjusted through this function if manual setting is preferred.

The setting range is ± 39 IPM (± 1.0 m/min), yet cannot be adjusted slower than ± 16 IPM (0.4 m/min). Based on "0," adjusting it to the negative direction lowers the speed, and adjusting it to the positive direction accelerates the speed.

When the starting performance is poor, decrease the slow-down speed to a negative value (which lowers the wire feed speed).

When the starting performance is not poor, setting the slow-down speed to a positive value (which accelerates the wire feed speed) can shorten the tact time.

6.7.2.14 F17/F18: Anti-stick time/voltage adjustment

Set the anti-stick time/voltage, which is the anti-stick processing time and voltage. Optimum setting of the anti-stick time/voltage enables to obtain the following effects:

- At the welding completion, wire adhesion to the base material can be prevented.
- The shape of wire tip can be arranged to obtain a stable start of the next welding.

The time and voltage for anti-stick process are automatically set to appropriate conditions depending on the welding method (wire type) and wire diameter; meanwhile, it can be adjusted through this function if wire should cause adhesion at the end of welding or if burning is too intense.

- Adjust the anti-stick process time in the range of ±50 (unit: 0.01 seconds) through the internal function F17. Based on "0," adjusting it to the negative direction shortens the time, and adjusting it to the positive extends the time.
- Adjust the anti-stick process voltage in the range of ± 9.9 V through the internal function F18. Based on "0," adjusting it to the negative values decreases the voltage, and adjusting it to the positive increases the voltage.

6.7.2.15 F19: Switching alarm setting

When alarm occurs, the output of welding power source can be stopped.

Yet for some alarm codes, it is possible to continue welding even if the alarm level is detected, which may sometimes cause the alarm display to be ignored. Using the alarm setting switch function ensures to stop the output from the welding power source.

- [ON]: any alarm detection stops the output of welding power source.
- [OFF]: alarm detection does not stop the output of welding power source.

Means to reset alarms is the same as those for errors, including restoration of the power. (9.1 Action in Case of Error)

6.7.2.16 F20: Low input voltage detection level

Set the low input voltage detection level on the primary side. When the input voltage is lower than the set value, an error code is displayed.

• WB-M352

Set the value in the range of 140 to 460 V.

/ TIPS

- The factory default setting is 160 V. However, the specification of input voltage as welding power source is 208 V (±10%), 230 V (±10%) or 460 V (±10%). If the input voltage is different from this value may affect welding performance.
- WB-M502

Set the value in the range of 260 to 400 V.

<u>/ TIPS</u>

 The factory default setting is 320 V. However, the specification of input voltage as welding power source is the range of 340 to 460 V. If input voltage is lower than this range, it may affect welding performance.

6.7.2.17 F21: Maximum cooling fan operation

The cooling fan can be rotated at the maximum rotation speed at all time.


- [ON]: The cooling fan rotates at the maximum rotation speed at all time. Even when it is set to [ON], ensure not to exceed the specified duty cycle. (2.1.4 Rated duty cycle)
- [OFF]: The cooling fan rotates in a control mode (power-saving operation) due to the temperature detection inside the
 welding power source.

This mode is effective in saving power consumption and preventing suction of extra powder dusts.

6.7.2.18 F23: Sleep mode switching time

When the welding power source is not operated for a fixed period of time, it can be turned into the sleep mode.


- [0]: disables the function.
- [1] to [10]: enables the function.
 Set the transition time to the sleep mode in the range of 1 to 10. During the sleep mode, power consumption is reduced.
 - In the sleep mode, the dot at the first digit on the left/right digital meters flashes. All the other displays on the operation panel are turned OFF.
 - Any operation during the sleep mode restores the condition to the previous state.



6.7.2.19 F24: Wire feeding speed setting

The welding current can be automatically set based on the wire feed speed.

- [ON]: enables the function.
 - The welding power source is automatically set based on the wire feed speed.
 - Even when the welding mode is changed by the GAS menu, the welding current is automatically set based on the set wire feed speed.
 - Each pressing the UNIT CHANGE key, the wire feed speed display and the welding current display switches alternatively. Switch to the wire feed speed display, and set the feed speed in the unit of 3.9 IPM (0.1 m/min).
 - Switching to the welding current display can check the welding current value automatically set.
 - In using the welding power source in the automatic machine mode, refer to the following diagram for the relationship of command voltage and the wire feed speed (when the internal function F4 (Auto/Semi-auto mode) is used with the setting of Automatic machine 1 mode).



/ TIPS

- The wire feed speed with the maximum command voltage is 866 IPM (22 m/min).
 (Depending on the welding mode, the wire feed speed does not always reach 866 IPM (22 m/min).)
- The minimum wire feed speed is approximately 24 to 79 IPM (0.6 to 2.0 m/min). (This
 depends on the welding mode.) Even when a low command voltage is input, it is not possible
 to set to a value below this.

- [OFF]: disables the function.
 - The wire feed speed is automatically set based on the welding current.
 - Even when the welding mode is changed by the GAS menu, the wire feed speed is automatically set based on the set welding current.
 - Each pressing the UNIT CHANGE key, the wire feed speed display and the welding current display switches alternatively. Switch to the welding current display, and set the welding current in the unit of 1 A.
 - Switching to the welding current display can check the wire feed speed automatically set.
 - In using the welding power source in the automatic machine mode, refer to the graph in " 6.7.2.4 F5: Maximum external command voltage". (When the internal function F4 (Auto/Semi-auto mode) is used with the setting of Automatic machine 1 mode)

6.7.2.20 F25 to F28: External output terminal setting

- Through F25, you can set the functions of OUT-EXT1 ("3" "4") on the terminal block for external connection.
- Through F26, you can set the functions of OUT-EXT2 ("5" "6") on the terminal block for external connection.
- Through F27, you can set the functions of OUT-EXT3 ("7" "8") on the terminal block for external connection.
- Through F28, you can set the functions of OUT-EXT4 ("9" "10") on the terminal block for external connection.

Configurable functions are as shown in the below table.

Setting	Function name	Explanation
0	_	No function is allocated.
1 to 3	_	No function is allocated in this machine.
4	Alarm Signal of Welding Monitor	A welding condition error is detected during welding, and the signal is output to the external terminal. If either of the current/voltage is out of the preset range, the external output terminal with this function is closed.

6.7.2.21 F25 to F28: External output terminal setting (reserved)

The external output terminals (OUT-EXT1 to EXT4 on the external output terminal TM4) are used in connection with the automatic machines of other manufacturers.

6.7.2.22 F29 to F32: External input terminal setting

Set the function of external input terminals. (when using robot or automatic machines)

- F29: set the function of IN-EXT1 ("5" to "9") on the external connection terminal block TM3.
- F30: set the function of IN-EXT2 ("6" to "9") on the external connection terminal block TM3.
- F31: set the function of IN-EXT3 ("7" to "9") on the external connection terminal block TM3.
- F32: set the function of IN-EXT4 ("8" to "9") on the external connection terminal block TM3.

For the details of external connection terminal block; (4.5.2 Connection of automatic machine)

The functions allocable to F29 to F32 are as follows:

Setting	Function name	Explanation	
0	-	No function is allocated.	
1	Gas valve	Causing short circuit between terminals opens the gas valve. (*1)	
2	Inching	Causing short circuit between terminals starts inching.	
3	Retract	When inching operation is performed after short circuit is caused between terminals are short-circuited the wire feeding motor reverses to retract the wire. (*2)	
4	Start	Causing short circuit between terminals starts welding. (torch switch: ON)(*3)	
5	Loading welding condition	The welding conditions stored on the memory can be read out by combination of signals. (*4), (*5)	

^{*1:} When the gas valve is opened by the signal from the external input terminal, the gas valve will not close when welding completes or according to the timer (2 minutes). In order to stop gas, ensure to open the terminals.

^{*2:} Causing short circuit between the external input terminals before turning on the inching signal. To stop the operation, turn off the inching signal and then disconnect the external input terminals.

^{*3:} The starting terminal of the feeder receptacle on the front of welding power source becomes deactivated.

*4: Combination of the external input terminals enables to read out the welding conditions of the JOB No. 1 to 16 (Registration No. 1 to 16) registered on the memory. The corresponding JOB No. are as shown in the below table.

JOB No.	Function (external input terminal)					
(Registration No.)	F29(IN-EXT1)	F30(IN-EXT2)	F31(IN-EXT3)	F32(IN-EXT4)		
1	OFF (open)	OFF (open)	OFF (open)	OFF (open)		
2	ON (close)	OFF (open)	OFF (open)	OFF (open)		
3	OFF (open)	ON (close)	OFF (open)	OFF (open)		
4	ON (close)	ON (close)	OFF (open)	OFF (open)		
5	OFF (open)	OFF (open)	ON (close)	OFF (open)		
6	ON (close)	OFF (open)	ON (close)	OFF (open)		
7	OFF (open)	ON (close)	ON (close)	OFF (open)		
8	ON (close)	ON (close)	ON (close)	OFF (open)		
9	OFF (open)	OFF (open)	OFF (open)	ON (close)		
10	ON (close)	OFF (open)	OFF (open)	ON (close)		
11	OFF (open)	ON (close)	OFF (open)	ON (close)		
12	ON (close)	ON (close)	OFF (open)	ON (close)		
13	OFF (open)	OFF (open)	ON (close)	ON (close)		
14	ON (close)	OFF (open)	ON (close)	ON (close)		
15	OFF (open)	ON (close)	ON (close)	ON (close)		
16	ON (close)	ON (close)	ON (close)	ON (close)		

The external input terminal without the setting "5" is regarded as signal OFF. Accordingly, for the function (external input terminal) which does not require the "ON" status for the JOB No. to read can be set to other functions.

Example 1) In reading out the welding condition of the JOB No.3;

Setting F30 to "5" and turning the signal of external input terminal IN-EXT2 to ON enable to read out the JOB No. 3.

For F29, F31, and F32, other functions can be set.

Example 2) In reading out the welding condition of the JOB No.3;


Setting F29 to F32 to "5" and turning the signal of external input terminal IN-EXT2 to OFF enable to read out the JOB No. 3.

Example 3) In reading out the welding condition of the JOB No.7;

Setting F30 and F31 to "5" and turning the two signals of the external input terminal IN-EXT2/IN-EXT3 to ON enable to read out the JOB No. 7. For F29 and F32, other functions can be set.

Example:

In the setting examples of F29: "5"; F30: "0"; F31: "5"; and F32: "0", the following diagram is available:



- Before 100 ms of the torch switch ON (start signal "ON"), set the welding condition to "5" for F29 to F32 to read out the welding JOB No.
- To switch plural signals at the same time, carry out the operation within 40 ms.
- From 40 ms before the torch switch OFF (start signal "OFF") to 100 ms after it, do not change the setting of "5".

6.7.2.23 F38: Arc voltage direct detection switching

Sets the combination of enabling or disabling the voltage direct detection terminal on the base metal side of the welding power source and voltage detection terminal of the wire feeder.

Extending the power cable without the cable at the base metal side can cause extraordinary volume of spatter. In this case, setting this function to "1" by using the voltage detection cable (optionally available) can improve the status.

Connection of voltage detection cable (4.6 Wiring of Voltage Detection Cable at Base Metal Side)

- 0: Direct detecting (Wire feeder)
 Terminal detecting (Base metal)
- 1: Direct detecting (Wire feeder) Direct detecting (Base metal)
- 2: Terminal detecting (Wire feeder) Terminal detecting (Base metal)

/ TIPS

- Use the voltage detection cable (optionally available) when the total length of the extension cable is 99 ft (30 m) or longer.
- When using wire feeder CM-7403, water-cooled welding torch cannot be used. Accordingly, arc voltage
 direct detection switch cannot be activated even with this function set to "1".
- · When using a reverse-polarity wire, set this function to "2".

6.7.2.24 F39/F40: Output current gain adjustment

If there is difference between the current value indicated on the digital meter and the actual output current value, the difference can be calibrated through adjustment of F39/F40.

The output current value that can be changed by F39 is [1], which is equivalent to 1A. The value that can be changed by F40 is about 0.01A, which is equivalent to [0.01].

This function can be adjusted only in the "calibration mode". For details, refer to "7.6 Calibration Mode".



Do not carelessly change the setting of this function.

6.7.2.25 F41/F42: Output voltage gain adjustment

If there is difference between the voltage value indicated on the digital meter and the actual output voltage value, the difference can be calibrated through adjustment of F41/F42. The output voltage value that can be changed by F41 is [0.1], which is equivalent to about 0.01 V. The value that can be changed by F42 is about [0.01], which is equivalent to about 0.01 V. This function can be adjusted only in the "calibration mode". For details, refer to "7.6 Calibration Mode".



· Do not carelessly change the setting of this function.

6.7.2.26 F43: CAN ID

When multiple welding power sources are connected with a PC monitoring system, set ID for CAN.

6.7.2.27 F44: Reading welding conditions with remote control

Sets whether to read the welding condition registered to the memory by the analog remote control (optional) or not. This function is effective when the internal function F4 (Auto/Semi-auto mode) is set to "0".


- [ON]: reads the welding condition by the analog remote control (optional)
 - Setting the welding current setting knob on the analog remote control to 1-10 of the scale can read out the conditions stored to the JOB No. 1-10.
 - By the welding voltage setting knob, fine adjustment of the welding voltage of the condition read out is available.
 (% adjustment)

Adjust the voltage value based on the center of welding voltage setting knob. To increase the welding voltage, turn the knob clockwise and to reduce the welding voltage, turn the knob counterclockwise.

The fine adjustment range for welding voltage is up to ± 20 %.

Example:

The right figure shows an example when the JOB No. "3" is read out and the welding voltage is the condition stored on the memory (no fine adjustment).




- [OFF]: disables the function.
- In the following cases, this function cannot be used:
 - Welding conditions are not registered to the memory;
 - Analog remote control (optional) is not connected to the welding power source;
 - Internal function F11 (Fine adjustment of welding conditions memory) is set to "1" to "30" (enabled);
 - Internal function F45 (Special crater sequence) is set to "ON" (enabled);
 - Internal function F48 (Adjusting current with torch switch) is set to "ON" (enabled); or
 - Internal function F51 (Special crater repeat) is set to "ON" (enabled); or
 - Either of the internal functions F29 to F32 (External input terminal setting) is set to either "4" (Start) or "5" (Loading welding condition).

6.7.2.28 F45/F46/F47: Special crater sequence (effective/initial standard time setting/crater standard time setting)

Incorporates initial condition and crater condition in the "No crater" sequence.

- Setting the internal function F45 to [ON] enables to carry out the initial welding/crater treatment set by F46/F47 even
 in the welding of "No crater" condition.
- When this function is enabled, "special crater" is displayed in the HOME screen, enabling the internal functions F46 and F47.
- To the internal function F46, set the time for initial welding in the range of 0.0 to 10.0 seconds. Set the value in the range of 0.0 to 10.0 seconds.
- To the internal function F47, set the crater treatment time in the range of 0.0 to 10.0 seconds. Set the value in the range of 0.0 to 10.0 seconds.



/ TIPS

- When the internal function F45 is set to [ON], automatically the setting of "special crater" is selected, disabling other welding modes. (The CRATER-FILL menu does not work.)
- · Welding method at crater treatment is the same as that of main welding.

- In the following cases, this function cannot be used:
 - Internal function F11 (Fine adjustment of welding conditions memory) is set to "1" to "30" (enabled);
 - Internal function F44 (Reading welding condition with remote control) is set to "ON" (enabled);
 - Internal function F48 (Adjusting current with torch switch) is set to "ON" (enabled); or
 - Internal function F51 (Special crater repeat) is set to "ON" (enabled); or
 - Either of the internal function F29 to F32 (External input terminal setting) is set to "5" (Loading welding condition).

6.7.2.29 F48: Adjusting current with torch switch

Increases/decreases the welding current by the torch switch operation.


- [ON]: the setting of "CRATER-FILL ON" is selected, enabling to increase or decrease welding current by single-clicking or double-clicking the torch switch in the period of welding condition (during start input holding)
- If this function is enabled, "ADJUST.CURRENT by TS" is displayed in the HOME screen, enabling the internal functions F49 and F50.
- Set the increase/decrease current volume through F49 (Current increase and decrease by single-clicking) and F50 (Current increase and decrease by double-clicking).
- [OFF]: disables the function.

/ TIPS

- When the internal function F45 is set to [ON], automatically the setting of "CRATER-FILL ON" is selected, disabling other welding modes. (The CRATER-FILL menu does not work.)
- · Setting for current increase and decrease is available for both single-clicking and double-clicking.
- Single-clicking or double-clicking operation should be within 0.3 seconds.
- At the time of transition to crater, press the torch switch for at least 0.3 seconds.
- · Welding method at crater treatment is the same as that of main welding.

Example:

In the setting examples of Crater setting: ON; Initial condition: OFF; Welding current: 100 A; Crater current: 60 A; F48: "ON"; F49:"-10"; and F50: "20", the following diagram is available:



- In the following cases, this function cannot be used:
 - An analog remote control (optional) is connected.
 - Internal function F11 (Fine adjustment of welding conditions memory) is set to "1" to "30" (enabled);
 - Internal function F44 (Reading welding condition with remote control) is set to "ON" (enabled);
 - Internal function F45 (Special crater sequence) is set to "ON" (enabled);
 - Internal function F51 (Special crater repeat) is set to "ON" (enabled); or
 - Either of the internal functions F29 to F32 (External input terminal setting) is set to either "4" (Start) or "5" (Loading welding condition).

6.7.2.30 F49: Current increase and decrease by single-clicking

To increase / decrease the welding current by the torch switch operation, set the current increase / decrease volume at single-clicking. This function is available when the internal function F48 (Adjusting current with torch switch) is set to [ON].

• Set the current increase/decrease volume by single-clicking in the range of -100 to 100 A.

6.7.2.31 F50: Current increase and decrease by double-clicking

To increase / decrease the welding current by the torch switch operation, set the current increase / decrease volume at double-clicking. This function is available when the internal function F48 (Adjusting current with torch switch) is set to [ON].

 \bullet Set the current increase/decrease volume by double-clicking in the range of -100 to 100 A.

6.7.2.32 F51: Special crater repeat

In the sequence of main welding of the "CRATER-FILL ON (Repeat)" (during start input holding), the torch switch operation can switch the welding and crater treatment repeatedly as many time as needed.

- [ON]: Setting of "CRATER-FILL ON (Repeat)" is applied, and transits to the crater treatment by single-clicking of the torch switch during the welding sequence (start input holding). It is available to return to the main welding as many times as needed even after transit to the crater treatment by single-clicking of the torch switch.


 When this function is enabled, "special crater (repeat)" is displayed in the HOME screen.
- [OFF]: disables the function.

/ TIPS

- When this function is set to [ON], automatically the setting of "CRATER-FILL ON (Repeat)" is selected, disabling other welding modes. (The CRATER-FILL menu does not work.)
- · Single-clicking operation should be within 0.3 seconds.
- At the time of transition to crater, press the torch switch for at least 0.3 seconds.
- · Welding method at crater treatment is the same as that of main welding.

Example:

In the setting examples of Initial welding current: 80 A; Main welding current: 100 A; and Crater current: 60 A, the following diagram is available:



- In the following cases, this function cannot be used:
 - Internal function F11 (Fine adjustment of welding conditions memory) is set to "1" to "30" (enabled);
 - Internal function F44 (Reading welding condition with remote control) is set to "ON" (enabled);
 - Internal function F45 (Special crater sequence) is set to "ON" (enabled);
 - Internal function F48 (Adjusting current with torch switch) is set to "ON" (enabled); or
 - Either of the internal functions F29 to F32 (External input terminal setting) is set to either "4" (Start) or "5" (Loading welding condition).

6.7.2.33 F52: Data type of data log function

This function enables to select data to save when using the data log function. The patterns of data which can be saved are as shown in the below table.

Satting	Welding current	Welding current	Welding voltage	Welding voltage	Wire feed speed	Wire feed speed
Setting	(Command value)	(Detected value)	(Command value)	(Detected value)	(Command value)	(Detected value)
0	-	-	-	-	-	-
1	-	Storable	-	Storable	-	Storable
2	Storable	-	Storable	-	Storable	-
3	Storable	Storable	-	Storable	-	-
4	Storable	Storable	-	-	-	Storable
5	-	Storable	Storable	Storable	-	-
6	-	-	Storable	Storable	-	Storable
7	-	Storable	-	-	Storable	Storable
8	-	-	-	Storable	Storable	Storable

For data log function; (7.3 Data Backup (Utilization of data)).

6.7.2.34 F53: Sampling speed of data log function

Selects the data sampling interval in using data log function.

The relationship between the setting value and the data sampling is as follows:

Setting	Sampling interval		
1	10 ms		
2	100 ms		
3	1 s		

For data log function; (7.3 Data Backup (Utilization of data)).

6.7.2.35 F54 Tack start process

This function enables to start the wire feeding speed with the normal feeding speed without slow-down after the welding completion. (which enables the tack welding of less transition time)

- [ON]: Pressing the torch switch within 0.5 seconds after the welding completion can start it with the normal feeding speed. (The wire feeding speed at this time is not exceeding 197 IPM (5 m/min).)
- [OFF]: disables the function.

6.7.2.36 F55 to F59: Reserved

Used in connection with the automatic machines of other manufacturers.

6.7.2.37 F67: Setting change of current value (initial condition, crater condition)

When "CRATER ON" is selected, the current value of the initial condition and the crater condition can be set in percentage based on the current value of the welding condition.

- [ON]: enables the function.
 Set the current value of the initial condition with F68, and set the current value of the crater condition with F69.
- [OFF]: disables the function.

6.7.2.38 F68: Setting of current value (initial condition)

The current value of the initial condition can be set in percentage based on the current value of the welding condition.

• Setting range of current value (initial condition): 10~% to 300~%

6.7.2.39 F69: Setting of current value (crater condition)

The current value of the crater condition can be set in percentage based on the current value of welding condition.

• Setting range of current value (crater condition): 10 % to 300 %

6.7.2.40 F70: Setting of upper limit of analog remote control

Sets the upper limit (the value when the knob is turned clockwise all the way) of the welding current adjustable by the analog remote control (optional accessory).

If it is difficult to perform fine current adjustment with the knob of the analog remote control when welding in the low current region, fine current adjustment will be easier if this function is used to lower the upper limit.

The setting range is as follows.

WB-M352: 20 to 400 A WB-M502: 20 to 550 A

6.7.2.41 F71: Interval welding function

This function repeats arc ON/OFF to control the heat input.

• "ON": Enables the function. When this function is enabled, ": Interval" will be displayed at the end of CRATER-FILL CONDITION in the HOME screen, and internal functions F72 and F73 will be enabled.

(Example) CRATER OFF: Interval

"OFF": Disable the function.

/ TIPS

- When this function is set to "ON", the setting of "CRATER-FILL: OFF" will be selected automatically, disabling other welding modes. (The CRATER-FILL menu will not function.)
- In the following cases, this function cannot be used:
 - Internal function F11 (Fine adjustment of welding conditions memory) is set to "1" to "30" (enabled);
 - Internal function F44 (Reading welding condition with remote control) is set to "ON" (enabled);
 - Internal function F45 (Special crater sequence) is set to "ON" (enabled);
 - Internal function F48 (Adjusting current with torch switch) is set to "ON" (enabled); or
 - Either of the internal functions F29 to F32 (External input terminal setting) is set to either "4" (Start) or "5" (Loading welding condition).

6.7.2.42 F72: Setting arc-ON time (Interval function)

Sets the arc-ON time in the Interval welding function.

• Set the arc-ON time in the range of 0.20 to 9.99 seconds.

6.7.2.43 F73: Setting arc-OFF time (Interval function)

Sets the arc-OFF time in the Interval welding function.

• Set the arc-OFF time in the range of 0.20 to 9.99 seconds.

6.7.2.44 F77: Welding result control function identification numbers

Sets the identification numbers of welding power source when using welding result control function. The identification number set in this function become the part of file name when backing up the data of welding result control function. (37 7.3.4 Welding Result Control Function)

· Setting range of identification number: 1 to 999.

6.7.2.45 F78: Prevention of unintended torch switch operation

Sets whether or not to output the error code when welding is not performed for a certain time after the pre-flow to avoid an unexpected torch switch operation.

- [ON]: If welding is not performed for five seconds after the pre-flow, Error code "E-011" is displayed on the left and
 right digital meters and the output of the welding power source stops.
- [OFF]: disables the function. (9.1 Action in Case of Error)

6.7.2.46 F79: Switching of CAN communication connection device

Set the connection device to be used for the CAN communication.

Set to "0" to use the Digital Remote Control Box.

Set to "1" to use the Digital panel (Attached to the wire feeder) and Intelli torch.

Set to "2" to use the Push-Pull torch.

Set to "3" to use the Inline assist feeder.

The Digital panel can also be used with "2" and "3".

This function is effective when any one of "0" (Semi-auto mode), "1" (Automatic machine 1 mode), and "2" (Automatic machine 2 mode) is selected for F4 (Auto/Semi-auto mode).

6.7.2.47 F80: Switching of CAN communication speed

Set the connection speed of the CAN connection.

Set to "0" to use the Digital panel, Intelli torch, Push-Pull torch and Inline assist feeder.

This function is effective when any one of "0" (Semi-auto mode), "1" (Automatic machine 1 mode), and "2" (Automatic machine 2 mode) is selected for F4 (Auto/Semi-auto mode).

6.7.2.48 F81: TIG Mode torch switch setting

Even if DC TIG is selected as welding method, operating the torch switch of the torch connected to the wire feeder can start or end welding. Normally, in DC TIG, torch detective voltage is always applied to the torch electrode, and then, arc starts when the electrode touches the base metal. However, when this function is ON, torch control is enabled.

- [ON]: Operating the torch switch can control the welding start and end. Setting of welding sequence including sealed gas flowing (Pre-flow, Initial Condition, Crater condition, Post-flow) is also enabled. In addition, functions such as "Gas valve", "Start" of external input terminal can be also used. (\$\infty\$ 6.7.2.22 F29 to F32: External input terminal setting)
- [OFF]: disables the function.


6.7.2.49 F83: Arc length adjustment right after starting

Adjusts the arc length right after starting the welding operation.

The arc length, right after starting the welding operation, will automatically be set to an adequate value according to the set welding conditions. If wire burning is not adequate at the start of the welding operation, carry out the arc length adjustment right after starting.

For more intense burning, increase the value of arc length adjustment right after starting. For less intense burning, reduce the value of arc length adjustment right after starting.

• Setting range of the value: -20 to 10.



6.7.2.50 F86/F87: Current display adjustment (GAIN/OFFSET)

Set the adjustment value (gain/offset) when the current display value on the left digital meter is different from the actual current value.

The current value displayed on the digital meter is obtained by software processing of the average value of outputs; therefore, it may not be consistent with the value indicated on a needle meter, etc. When this happens, using this function enables to finely adjust the current display value.

- For F86, set gain, and for F87, set offset.
 Changing the set value only corrects the display; the output welding current does not change.
- For more information on the adjustment procedure, contact dealer.



· Do not carelessly change the setting of this function.

6.7.2.51 F88/F89: Voltage display adjustment (GAIN/OFFSET)

Set the adjustment value (gain/offset) when the voltage display value on the right digital meter is different from the actual voltage value.

The voltage value displayed on the digital meter is obtained by software processing of the average value of outputs; therefore, it may not be consistent with the value indicated on a needle meter, etc. When this happens, using this function enables to finely adjust the voltage display value.


- For F88, set gain, and for F89, set offset.
 Changing the set value only corrects the display; the output welding voltage does not change.
- For more information on the adjustment procedure, contact dealer.



. Do not carelessly change the setting of this function.

This section explains the functions of knobs and buttons arranged for the analog remote controller (optional) as well as their operation.

Since the setting at the analog remote control is preferred when connected, it is not possible to set this condition on the operation panel of welding power source. (The initial condition and crater condition can be set on the operation panel.)



No.	Name	Function		
1	Welding current adjustment knob	Set the welding current. The set value is displayed on the left digital meter at the welding power source side.		
		Set the welding voltage. The set value is displayed on the right digital meter at the welding power source side.		
2	Welding voltage adjustment knob	 < SYNERGIC adjustment > Optimum welding voltage according to the welding current is automatically set, and fine adjustment is available for the set welding voltage. Align the welding voltage adjustment knob to the center ("		
		< INDIVIDUAL adjustment > The welding voltage can be individually adjusted without being influenced by the welding current.		
3	Inching button	Feeds the wire. (5.4 Wire Inching) During when the button is pressed, the wire feeding is carried out. Wire feed speed can be adjusted by the welding current adjustment knob while pressing the inching button.		
4	Scale plate (*1)	Replace the scale plate for analog remote control (6.7.2.8 F9: Analog remote control scale) when using the optional analog remote control. Note that the scale of analog remote control as well as the scale plate to be used depends on the rated output current of the welding power source. (Above diagram shows an example with 350 A)		
		350 A: 350/200 500 A: 500/350/200		
5	Switch knob	Operated to use the functions selected in internal function F2. 6.7.2.8 F2: Switching functions with remote control)		
6	Fixing screw	To replace the scale plate, turn the screw counter clockwise, and remove them.		

^{*1:} For adjustment of low current region when using a thin wire, etc., using the accessory scale plate with full scale of 200 A allows fine adjustment. To use this scale plates, set the internal function F9 function. (© 6.7.2.8 F9: Analog remote control scale)

/ TIPS

- In connecting (or removing) the analog remote control to (or from) the welding power source, turn OFF
 the power switch of the welding power source.
- The analog remote control is automatically recognized after being connected to the analog remote control and turning ON the power switch.

The functions which can be assigned to the switching knob are as follows.

"F2" setting	Functions	Position of switching knob		
rz setting	runctions	[1]	[2]	[3]
0	No function	-	-	-
1	Crater setting (6.6.4 Crater setting)	CRATER-FILL OFF	CRATER-FILL ON	CRATER-FILL ON (Repeat)
2	Gas check (5.3 Power ON and Gas Supply)	OFF	OFF	ON
3	Constant penetration (6.8 Penetration control adjustment)	OFF	OFF	ON
4	Tack Start (6.7.2.35 F54 Tack start process)	OFF	OFF	ON
5	Read out of welding conditions (6.7.2.27 F44: Reading welding conditions with remote control)	OFF	OFF	ON
6	No function	-	-	-

Administrator Functions

Chapter 7 Administrator Functions

This chapter explains the functions used by administrators such as protection and initialization of welding conditions.

7.1 Protection of Welding Conditions

This section explains the protection function (password function) of welding conditions. When the function is enabled (5.5.2) Preventing erroneous operation on operation panel), a password will be requested to disable the erroneous operation prevention function.

The erroneous operation prevention function prohibits the following operations to prevent accidental change of welding conditions.

- Setting welding conditions (Checking of settings is allowed)
- · Operating the mode switching menu and the parameter adjusting knob

Functions such as gas check that do not affect the welding conditions will not be prohibited. The operations above will become possible if the erroneous operation prevention function is disabled.

NOTE

- Write down the password on a piece of paper and store it safely.
- · The current password will be requested also when you change it.
- If a password is set and the erroneous operation prevention function is enabled, the
 erroneous operation prevention function will not be disabled even if the power is turned off
 and on or if the welding conditions and internal functions are initialized.
- · If the password is lost, please contact your dealer.

7.1.1 Setting/Changing password

This section explains how to set and change the password.


- Welding is not possible during setting the password.
- Set a three-digit number other than "000" (initial value) as the password. Setting "000" does not set a password. (No password specified)

/ NOTE

 First determine a specified number and write it down on a piece of paper, and then set the number as the password having the paper at hand.



- 1. Turn OFF the power switch.
- 2. While both DISPLAY CHANGE keys are pressed at the same time, turn ON the power switch.
 - ⇒ The USER MENU will be displayed on the LCD panel.



- 3. Turn the screen operation knob to select "Password Setting", and press the knob.
 - If a password has already been set, the Password Input screen will be displayed on the LCD panel. To change the password, delete the password with the operation from the step 3 of "7.1.2 Disabling erroneous operation prevention" and go to the next step.
 - If a password has not been set yet, the Password Setting screen will be displayed on the LCD panel. Check that the Password Setting screen is displayed, and go to the next step.







- 4. Turn the screen operation knob to select the digit that needs to be set, and press the knob.
 - ⇒ The color of the selected digit will be inverted on the display.



- 5. Turn the screen operation knob, set the password of the selected digit, and press the knob.
 - ⇒ The number is confirmed, and the display will change from color inversion display to digit selection display.



6. Set the password of other digits in the same manner as the steps 4 and 5.



- 7. Turn the screen operation knob to select "OK" (color inversion display).
 - To cancel setting of the password, turn off the power switch.



- 8. Check that the password is correct and press the screen operation knob.
 - ⇒ The password has been set.




After the password is set, if the KEY LOCK is turned ON in the MENU screen, the key mark
will be displayed in the HOME screen, and the erroneous operation prevention function
becomes enabled. To disable the erroneous operation prevention function, the password will
be requested.

7.1.2 Disabling erroneous operation prevention


This section explains how to disable the password-protected erroneous operation prevention function.




- 1. Display "KEY LOCK" in the MENU screen.
 - Turn the screen operation knob to place the cursor on "KEY LOCK", and press the knob.




- 2. Turn the screen operation knob to select the digit that needs to be entered, and press the knob.
 - ⇒ The color of the selected digit will be inverted on the display.




- 3. Press the screen operation knob, enter the password of the selected digit, and press the knob.
 - The number is confirmed, and the display will change from color inversion display to digit selection display.
 - To cancel deleting the password, press the "CANCEL" key.




4. Enter the password of other digits in the same manner as the steps 3 and 4.




5. Turn the screen operation knob, and have the color of "OK" inverted on the display.



- 6. Press the screen operation knob.
 - ⇒ When the number matches the set password, "Password OK" is displayed on the LCD panel and the lock will be released.
 - If the number does not match the set password, "Password NG" is displayed. Check the password and carry out the operation again.





- 7. Press the screen operation knob to exit from the Password Deletion screen.
 - \Rightarrow For the KEY LOCK releasing operation, the screen will return to the MENU screen.
 - ⇒ For the password changing or deleting operation, the screen will shift to the Password Setting screen. (☞ 7.1.1 Setting/Changing password)

7.2 Welding Result Control Function

This section explains about the welding result control function. The function enables the management of the items below.

Welding control parameter	Monitor No.	Initial value	Setting range	Explanation
	P10	0	-	Cumulative number of welding points (number of times)
Number of welding	P11	0	0 to 9999	Target value of welding points (number of times)
point	P12	0	0 to 5	Operation at the time when the target value of welding points is achieved
	P20	0.00	-	Cumulative wire consumption used in welding [lbs (kg)]
Wire consumption	P21	0	0 to 9999 (0 to 4535)	Target wire consumption [lbs (kg)]
	P22	0	0 to 5	Operation at the time when the target wire consumption is achieved
	P30	0	-	Cumulative total welding time (minute)
Total welding time	P31	0	0 to 9999	Target total welding time (minute)
	P32	0	0 to 5	Operation at the time when the target total welding time is achieved
	P40	0	-	Max. fluctuation value of average range monitor (A or V)
	P41	100	0 to 100	Current tolerance (+) (%)
	P42	100	0 to 100	Current tolerance (-) (%)
Welding monitor	P43	100	0 to 100	Voltage tolerance (+) (%)
	P44	100	0 to 100	Voltage tolerance (-) (%)
	P45	0	0 to 100	WARNING judgment time (second)
	P46	0	0 to 2	Operation at the time of WARNING detection
	P50	0.0	-	Cumulative total operation time (hour)
Total operating time	P51	0.0	-	Cumulative total welding time (hour)
	P52	OFF	cLr/OFF	Clear the control data

Details of control contents (7.2.2 Details of welding control items)


7.2.1 Setting welding result control function

This section explains how to set the welding result control function.




- 1. Place the cursor on "WELD MONITOR" in the MENU screen, and press the screen operation knob.
 - ⇒ The monitor No. is displayed on the left digital meter.
 - ⇒ The data value specified for the monitor No. is displayed on the right digital meter.






2. Select the desired monitor No.

- Turning the screen operation knob (or parameter adjustment knob) will change the tens place digit of monitor No. (Example: "P10" -> "P20" -> "P30" -> "P40")
- Pressing the screen operation knob will change the ones place digit of monitor No. (Example: "P10" -> "P11" ->
- When an appropriate monitor No. is selected on the left digital meter, the right digital meter will flash.



3. Turn the screen operation knob (or parameter adjustment knob), and change the setting value.

- ⇒ The set value is displayed on the right digital meter.
- To select another monitor No., press the screen operation knob until the ones place digit is set at "0" on the digital meter, and perform the same operation as step 2



4. Press the CANCEL key.

- ⇒ The screen will return to the MENU screen.
- ⇒ When the set target is achieved or at the time of WARNING detection, an alarm will appear on the left/right digital meters. (7.2.2 Details of welding control items)

7.2.2 Details of welding control items

This section explains about details of the welding control items.

7.2.2.1 Number of welding point

The number of welding points is controlled according to the setting range.

- P10 (Cumulative number of welding points)
 - The interval from the start of current flowing triggered by the torch switch ON to the stop of output triggered by the torch switch OFF is regarded as one count (one welding point) and accumulated.

The setting range of count value is between 0 and 9999. The count value will be cleared according to the "P12" setting. (If continuous operation is enabled, the value will be cleared when exceeding 9999 and return to 0.)

- P11 (Target value of welding points)
 - Select the target value of welding points in the range from 0 to 9999. When the "P10" count value reaches the number of welding points specified here, an alarm appears indicating that the target is achieved. (7.2.2.6 Alarm indication when target is achieved)
- P12 (Operation at the time when the target value of welding points is achieved) Select the operation from 0 to 5 for the time when the target specified for "P11" is achieved. The set values and operations when the target is achieved are as below.

Operation	Set value					
	0	1	2	3	4	5
The count value is cleared when the target is achieved (*1)	Yes	No	Yes	No	No	No
Operation is continued after the target is achieved (*2)	Enable	Enable	Enable	Enable	Disabled	Disabled
The count value is cleared when the power is turned on	Yes	Yes	No	No	Yes	No

^{*1:} When an alarm is displayed, pressing any key of the operation panel can also clear the count value.

*2: If "Disabled" is selected and the target is achieved, next welding cannot start until any key on the operation panel is pressed.

7.2.2.2 Wire consumption

Wire consumption is controlled according to the setting range.

P20 (Cumulative wire consumption used in welding)
 Wire consumption [lbs (kg)] used in welding is measured and counted.

The setting range of count value is between 0 and 9999 lbs (0 and 4535 kg). The count value will be cleared according to the "P22" setting.

(If continuous operation is enabled, the value will be cleared when exceeding 9999 and returns to 0.)

TIPS

 Approximate wire consumption will be obtained with the wire consumption control function. The wire consumption may be different from the actual wire consumption due to reasons such as slipping of wire.

The table below shows the wire unit amount [lbs (g/m)] calculated from the specific gravity (g/cm^3) of the wire material. Wire consumption is calculated based on the unit amount and the wire feeding amount during welding. Therefore, there will be differences between the actual consumption and the calculated value depending on the wire constituents.

- When wire consumption is 220.5 lbs (100 kg) or lower, the value after the decimal point
 is also displayed.
- · The wire consumption used in inching or wire slowdown is not measured.
- · Special wires not listed in the table below are not measured.

Wire		Unit amount [lbs (g/m)]												
diameter [in. (mm)]	Mild steel solid	Mild steel cored	Stainless steel	Stainless ferrite	Stainless cored	Brazing CuSi	Brazing CuAl	Soft aluminum	Hard aluminum	Inconel	Titanium			
.030 (0.8)	0.0086 (3.9)	_	0.0088 (4.0)	0.0086 (3.9)	1	0.0099 (4.5)	0.0099 (4.5)	_	_		_			
.035 (0.9)	0.0110 (5.0)	_	0.0112 (5.1)	0.0108 (4.9)	0.0093 (4.2)	_	_	_	_	0.0119 (5.4)	_			
.040 (1.0)	0.0137 (6.2)	0.0137 (6.2)	0.0139 (6.3)	0.0132 (6.0)	_	0.0157 (7.1)	0.0157 (7.1)	_	0.0046 (2.1)	0.0214 (9.7)	0.0079 (3.6)			
.045 (1.2)	0.0196 (8.9)	0.0163 (7.4)	0.0198 (9.0)	0.0192 (8.7)	0.0163 (7.4)	0.0225 (10.2)	0.0225 (10.2)	0.0066 (3.0)	0.0066 (3.0)	-	0.0115 (5.2)			
.052 (1.4)	0.0267 (12.1)	0.0223 (10.1)	1	_	1	_	_	_	_	ı	_			
1/16 (1.6)	0.0348 (15.8)	0.0291 (13.2)	0.0351 (15.9)	_	0.0291 (13.2)	_	_	0.0119 (5.4)	0.0119 (5.4)	-	_			

• P21 (Target wire consumption)

Select the target value of wire consumption in the range from 0 to 9999 lbs (0 to 4535 kg).

When the "P20" count value reaches the wire consumption specified here, an alarm appears indicating that the target is achieved. (7.2.2.6 Alarm indication when target is achieved)

P22 (Operation at the time when the target wire consumption is achieved)
 Select the operation from 0 to 5 for the time when the target specified for "P21" is achieved.
 The set values and operations when the target is achieved are the same as those of the "P12" function. "P12 (Operation at the time when the target number of welding points is achieved)" (7.2.2.1 Number of welding point)

7.2.2.3 Total welding time

The total welding time is controlled according to the setting range.

P30 (Cumulative total welding time)
 Every interval from the start of current flowing triggered by the torch switch ON to the stop of output triggered by the torch switch OFF is counted and accumulated as welding time.

The setting range of count value is between 0 and 9999 minutes. The count value will be cleared according to the "P32" setting. (If continuous operation is enabled, the value will be cleared when exceeding 9999 and returns to 0.)

- P31 (Target total welding time)
 - Select the target value of total welding time in the range from 0 to 9999 minutes.
 - When the "P30" count value reaches the total welding time specified here, an alarm displays indicating that the target is achieved. (\$\infty\$ 7.2.2.6 Alarm indication when target is achieved)
- P 32 (Operation at the time when the target total welding time is achieved)
 Select the operation from 0 to 5 for the time when the target specified for "P31" is achieved.
 The set values and operations when the target is achieved are the same as those of the "P12" function. "P12 (Operation at the time when the target number of welding points is achieved)" (7.2.2.1 Number of welding point)

7.2.2.4 Welding monitor

Average current/voltage during welding is monitored. When it exceeds the range specified here, an alarm displays and the output stops. Also, by setting the internal functions (Functions), the welding power source can output the alarm signal to the external output terminal when it exceeds the range. (© 6.7.2.20 F25 to F28: External output terminal setting)

P40 (Max. fluctuation value of average range monitor)
 If the average current/voltage (per second) becomes out of the allowable tolerance range specified in "P41" to "P44", an alarm is displayed indicating the following. (\$\simp 7.2.2.7\$ Alarm indication at the time of WARNING detection (Welding Monitor "P45" "P46"))

```
If the current is out of the range : Difference (A) between the set value and the average value of welding current if the voltage is out of the range : Difference (V) between the set value and the average value of welding voltage if both the current and voltage are out of the range : Difference of either value which is more largely out of the range than the other range
```

- P41 (Current tolerance (+))
 - P42 (Current tolerance (-))
 - P43 (Voltage tolerance (+))
 - P44 (Voltage tolerance (-))

Select the allowable tolerance range from 0 to 100 % in relation to the set values of welding current/voltage.

Example: The "P41" to "P44" settings when the set value of welding current is 200A and that of welding voltage is 20 V.

```
P41 (Current tolerance (+)) is set to "10" % (= 220 A) P42 (Current tolerance (-)) is set to "20" % (= 160 A) P43 (Voltage tolerance (+)) is set to "20" % (= 24 V) P44 (Voltage tolerance (-)) is set to "10" % (= 18 V)
```

In the example above, the allowable tolerance range of welding current is 160 to 220 A and that of welding voltage is 18 to 24 V.

P45 (WARNING judgment time)

Select the time to judge the event as an error in the range from 0 to 100 seconds when the average current/voltage (average per second) during welding is out of the allowable tolerance range.

When the out-of-range state becomes longer than the time specified here, an alarm displays. (\$\infty\$ 7.2.2.7 Alarm indication at the time of WARNING detection (Welding Monitor "P45" "P46"))

If "0" is set, WARNING detection will not be performed.

• P46 (Operation at the time of WARNING detection)
Select the operation at the time of WARNING detection from 0 to 2.

The set values and operations at the time of WARNING detection are as below.

Set value	Operation						
0	Alarm indication only. Welding can continue. (Continuous operation is possible)						
1	The ongoing welding can continue. After the welding is finished, next welding cannot start until any key of the operation panel is pressed. (Continuous operation is not possible)						
2	Welding stops immediately. Next welding cannot start until any key of the operation panel is pressed. (Continuous operation is not possible)						

Alarm signal output function to external output terminal

If the average current/voltage (average per second) during welding falls outside the tolerance range set by "P41" to "P44", the external output terminals set by the internal functions will be shorted. (\$\infty\$ 6.7.2.20 F25 to F28: External output terminal setting)

The shorted external output terminals open when any of the following conditions are met.

- When some key on the panel is pressed while the alarm is displayed and normal display is restored.
- When the torch switch is set to "ON" while an alarm is displayed to start welding (only when P46 is set to "0")
- When operation is stopped by releasing 3-4 (operation stop terminal) on the external connection terminal block TM3 during alarm indication, and then the operation stop is canceled by short-circuiting these terminals (only when F4 setting is "1" or "2").

7.2.2.5 Total operating time

Total operation time and total welding time are managed according to the display range.

- P50 (Cumulative total operation time)
 The operation time of welding power source is counted at all time and accumulated as total operation time. The setting range of count value is between 0 and 9999 hours.
 Refer to P52 (Clear the control data) about how to clear "P50".
- P51 (Cumulative total welding time) Every interval from the start of current flowing triggered by the start signal ON to the stop of output triggered by the start signal OFF is counted and accumulated as welding time. The setting range of count value is between 0 and 9999 hours. The time between 0 and 99.9 hours are displayed in the unit of 0.1 hour and the time exceeding 100 hours is displayed in the unit of 1 hour. The count value of "P51" will not be cleared according to the "P32" setting. Refer to P52 (Clear the control data value) about how to clear "P51".
- P52 (Clear of the control data value)
 Clear the various control data. After setting the setting value of P52 to "cLr", return to the MENU screen. Then, the control data shown below will be cleared.

P50 (Cumulative total operation time) P51 (Cumulative total welding time)

7.2.2.6 Alarm indication when target is achieved

When any of the number of welding points, wire consumption and total welding time reaches the target specified, its corresponding control No. will flash.

- In the right example, the control No. "P20" flashes on the left digital meter and the specified value "910" on the right digital meter.
- The display returns to the normal state when any key of the operation panel is pressed.
- If continuous operation is enabled in the setting of the operation for the time when the target is achieved, an alarm will display every time welding finishes until any key of the operation panel is pressed.



<Example> When wire consumption reached the target value

7.2.2.7 Alarm indication at the time of WARNING detection (Welding Monitor "P45" "P46")


If the average current or average voltage becomes out of the specified range, the difference between the average value and the specified value will flash.

 The right example shows a current error. The control No. "P40" flashes on the left digital meter and the difference between the average value and specified value "30" on the right digital meter, with the "A" LED lighting.



<Example> While welding is conducted with the welding current 200 A/Current tolerance (+) 10% (=220 A), the average current during welding rose to 230 A and the WARNING judgment time specified in "P45" elapsed.

- The right example shows a voltage error. The control No. "P40" flashes on the left digital meter and the difference between the average value and specified value "1.5" on the right digital meter, with the "A" LED lighting.
 - In case of voltage error, the difference between the average voltage and specified voltage is displayed in one decimal place.
- The display returns to the normal state when any key of the operation panel is pressed.
- If continuous operation is disabled ("1" or "2" is selected) in the "P46" setting, next welding cannot start until any key of the operation panel is pressed.



<Example> While welding is conducted with the welding voltage 15 V/Voltage tolerance (+) 0% (=15 V), the average voltage during welding rose to 16.5 V and the WARNING judgment time specified in "P45" elapsed.

7.3 Data Backup (Utilization of data)

This section explains about backup of data such as welding conditions and importing of the backup data. The following contents can be backed up as csv files in USB flash drive and also imported to the welding power source.

No.	Data	Backup	Import
1	Welding Condition	Enabled	Enabled
2	Internal function setting	Enabled	Enabled
3	Simplified data log	Enabled	Disabled
4	Failure log	Enabled	Disabled
5	Welding Results Control Function	Enabled	Disabled

Backup data can be used for the following applications.

- · Copying the same setting to another welding power source
- · Analyzing output waveform at the time of failure
- · Managing the error history

A CAUTION

 The backup data (electronic information) may be altered or lost when affected by static electricity, impact or repair work. Important information should also be stored as printed document.

Please note that OTC will not be liable for any alteration or loss of electronic information.

/ TIPS

- For the USB flash drive, use the version 1.0. 1.1 or 2.0 with backward compatibility.
- · The USB flash drive to be used should be formatted as FAT32.
- Compatibility of the following USB flash drives has been confirmed.

Model No.: SFU22048E3BP2T0-I-MS-121-STD (swissbit)

Part No.: 100-1820

There is software allowing you to easily display waveforms and edit welding conditions. You
can download it from our home page.

URL: https://www.daihen.co.jp/en/products/welder/software/

7.3.1 Setting of welding conditions/internal functions

The following contents can be stored in the "DAIHEN_OTC_WELDING_PRAMETER.CSV" file.

- All the welding condition data recorded in memory
- · The internal function values at the time of data backup

The current welding conditions set with the operation panel will not be saved. (If necessar , record them in memor beforehand.) The welding condition data recorded in the memor will be output in the wa that the JOB Nos. (registration Nos.) are displated in a vertical line and the parameter values in a hori ontall line.


	F	aramete	or value		Parameter of condition No.1					
	ŀ	A	Value	C		D	Е	F	G	
1	V٨	/ELDING:								
2	je	b_num	spot_tim	prf_tim		pre_iset	pre_vset	pre_uni_vse	wld_iset	wlg
3		1.	30		1	100	185	0	150	
4	9	2	30		1	100	185	0	200	$\Box / /$
5	В	-253	30		1	100	185	0	150	//
6	2		30		1	100	185	0	150	П
7		_251	30		1	100	185	Ö	150	
	\checkmark		30		1				150	7/
"-" is shown for unused condition numbers.										

Item	Description	Unit	Item	Description	Unit
job_num	JOB No.	1 to 100	wmode_H	Process information 1	(*2)
spot_tim	Arc Spot time	0.1 (s)	wmode_L	Process information 2	(*2)
prf_tim	Pre-flow time	0.1 (s)	reserve	Reserved	-
pre_iset	Initial current	1 (A)	reserve	Reserved	-
pre_vset	Initial voltage	0.1 (V)	reserve	Reserved	-
pre_uni_vset	Initial voltage (synergic)	1 (±)	ant_tim_adj	Anti-stick time adjustment	0.01 (s)
wld_iset	Welding current	1 (A)	ant_vset_adj	Anti-stick voltage adjustment	0.1 (V)
wld_vset	Welding voltage	0.1 (V)	sldwn_adj	Slowdown adjustment	3.9 (IPM) [0.1 (m/min)]
wld_uni_vset	Welding voltage (synergic)	1 (±)	up_slp_tim	Up-slope time	0.1 (s)
cre_iset	Crater current	1 (A)	dwn_slp_tim	Down-slope time	0.1 (s)
cre_vset	Crater voltage	0.1 (V)	pre_tim	Initial time	0.1 (s)
cre_uni_vset	Crater voltage (synergic)	1 (±)	cre_tim	Crater time	0.1 (s)
aff_tim	Post-flow time	0.1 (s)	Perlset	Setting change of current value	0/1 (OFF/ON)
arc_char	Arc characteristics	1 (±)	PrelsetPer	Setting of current value (initial condition)	1 (%)
arc_char2	Arc characteristics (reserved)	_	CrelsetPer	Setting of current value (crater condition)	1 (%)
pre_sens_cnst	_	_	TsCrickIset	Torch switch current adjustment	0/1 (OFF/ON)
reserve	Reserved	_	CrilsetStep1	Current increase/decrease value by single clicking	1 (A)
reserve	Reserved	_	CrilsetStep2	Current increase/decrease value by double clicking	1 (A)
reserve	Reserved	_	reserve	Reserved	_
pre_feed	Initial feeding speed	3.9 (IPM) [0.1 (m/min)]	Interval	Interval welding	0/1 (OFF/ON)
wld_feed	Welding feeding speed	3.9 (IPM) [0.1 (m/min)]	Interval_ON	Arc-ON time on interval welding	0.01 (s)
cre_feed	Crater feeding speed	3.9 (IPM) [0.1 (m/min)]	Interval_OFF	Arc-OFF time on interval welding	0.01 (s)
reserve	Reserved	_	exp_ctrl	Extended control information	_
reserve	Reserved		dummy1 to 10	Reserved	
ctrl	Sequence information	(*1)	chksum	Checksum	Checksum data

^{*1:} Crater sequence and other information is recorded.

^{*2:} Wire diameter, material, shield gas and other process information is recorded.

The internal function setting data will be output below the JOB Nos. (registration Nos.)



/ TIPS

- It is not possible to separately save the welding condition data recorded in memory and the internal function setting data. Both of the data will always be written in the "DAIHEN_OTC_WELDING_PARAMETER.CSV" file.
- When importing the backup data to the welding power source, both or either of the data above can be imported at one time.
 - "ALL": Welding condition data recorded in memory + Internal function setting data
 - "1": Welding condition data recorded in memory
 - "2": Internal function setting data

7.3.2 Simplified data log function

The welding status can be checked on a computer by sampling the data during welding and backing them up in the USB memory. Only three of the following data can be sampled. Adding to this, the "Heat input" will be displayed in column E.

- Welding current set value
- Welding voltage set value
- Wire feeding speed set value

- Welding current actual value
- Welding voltage actual value
- Wire feeding speed actual value

The data types/sampling speed should be specified in the internal function F52/F53 (data log function).

(6.7 Setting Internal Functions)

Simplified data log will be created below the "DAIHEN_OTC_Welbee $\DAT\DAT00001$ " folder. A csv file will be created per welding.

When DAIHEN_OTC_Welbee\DAT\DAT00001 folder is already existing, "DAT00002" folder will be created below the "DAIHEN_OTC_Welbee\DAT" folder and folder for the consecutive number will per created for each simplified data log.

Example: The data will be output as below when the internal function F52 is set to "1" (detected values of welding current, welding voltage and feeding speed) and F53 to "2" (100 ms).

									\rightarrow	
				A	В	С	D	E		
	1_	Time	ime [msec]		Welding current [A]	Welding current [V]	Feeding rate [m/min]			
Start of welding —	2			o	42	53.8	1.5			
	3			100	97	25.3	2.1			
	4			200	139	12.3	2.1			
	5		Ф	300	146	11.7	2.1			
	6	l E	se of tim	400	132	13.1	2.1			
	7			500	106	15.6	2.1		//	
	8	Se Se		"	600	107	16.5	2.1		$\Box II$
	9			חסיב ומי	113	16.5	2.1		$\square / /$	
	10		lap	800	117	14.9	2.1		$\Box H$	
	11	Ш	900	125	14.2	2.1		$\prod \prod$		
	12	\Box		7 1000	115	15.3	2.1		\Box	
	13		$\setminus /$	1100	125	14.6	2.1		\Box	
	14			1200	155	12.3	2.1		$\Box \backslash \backslash$	
=					141				\square	

TIPS


- The length of time that can be used for recording depends on the sampling speed. If the
 sampling speed is set to 100 ms, data of approximately five hours can be recorded. When
 the data exceeds the capacity, they will be deleted in order from the oldest. Also note that
 data will be recorded during welding only, and not recorded when there is no output.
- The simplified data log cannot be backed up. It will be deleted when the power switch is turned off.

The simplified data log can be exported even if an error code is displayed (error code is output) on the left/right digital meters. In that case, back up the data before turning off the power switch.

7.3.3 Failure log function

It is possible to record the latest ten error codes. (The data and time of occurrence will not be recorded.)

The failure log data will be recorded in the "DAIHEN_OTC_WELDING_ABN.CSV" file. The leftmost record in the table shows the latest failure log and the records are older as they are closer to the right side.



7.3.4 Welding Result Control Function

 $The following contents can be saved in the file "DAIHEN_WELDING_MONITOR_DATA_MACHINE_" ". CSV ". IN CORREST OF THE CORREST O$

- Welding machine identification Number
- · Cumulative values of Welding result control function

The values of internal function F77(Welding result control function identifications numbers) enters into "***" in the end of filename. (© 6.7.2.44 F77: Welding result control function identification numbers)

	A	В	С	D			
1	Machine No.	1			 Welding machine identification 		
2	Number of welding point	22	times		Number		
3	Wire consumption	0.22	kg				
4	Total welding time	6	min		Cumulative values of Welding		
5	welding monitor	-62	Α		result control function		
6	welding monitor	5					
7	Total operation time						
8	Total welding time	0.1	Н				

7.3.5 Backup operation


This section explains how to back up the data such as welding conditions. The data can be backed up in a USB flash drive.


/ TIPS

 The USB flash drive to be used should be formatted as FAT32. If it is formatted as FAT16 or NTFS, reformat it to FAT32.

STEP

- 1. Turn ON the power switch.
- 2. Insert the USB flash drive to the USB connector of the operation panel.
- 3. Display "BACKUP" in the MENU screen.
 - Turn the screen operation knob to place the cursor on "BACKUP", and press the knob.
 - ⇒ "ALL" or JOB No. (registration No.) is displayed on the right digital meter in a flashing mode, and the LED of "JOB" lights up.
 - ⇒ "USb" is displayed on the left digital meter.





4. Select the data to back up.

- Turn the screen operation knob further counterclockwise to display the data to back up on the right digital meter.
- \Rightarrow The display changes in order of "ALL" -> "1" -> "2" -> "3" -> "4".
- ⇒ "ALL" means that all the data ("1" to "4") available for backup are selected.
- ⇒ Details of the numbers displayed.



5. Press the screen operation knob.

⇒ Flashing of the left/right digital meter displays will stop, and the display changes to the light-up mode.



- 6. Press the screen operation knob.
 - Data backup starts. During backup, the display of right digital meter changes.
 - \Rightarrow When backup is completed, "End" will be displayed on the right digital meter.



7.3.6 Importing backup data


This section explains how to import the backup data.



 The data stored in the welding power source will be overwritten by the backup data. Make sure of it before overwriting.

STEP

- 1. Turn ON the power switch.
- 2. Insert the USB flash drive to the USB connector of the operation panel.
- 3. Display "RESTORE" in the MENU screen.
 - Turn the screen operation knob to place the cursor on "RESTORE", and press the knob.
 - "ALL" or JOB No. (registration No.) is displayed on the right digital meter in a flashing mode, and the LED of "JOB" lights up.
 - ⇒ "USb" is displayed on the left digital meter.



4. Select the data to import.

- Turn the parameter adjusting knob further counterclockwise to display the data to import on the right digital meter.
- \Rightarrow The display changes in order of "ALL" -> "1" -> "2".
- "ALL" means that all the data ("1" to "2") available for importing are selected.
- Details of the numbers displayed (\$\sigma\$ 7.3 Data Backup (Utilization of data))



5. Press the screen operation knob.

⇒ Flashing of the left/right digital meter displays will stop, and the display changes to the light-up mode.



6. Press the screen operation knob.

- ⇒ Importing the backup data starts. During backup, the display of right digital meter changes.
- \Rightarrow When importing is completed, "End" will be displayed on the right digital meter.



7.4 Initializing Welding Conditions and Internal Functions

This section explains how to initialize the welding conditions and internal functions.


If initialized, the welding conditions currently used and internal function values will return to the default (initial) setting. However, does not affect the welding conditions registered in memory.

/ NOTE

· F39 to 42 will not be initialized.




- 1. Turn OFF the power switch.
- Press and hold the WIRE INCH key and left DISPLAY CHANGE key simultaneously and turn on the power switch.
 - Hold the two keys pressed down until "End" is displayed on the left/right digital meters.
 - ⇒ Initialization starts.



- 3. Check that "End" is displayed on the left/right digital meters and turn off the power switch.
 - ⇒ The power LED switch lights off. The status returns to normal when the power switch is turned on.

7.5 Checking the Software Version and Serial Number

This section explains how to check the software version installed in the welding power source. The software version is managed as below.




There are two methods for checking: Checking at the LCD panel, and checking at the digital meter.

How to check at the LCD panel




- In the MENU screen, turn the screen operation knob to place the cursor on "PRODUCT INFORMATION", and press the knob.
 - The product information will be displayed on the LCD panel.
 - When the screen operation knob is turned, information on the peripheral equipment will be displayed ("Not connected" if not connected).
 - To return to the MENU screen after checking, press the CANCEL key.



· How to check at the digital meter



- 1. Turn OFF the power switch.
- 2. Press and hold the UNIT CHANGE key and turn ON the power switch.
 - ⇒ The Product No. is displayed on the left and right digital meters.
 - ⇒ The display changes every time the UINIT CHANGE key is pressed. (The display order of 5 or later is for manufacturer's management. It is not necessary for the user to check it.)
 - The serial number is not displayed by this method.



Display order	Display Content					
Display order	Left digital meter	Right digital meter				
1	Product No	Product No				
2	Main version	""				
3	Minor version	Minor version				
4 ""		Extended version				
5 or later	Version for management					

- 3. After checking, turn off the power switch.
 - \Rightarrow The power LED switch lights off. The status returns to normal when the power switch is turned on.

7.6 Calibration Mode

The calibration mode can be used to calibrate the current and the voltage values indicated on the digital meter of the welding source as well as the actual output current and voltage values.

/ TIPS

To calibrate the current and/or voltage value with this function, the followings are necessary:
 WB-M352: Calibrated voltmeter and ammeter, a resistance load, and a cable with a cross-section of 38 mm² or more

WB-M502: Calibrated voltmeter and ammeter, a resistance load, and a cable with a cross-section of 60 mm² or more

7.6.1 Adjustment of output current



- 1. Connect a following resistance load to the output terminal.
 - WB-M352

 $0.1\,\Omega$, $12.6\,kW$ or more (If no resistance load is applied, short-circuit between the output terminals by using a cable with a cross section of $38~mm^2$ or more.)

WB-M502:

 $0.09~\Omega$, 22.5 kW or more (If no resistance load is applied, short-circuit between the output terminals by using a cable with a cross section of 38 mm² or more.)


- The following methods can be carried out to form a short circuit.
 - (1) WB-M352:

Connect a cable, having cable connectors at both ends (Specification: DIX SK 50/Part No.: 4734-016), to the welding power source.


WB-M502:

Connect a cable, having crimp-style terminals at both ends (Specification: R80-10/Part No.: 100-1298), to the welding power source.

- (2) Directly tighten the torch side cable (for connecting to wire feeder) and base metal side cable using a bolt and nut.
- 2. Connect an external ammeter or a measuring device that can measure an output current, such as a shunt resistor.
- 3. While both DISPLAY CHANGE keys are pressed at the same time, turn ON the power switch.
 - \Rightarrow $\;$ The USER MENU will be displayed on the LCD panel.



- 4. Turn the screen operation knob to select "CALIBRATION MODE", and press the knob.
 - ⇒ "cAL cAL" is displayed on the operation panel.



- 5. Set the current setting as follows.
 - WB-M352: 350 A
 WB-M502: 500 A
- 6. Turn ON the torch switch, and measure the output voltage.

equivalent to the output current of 0.01 A.

- After measuring the output voltage, turn OFF the torch switch.
- Correct the difference between the measured value and the set value by using the values of internal functions F39 and F40.
 - When the value of F39 is "1", it is equivalent to the output current of 1 A. To increases the output current, increase the numerical value to + side.
 If the output current needs to be adjusted finely, change the value of F40. When the value of F40 is "0.01", it is
- 8. When you have adjusted the output current, turn ON the torch switch to confirm the adjusted result to the set value.
 - Make sure that the value of the output current is within the following limits.
 WB-M352: 350±1 A
 - If the current value is out of this range, readjust the values of F39/F40.
- 9. When the calibration has been completed, turn OFF the power switch of the welding power source, and then turn ON the power source again after the operation panel has completely turned off.

7.6.2 Adjustment of output voltage

WB-M502: 500±1 A



- 1. Connect a following resistance load to the output terminal.
 - WB-M352:

 0.1Ω , 12.6 kW or more

(If no resistance load is applied, open the circuit between the output terminals.)


WB-M502:

 0.09Ω , 22.5 kW or more

(If no resistance load is applied, open the circuit between the output terminals.)

2. Connect an external voltmeter and a voltage detection line to both ends of the resistance load (if no load is applied, connect to the output terminal).

- 3. While both DISPLAY CHANGE keys are pressed at the same time, turn ON the power switch.
 - ⇒ The USER MENU will be displayed on the LCD panel.



- 4. Turn the screen operation knob to select "CALIBRATION MODE", and press the knob.
 - ⇒ "cAL cAL" is displayed on the operation panel.



- 5. (If the resistance load is connected) Turn ON the torch switch, measure the voltages of the resistance load at its ends, and set the output current so that the voltage is within the range of 30.0±0.1 V.
 - ⇒ If the resistance load is not connected to the output terminals (open circuit), the maximum no-load voltage will be output, and the measured output voltage value will not change even if the output voltage setting is changed. Therefore, in this case, the output voltage is adjusted at the maximum no-load voltage.
- 6. Turn ON the torch switch, and confirm the difference between the output voltage displayed on the voltmeter and the voltage displayed on the operation panel.
- 7. Correct the difference by using the values of internal functions F41 and F42 so that the difference is within the range of ±0.1 V.
 - When the value of F41 is "0.1", it is equivalent to the output current 0.1 V. To increases the output voltage, increase the value to + side.
 If the output current needs to be adjusted finely, change the value of F42. When the value of F42 is "0.01", it is equivalent to the output current of 0.01 V.
- 8. When you have adjusted the output voltage, turn ON the torch switch to confirm the adjusted result.
 - lacktriangle Make sure that the difference between the measured value and the value indicated on the operation panel is within the range of $\pm 0.1 \, \text{V}$.
 - If the difference is out of this range, readjust the values of F41/F42.
- 9. When the calibration has been completed, turn OFF the power switch of the welding power source, and then turn ON the power source again after the operation panel has completely turned off.


7.7 System Setting

Sets the "Font Size" of the HOME screen as well as the "LCD Background" and "Language" of all screens.




- 1. Select "SYSTEM SETTING" on the MENU screen.
 - Turn the screen operation knob to place the cursor on "SYSTEM SETTING", and press the knob.
 - ⇒ The menu of SYSTEM SETTING will be displayed.






- 2. Select the parameter that needs to be set.
 - Turn the screen operation knob to place the cursor on the parameter that needs to be set, and press the knob.
 - Font Size



- Turn the screen operation knob to select the Font Size from "Standard" and "Large", and press the knob.
- Language



 Turn the screen operation knob to select the language, and press the knob. LCD Background



Turn the screen operation knob to select the background color (White, Black). The background color will switch every time the knob is pressed.

Chapter 8 Maintenance and Inspection

This chapter explains the daily and periodical inspection of the welding power source.

8.1 Precautions for Maintenance and Inspection

This section explains the precautions for maintenance and inspection work.

To prevent electric shock or burn injury, ensure to follow the instructions below:



⚠ WARNING

- Do not touch the input and output terminals and the internal live electrical parts of the welding power source.
- Perform periodical maintenance and repair damaged parts if any before use.
- Maintenance, inspection and repair should be performed by qualified persons or persons familiar with the Welding power source.
- Before starting maintenance and inspection, make sure to cut the input power with the
 disconnect switch in the box connected with the welding power source and wait three
 minutes or more.
 - The capacitors may be still charged even after the input power is cut. Make sure that there is no charged voltage before starting the work.
- During maintenance and inspection, take an appropriate measure to prevent turning on the input power.
 - Special attention is necessary because the welding power source contains many parts connected to the input side due to its high-frequency inverter method.
- Periodically blow the parts of welding power source with dry compressed air to remove dust.

Powder dust accumulating inside may cause insulation deterioration, resulting in electric shock or fire.



A CAUTION

 Before maintenance and inspection, wait until the temperature inside the welding power source becomes low.

The main circuit parts such as DC reactor and heat sink are hot just after welding. Touching them accidentally may cause burn injury.

To prevent being caught/pinched by the rotating parts, ensure to follow the instructions below:



⚠ WARNING

- Removing the cases for maintenance, inspection or repair should be performed by
 qualified persons or persons familiar with the Welding power source. Also put up a
 barrier around the Welding power source or take other necessary measure to prevent
 other people from getting in the nearby area.
- Keep your hands, fingers, hairs and clothes away from the rotating cooling fan and the open parts around the cooling fan;

To prevent damage and problem of the welding power source and loss of the data, ensure to follow the instructions below:

A CAUTION

- The welding conditions (electronic data) stored by this function are susceptible to
 occurrence of static electricity, impact, repair, etc., and there is a possibility that the
 stored contents may be changed or lost. Important information should also be stored
 as printed document.
 - Please note that OTC will not be liable for any alteration or loss of electronic information.
- When cleaning the welding power source, do not expose the cooling fan directly to compressed air.
 - Otherwise powder dust may get inside the cooling fan. Also the cooling fan may rotate at high speed due to compressed air, resulting in wearing of the bearing.
- When using a vacuum cleaner to remove powder dust accumulating on the welding power source, do not vacuum between the rotating part of cooling fan and the main body.
 - Otherwise lubricant of the bearing of cooling fan may also be removed, resulting in failure or shorter service life of the cooling fan.

8.2 Daily Inspection

This section explains the daily inspection of the welding power source. Perform daily inspection for the following items in the table.

The front and rear panels and the fan of the welding power source is made from polycarbonate resin. To prevent from electric shock or fire caused by the damage on polycarbonate resin, ensure to follow the instructions below.



and degrade the strength.

- Before performing daily inspection, refer to "8.1 Precautions for Maintenance and Inspection".
- If there is dirt on plastic parts, soak a soft cloth in water, alcohol or neutral detergent, wring it well and wipe off the dirt.
 Do not use organic detergent or chemical agent. Doing so may cause crack (breaking)
- If there is any abnormality in the plastic parts such as front panel, rear panel and fan, immediately stop the use and contact your dealer.

Daily inspection item	Content
Status of the grounding cable	 Check that the grounding terminal on the back of the welding power source is securely grounded. (If it is not grounded, electric shock/failure/malfunction may occur.)
Chatter of achies	Check that there is no abnormal heat generation in cable connections.
Status of cables	Check that cable connections are not loose.
(Primary power cable for facility side, cables for base metal side/torch side, torch cable, voltage detection cable, etc.)	Check that there is no problem in the insulation method between the cables and base metal.
l strage detection easily easily	Check that cables are not cut or damaged.
Appearance of the welding power source	 Check that there is no abnormality such as crack in plastic parts of the welding power source.
Noise/vibration/odor generated from the	Check that there is no sound of metal, abnormal vibration or burnt odor inside the welding
welding power source	power source.
Status of the cooling fan	 Check that the cooling fan smoothly rotates when the power switch is turned on. (There should not be sound of metal, abnormal vibration or burnt odor.) While the cooling fan is rotating, air is ventilated from the slits on the front and rear of the welding power source.
Status of the operation panel/torch switch	Check that the keys on the operation panel and the torch switch work normally.
Status of the primary power voltage for facility side	Check that there is not large fluctuation in the primary power voltage.

8.3 Periodical Inspection

This section explains the periodical inspection of the welding power source. Check the items in the table below every three (3) to six (6) months.



 Before performing maintenance and inspection, read the instructions in "8.1 Precautions for Maintenance and Inspection" and "8.2 Daily Inspection".

A CAUTION

- When cleaning the welding power source, do not expose the cooling fan directly to compressed air.
 - Otherwise powder dust may get inside the cooling fan. Also the cooling fan may rotate at high speed due to compressed air, resulting in wearing of the bearing.

Periodical inspection item	Inspection work
Grounding wire	
Each cables	
(Primary power cable for facility side, cables for base metal side/torch side, torch cable, voltage detection cable, etc.)	Refer to the description for the same item in "8.2 Daily Inspection".
Welding torch	Check that there is no deterioration, damage or other abnormality in consumable parts of the welding torch. Abnormality in consumable parts can prevent smooth wire introduction.
Cleaning inside the welding power source	Blow with dry compressed air from the front slit (ventilation hole) to the back side to remove dust inside the welding power source. Dust accumulating on the heat sink of transistor and rectifier may prevent heat radiation, adversely affecting the transistor. Also, accumulation of dusts between the winding of transducer could deteriorate insulation. Compressed air
Cleaning inside the welding power source (When an abnormal temperature error code is displayed)	Dust accumulating on the fin or winding of heat sink can cause insufficient heat radiation. Remove the left side panel and fan frame and check the dirt inside. If there is heavy dirt, blow the fin and coils of heat sink directly with compressed air to remove dust inside. WB-M352 WB-M502 Fan frame Connector Fan frame Fan frame Fan frame Heat sink

8.4 Periodical Replacement Parts

This section explains the parts to be replaced periodically.

Printed circuit board PCB7 (\$\sigma\$ 10.1 Parts List)
 The printed circuit board PCB7 inside the welding power source has a high voltage electrolysis capacitor.
 The high voltage electrolysis capacitor supplies stable direct current to the inverter circuit, but its performance will degrade year by year.

If the printed circuit board PCB7 is used for an extended period without being replaced, it may result in performance degradation of the welding power source and damage of the high voltage electrolysis capacitor or other parts. It is recommended to replace the printed circuit board PCB7 every five years.

For replacement of the printed circuit board PCB7, contact your dealer.

↑ CAUTION

- Even if the part is replaced by the user, please contact your dealer.
- When inserting the connector to the printed circuit board, check that the number printed on the printed circuit board is the same as the number indicated on the connector, and insert firmly to the end.
- Do not turn on the power switch of welding power source when the connector of printed circuit board is disconnected.
- Others

Fan, relay, and rated power supply has a certain lifetime; they are recommended to be replaced once in approximately five years.

When replacement of fan, relay, and rated power supply is necessary, please contact your dealer.

8.5 Insulation Resistance Measurement and Withstand Voltage Test

If insulation resistance measurement and withstand voltage test is necessary, please contact your dealer.

↑ WARNING

- The customer MUST NOT perform the withstand voltage test. If withstand voltage test is necessary, ensure to contact your dealer.
- Insulation resistance measurement should be conducted by qualified persons or
 persons familiar with the welding machine. Also, fence and other necessary measures
 should be taken around the welding machine to prevent other people from getting in
 the nearby area.

CAUTION

- Conducting insulation resistance measurement by customer may result in injury or equipment failure. For insulation resistance measurement, be sure to ask your dealer.
- When measuring insulation resistance and testing withstand voltage, follow the steps below.
 Refer to the schematic diagram, parts layout, and parts list for maintenance.
 - Disconnect the input power cable and grounding cable from the disconnect switch and short-circuit the input terminal.
 - Short-circuit the positive (+) and the negative () sides of the output terminal.
 - Unground all the case grounding cables (line No.80, total of 6 positions) and insulate them with insulation tape.
 - For DR1, 2, and 4, short-circuit the AC side and positive (+) output side, and short-circuit the AC side and negative (-) output side.
 - Short-circuit between TR1 (C1) and (E1C2), TR1 (E1C2) and (E2), TR3 (C2) and (E2), TR5(C) and (E), TR6(C) and (E).
 - Apply NF.
 - After finishing insulation resistance measurement, return the above to the original state.

CAUTION

 After finishing insulation resistance measurement, it is necessary to remove the shortcircuit cables and return the welding power source to the original state.
 If the power is turned on without returning it to the original state, the welding power source will burn out.

Chapter 9 Troubleshooting

This chapter explains the typical troubleshooting for the welding power source.

The cause of problems can be categorized as below:

- Mechanical problems (e.g., problems of driving mechanism of the wire feeder)
- Electric and control problems
- Operational errors

A problem may become complicated as a result of mix of multiple causes. If a problem has occurred in the welding power source, it is necessary to identify its cause and address it appropriately.

For question concerning problems, contact your dealer.

9.1 Action in Case of Error

This section explains the causes of abnormalities displayed on the operation panel and how to cope with them. If any error occurs in the welding power source, the operation panel will indicate it as below:

- · An error message is displayed on the LCD panel
- An error code flashes on the left/right digital meters

The welding power source may stop or may not stop output depending on the type of error code. The meanings of (*1) and (*2) in the table below are as follows.

- *1: When the error occurs, the welding power source stops the output.
- *2: Even when the error occurs, the welding power source does not stop the output. To stop the output, set the internal function F19 to "ON". (\$\infty\$ 6.7.1 Setting procedure)

 Details on the internal function F19 (\$\infty\$ 6.7.2.15 F19: Switching alarm setting)

Check the error code displayed and take an appropriate action according to the table below. (If the welding power source is combined with robots manufactured by OTC, see the instruction manual of the robot controller.)



 Before inspecting the welding power source, make sure to read "8.1 Precautions for Maintenance and Inspection".

CAUTION

If an error code not listed in the table is displayed, write it down on paper, turn off the
power switch and contact your dealer.
 Do not turn on the power switch because it may indicate a serious problem of the

Do not turn on the power switch because it may indicate a serious problem of the welding power source.

Error	code	Error cause	Action and how to cancel error
E-	000	There is no load between the STOP terminals (*1)	 Identify the cause of no load between the STOP terminals (3-4) of the terminal block TM3 for external connection. How to clear the error code indication differs depending on the setting of internal function F4. (6.7.2.3 F4: Auto/Semi-auto mode)
E-	010	The torch switch was on when the power switch was turned on (*1)	 Check that the torch switch is not on (not pressed). If the internal functions F29 to F32 are set to "4" (activate), check also the connections of the terminal blocks for external connection. 6.7.2.22 F29 to F32: External input terminal setting) The error code will disappear when the status above is resolved.
E-	011	After torch switch was turned ON, 5 seconds have passed without arc start. (*1)	 Check that the torch switch is not ON (not pressed). Occurrence of this abnormality can be avoided by turning OFF internal function F78. If occurrence of this error is not desired, turn OFF internal function F78.) The error code will disappear when the status above is resolved.

Error	code	Error cause		Action and how to cancel error
			• (Check that the WIRE INCH key (or inching button) is not pressed.
E-	020	Inching was active when the power switch was turned on (*1)	C	f the internal functions F29 to F32 are set to "2" (inching), check also the connections of the terminal blocks for external connection. (6.7.2.22 F29 to F32: External input terminal setting)
			• 1	The error code will disappear when the status above is resolved.
E-	030 to 037	Installing the software from a USB flash drive failed (*1)	C	Check that the USB flash drive is normal and connected to the USB connector correctly, and try installing again.
E-	040	Panel Communication Error	• 1	The error code will disappear when the power switch is turned off.
E-	041	Panel Startup Timeout Error		
E-	042	Secondary Communication Error		
E-	050	Communication Error in Control Board (Primary Side HCl Communication Error: Timeout)		
E-	051	Communication Error in Control Board (Primary Side HCl Communication Error: Watchdog)		
E-	052	Communication Error in Control Board (Primary Side HCl Communication Error: Parameter)		
E-	053	Communication Error in Control Board (Primary Side HCl Communication Error: NAK Resending Over)		
E-	054	Communication Error in Control Board (Primary Side HCl Communication Error: Application Parameter)		
E-	055	Communication Error in Control Board (Secondary Side HCl Communication Error: Timeout)		
E-	056	Communication Error in Control Board (Secondary Side HCl Communication Error: Watchdog)	• (Contact your dealer.
E-	057	Communication Error in Control Board (Secondary Side HCl Communication Error: Parameter)		
E-	058	Communication Error in Control Board (Secondary Side HCI Communication Error: NAK Resending Over)		
E-	059	Communication Error in Control Board (Secondary Side HCl Communication Error: Application Parameter)		
E-	074	USB Communication Error (USB File Error)		
E-	075	USB Communication Error (USB File Error)		
E-	078	USB Communication Error (USB Initialization Error)		
E-	094	MPC Zero Point Deviation Error		
E-		MPC Parameter Setting Error		
E- E-	096 097	MPC Communication Error Initial Data Not Set to MPC (Instantaneous Power Failure)		
E-	098	MPC Alarm		
E-	099	Gas Flow Rate Warning		
E-	100	Error of control power (*1)	a	f cables are drawn out of the welding power source, check that there is no abnormality (e.g., short-circuit) in the cables.
_	440	Control Dower Eciliero		The error code will disappear when the power switch is turned off.
E- E-	150	Control Power Failure The input voltage for primary side exceeded	• (Contact your dealer. Check that the input voltage for primary side is in the following range. NB-M352: 208/230/460 V ±10% NB-M502: 460 V ±10%
		the allowable range (*1)		NB-M502: 460 V ±10% The error code will disappear when the power switch is turned off.

Error	code	Error cause	Action and how to cancel error
E-	155	WB-M352: The input voltage for primary side was out of allowable range from 265 to	Check that the input voltage for primary side is the range of (208/230/460 V ±10%).
		320 V (*1)	The error code will disappear when the power switch is turned off.
E-	160	The input voltage for primary side fell below the allowable range (*2)	Check that the input voltage for primary side is in the following range. WB-M352: 208/230/460 V ±10% WB-M502: 460 V ±10% Check the set value of internal function F20. (6.7.2.16 F20: Low input voltage detection level)
			The error code will disappear when the power switch is turned off.
E-	200	Primary Current Detection Circuit Failure	Contact your dealer.
E-	210	The arc voltage was not detected (*1)	 Check that the power cables such as cables for base metal side and torch side and the voltage detection cable are not disconnected. The error code will disappear when the power switch is turned off.
E-	220	Primary Main Circuit Failure	
E-	230	Primary Main Circuit Driver Failure	
E-	240	Secondary Current Detection Circuit Failure	
E-	250	Secondary Diode Failure	Contact your dealer.
E-	260	Output Voltage Detection Circuit Failure	
E-	270	Chopper Error	
			Leave it untouched (with the power on) and operate the cooling fan for 10 minutes or more, and then turn off the power.
E-	300 to 303	The temperature inside the welding power source exceeded the allowable range (*1)	After the above, clean dusts inside the welding power source. 8.3 Periodical Inspection)
	303		The error code will disappear when the power switch is turned off.
			After recovery, be careful not to exceed the rated duty cycle.
_	310	Rotation problem of the cooling fan (*2)	Clean dusts inside the welding power source. 8.3 Periodical Inspection) (Cooling fan may not work normally due to powder dust or foreign matter.)
E-	to 313		If the problem persists, the cooling fan may be broken. Contact your dealer.
			The error code will disappear when any key of the operation panel is pressed.
_		WB-M352: When using a single phase	When using a single phase power, check that power is at 60% rated duty cycle.
E-	320	power, the power source exceeds the rated duty cycle (*1)	The error code will disappear when the power switch is turned off.
E-	331	Abnormal Temperature (Display) - Push-Pull Torch	
E-	332	Abnormal Temperature (Display) - Inline Assist Feeder	
E-	334	Duty Cycle Exceeded - Inline Assist Feeder Abnormal Temperature (Motor) - Push-Pull	
E-	340	Torch Abnormal Temperature (Motor) - Push-Pull Abnormal Temperature (Motor) - Inline	Contact your dealer.
E-	341	Assist Feeder	
E- E-	400	HID device startup error HID device termination error	
E-	401	HID device termination error HID device driver initialization error	
E-	500	Lack of water pressure (*1)	Check for water leakage from the cooling water hose and ensure that sufficient cooling water is available. When using the air-cooled torch, check that LED of the TORCH key on the operation panel is off. Check that the condensing water hose is connected to the rear of the welding
			power source, instead of the feeding water hose.
E-	615	Error of the backup memory data (*2)	 The error code will disappear when any key of the operation panel is pressed. At the time, the welding conditions specified/registered and the settings of internal functions may be initialized. After the error is cleared, check that there is no problem in the data.

Error	code	Error cause	Action and how to cancel error			
			Check that the tip at the end of torch is not contacting the base metal.			
E-	700	An over current was detected at the output side of the welding power source (*1)	Check that the power cables such as cables for base metal side and torch side are not short-circuited.			
			The error code will disappear when the power switch is turned off.			
_	740	The phase W of input voltage for primary	Check that there is no problem in input voltage for primary side and in cable wiring			
E-	710	side is not connected (*1)	The error code will disappear when the power switch is turned off.			
			Check that there is no disconnection, short-circuit or other abnormalities in the			
	800	The rotation rate of the motor of wire feeder	cables connecting the wire feeder.			
E-	801	was not detected (*1)	Check that there is no problem in the wire feeder.			
			The error code will disappear when the power switch is turned off.			
E-	802	Push-Pull Torch Encoder Error	The error code will disappear when the power switch is turned on.			
E-	803	Inline Assist Feeder Encoder Error	Contact your dealer.			
	003	The temperature of the governor circuit	Check that the wires are not stuck or there are no other abnormalities in the			
		exceeded the allowable range (*1)	welding torch or wire feeder.			
E-	810		The error code will disappear when the power switch is turned off.			
_	020		· ·			
			 The "E-820" indication will disappear when any key of the operation panel is pressed. 			
	_	Printed Circuit Board Push-Pull Torch				
E-	811	(Driver) Error	Control of the Control			
E-	812	Printed Circuit Board Inline Assist Feeder	Contact your dealer.			
	012	(Driver) Error				
			Check that the wires are not stuck or there are no other abnormalities in the			
		The current in the wire feeder motor	welding torch or wire feeder.			
E-	820	exceeded the warning level (*2)	The error code will disappear when the power switch is turned off.			
			The "E-820" indication will disappear when any key of the operation panel is			
			pressed.			
E-	821	Push-Pull Torch Motor Overload Warning	Contact your dealer.			
E-	822	Inline Assist Feeder Motor Overload Warning	,			
		The current in the wire feeder motor exceeded the WARNING detection level (*1)	Check that the wires are not stuck or there are no other abnormalities in the welding teach anything fooder.			
_			welding torch or wire feeder.			
E-	830		The error code will disappear when the power switch is turned off.			
			The "E-820" indication will disappear when any key of the operation panel is			
	004	Durch Dull Touch Mater Outres and France	pressed.			
E-	831	Push-Pull Torch Motor Overcurrent Error				
E-	832	Inline Assist Feeder Motor Overcurrent Error	•			
E- E-	850	Wire Feeder 24 V Power Source Failure				
E-	861	Wire Feeder 48 V Power Source Failure Push-Pull Torch 48 V Power Source Failure				
L-	301	Inline Assist Feeder 48 V Power Source				
E-	862	Failure				
E-	900	Software Error: Stack Overflow				
E-	901	Software Error: Watchdog				
E-	902	Software Error: DataAbort				
E-	903	Software Error: No Cause of Interrupt	Contact your dealer.			
E-	904	Software Error: Flash Overwrite	Some System doubles			
E-	905	Software Error: I2C Timeout				
E-	906	Software Error: EEPROM Timeout				
E-	907	Software Error: DSP software Error				
E-	910	Software Error: No Space in Memory Pool				
E-	911	Software Error: Excess Memory Pool Size				
E-	912	Software Error: Access error to data				
E-	020	structure Findbus Communication Error: Watchdoo				
	920	Fieldbus Communication Error: Watchdog Fieldbus Communication Error: NAK				
E-	921	Resending Over				

Error	code	Error cause	Action and how to cancel error
E-	922	Fieldbus Communication Error: No Connection	Contact your dealer.
E-	950	CAN Bus Off Error	
E-	951	There is a duplicate ID on a single bus (*1)	Turn off the power switches of all other CAN-connected welding power sources, then turn on the power switches and check the setting of internal function F43. (6.7.2.26 F43: CAN ID)
			The error code will disappear when the power switch is turned off.
E-	952	CAN Error	
E-	953	CAN Received Data Error	
E-	954	CAN Error Buffer Overflow	
E-	955	CAN Power Source Type Mismatch	
E-	956	CAN Sending/Receiving Memory Error	Contact your dealer.
E-	957	CAN Error Timeout	
E-	958	CAN Error Command Receipt	
E-	959	No CAN Error Connection	
E-	961	Push-Pull Torch Communication Error / Inline Assist Feeder Communication Error	

9.2 Troubleshooting

This section explains the typical problems other than the error codes, their causes, and how to cope with them. Check the table below before requesting repair service.

MARNING

• Before inspecting the welding power source, make sure to read "8.1 Precautions for Maintenance and Inspection".

No.	Problem	Possible cause	Corrective action
1	The power switch has tripped.	Leak has occurred in the welding power source.	DO NOT turn on the power switch. Contact your dealer.
3	The power LED switch does not light even when the power switch is turned on. Nothing is displayed on the left/right digital meters even when the power switch is turned on.	The primary power source is not supplied.	Supply the primary power source in the following range. WB-M352: $208/230/460~V~\pm10\%$ WB-M502: $460~V~\pm10\%$
4	An error code is displayed when the power switch is turned on.	The protection circuit has been activated due to temperature error.	Leave it untouched (with the power on) and operate the cooling fan for 10 minutes or more, and then turn off the power. After the above, clean dusts inside the welding power source.
		The valve of gas cylinder is closed.	Open the gas valve.
		The pressure of gas cylinder is insufficient.	Replace the gas cylinder.
5	Shield gas is not flowing.	Setting/handling of the external inputs is not correct.	Check that the setting of internal functions F29 to F32 is correct. (© 6.7.2.22 F29 to F32: External input terminal setting)
		The external input cables are disconnected/short-circuited.	Check that there is no abnormality in the cables connected to the external input terminal block. If any, repair/replace the cables.
6	Shield gas does not stop flowing.	Setting/handling of the external inputs is not correct.	Check that the setting of internal functions F29 to F32 is correct. (6.7.2.22 F29 to F32: External input terminal setting)
Ü		The external input cables are disconnected/short-circuited.	Check that there is no abnormality in the cables connected to the external input terminal block. If any, repair/replace the cables.

No.	Problem	Possible cause	Corrective action
7	Arc does not generate even when the setting of welding conditions is	Connection of the torch cable is loose.	Securely connect the torch cable.
	correct. (w/o no-load voltage)	The torch switch is broken.	Check that the torch switch works normally.
		The automatic machine mode is selected.	Check that the setting of internal functions F4 is correct. (67.2.3 F4: Auto/Semi-auto mode)
8	Setting of current/voltage is not possible.	An analog remote control (optional) is connected.	When an analog remote control (optional) is connected, the setting of the remote control has priority.
		The encoder is broken.	The printed circuit board PCB2 (P30304R00) needs to be replaced. Contact your dealer.
9	Operation of the CRATER-FILL menu is not possible.	The internal function F4, F48 or F51 is set to "ON".	Turn the settings to "OFF".
10	The welding conditions cannot be set with the operation panel. The welding mode does not change even when switched with the operation panel.	The erroneous prevention function to prevent malfunction of the operation panel is enabled. (Erroneous operation prevention function)	Release the KEY LOCK to disable the erroneous operation prevention function the operation panel.
		The setting of welding mode is not correct.	Check the settings of wire diameter, wire materials and shield gas.
11	Arc is unstable.	The wire is defective or there is a failure in wire feeding.	Check that there is no problem in the wire or wire feeder. (5.2 Check before Welding)
		Connection of the voltage detection cable is not correct.	Check that connection of the voltage detection cable is correct.
		There is noise in the voltage detection cable.	Adjust the arc characteristics to the plus side.
12	Wire is not fed (no error code is	The pressure roll of wire feeder came off.	Set correctly the pressure roll of wire feeder. (For setting, see the instruction manual of the wire feeder.)
12	displayed).	There is an abnormality in cables of the wire feeder.	Check that there is no abnormality in cables of the wire feeder.
13	There are blowholes.	There is a problem in the shield gas.	Check that there is no abnormality in the gas cylinder or gas hose.
		The tip of the welding torch wore out.	Replace the tip.
14	Continuous output of the WCR signal is shown on the monitor of the robot. (The WCR signal is used for communicating with the robot to check the presence of the welding current.)	The WCR relay of welding power source is broken.	The WCR relay on the printed circuit board PCB1 (P30099P00) needs to be replaced. Contact your dealer.
15	The password is lost.	-	Contact your dealer.

Chapter 10 Reference Materials

This chapter contains the parts list of welding power source, and reference materials for setting the welding conditions.

10.1 Parts List

This section shows the parts list of welding power source.

• When placing an order, provide your dealer with the necessary information: the model name of welding power source, the name of the part to be replaced, and the part number (or specifications if part has no number).

The period of supplying parts will be at the shortest approximately seven years after the welding power source is manufactured. It may change, however, if the parts from other companies cannot be supplied.

· The codes in the table correspond to those in the schematic diagram/parts layout drawing.

0	D- 421	B1	0	Q	Q'ty	
Code	Part No.	Product Name	Specifications	WB-M352	WB-M502	Remarks
NF	100-1683	Circuit protector	IULK-1-111-62F-75A-AC480V	1	-	
INF	100-1568	- Circuit protector	CA3-X0-19-177-41D-C	-	1	
DI 4	4600-341	Dilatiana	N20010A7SW	1	-	
PL1	100-0171	Pilot lamp	N46010A7KW-01 ROHS	-	1	
DR1	100-1938	Diode module	PGH150N16 1 1			
DR2 to 5	4531-308	Diode module	DBA200UA60	4	-	
DR2 to 6, 8 to 11	4531-119	Diode module	DSEI 2X101-06A	-	9	
DR6	100-0179	Diode module	DSEI 2X101-12A	1	-	
DR7	4531-505	Diode	S2L60	1	1	
TD4 + 4	4534-416	IODT	CM100DUS-12F	4	-	
TR1 to 4	100-1750	- IGBT module	CM300DU-12NFH	-	4	
TR5	100-2219	IGBT module	1MBI300HH-120L-50	1	-	
0054	4530-137	The state of	SG25AA60	1	-	
SCR1	4530-412	Thyristor	SG25AA20	-	1	
CT1	4810-030	Current transformer	W-W03029	1	1	
CT2	100-0956	Hall current detector	CS-40GEH	1	1	
CT3	4810-030	Current transformer	W-W03029	1	-	
T1	P30086B00		P30086B00	1	-	
T1, T2	P30089B00	Inverter transformer	P30089B00	-	2	
T2	W-W03830	Auxiliary transformer	W-W03830	1	-	
T3	W-W03674	Auxiliary transformer	W-W03674	-	1	
	P30086L00		P30086L00	1	-	
L1	P30089L00	Input reactor	P30089L00	-	1	
	P30087C00		P30087C00	1	-	
L2	P30089C00	DC reactor	P30089C00	-	1	
L3	100-1950	Ferrite core	TW70W(R402715)	2	1	
L4 to 5			, , , , , , , , , , , , , , , , , , , ,	2	-	
L4 to 7	100-2321	Ferrite core	TW70W(R311019)	-	4	
L6	100-0620	Ferrite core	SN-20 OR 23.5×9.5×12.6	1	-	
L7	P30139C00	Reactor	P30139C00	1	-	
L8	100-1950	Ferrite core	TW70W(R402715)	1	-	
L8, 9,11	100-0618	Ferrite core	HM2AT4815	-	3	
L10	100-0620	Ferrite core	SN-20 OR 23.5×9.5×12.6	-	2	
THP1	4614-051	Thermostat	67L090	-	1	
	4258-046		US-602AXTTL 120 °C	1	-	
THP2	100-1824	Thermostat	US-602SXTTAS 140 °C	-	1	
THP3	4614-057	Thermostat	67L080	1	-	
FM1 to 3	100-3207	Fan	9WV1224P1H003-X	3	3	
FM4	K5791K00	Fan	K5791K00	1	1	
	4403-134	-	SH400A/60mV	1	-	
SH		Meter shunt				
SH	4403-132	Weter shall	SH600A/60mV	_	1	

		T		1 0	14	
Code	Part No.	Product Name	Specifications	Q'ty WB-M352 WB-M502		Remarks
R5 to 10				6	-	
R5 to 10, 20, 21	100-0234	Carbon resistor	RD20S 1kΩJ	-	8	
R11, 12 R11 to 14	100-1430	Metal film resistor	RPM200Z 5Ω	2	- 4	
R16	4509-916	Cement resistor	T20SH 2.2ΩJ	1	1	
R17	100-0234	Carbon resistor	RD20S 1kΩJ	1	1	
R18	100-0662	Thermistor	EC2F103A2-40113	1	1	
R19a, b	100-1432	Winding resistor	FHN50 471J/R0	2	2	
R20, 21	100-2035	Cement resistor	RX27-4V-20W-15kΩ-J	2	-	
R22	100-1571	Winding resistor	CS1P 100ΩJ	1	1	
R23	4509-918	Cement resistor	40SH 200ΩJ	1	1	
R24	100-0234	Carbon resistor	RD20S 1kΩJ	1	1	
R26	100-0234	Carbon resistor	RD20S 1kΩJ	1	-	
R27	100-2224	Metal film resistor	RPM200Z A2.5ohm J Z00	1	_	
R29	100-2225	Metal film resistor	RPM200Z A20ohm J Z00	1	_	
		Fixed metal oxide film				
R30	100-4022	resistor	MOS5C L30A 913J	1	-	
C1 to 4	100-1433	Ceramic capacitor	DEBE33D222ZA2B	4	4	
C5, C6	100-1434	Film capacitor	FHC(180)2000V682J	2	-	
C5, 6, 9, 10			1, 11, 11, 11	-	4	
C7, 10	100-0227	Film capacitor	0.47uF 50V	2	-	
C7, 11		,		-	2	
C8	4511-512	Electrolysis capacitor	LQA2C222MSMEZO	1	1	
C9	100-1572	Film capacitor	FHC(180)2000V103J	1	-	
C11, 12	100-2226	Electrolysis capacitor	ECST401LGB332MDD0M	2	-	
C12	100-1572	Film capacitor	FHC(180)2000V103J	-	1	
C13	4514-206	Film capacitor	US20X472JAASA	1	-	
C14	100-2227	Film capacitor	US20X682JAASA	1	-	
CON1	100-1435	Receptacle	DPC25-10BP	1	1	
CON2	4730-010	Receptacle	DPC25-6BP-Z	1	1	
TM5	4739-141	Terminal board	T-3(Black)	1	1	
TM6	100-2228	Input terminal block	DSTB22-04	1	1	
F1	100-2229	Fast acting fuse	750GH-125SUL	1	-	0.1.1.0004.1/
DCV1	K5791B00	Power supply	K5791B00	1	1	Output DC24 V
DCV2	K5791C00	Power supply	K5791C00	1	1	Output DC48 V
PCB1	P30099P00 4341-206	Printed circuit board	P30099P00	1	1	(*1)
PCB2	P30304R00	Relay Printed circuit board	G6A-274P DC24V P30304R00	1	1	With PCB1
FUB2	100-2518		RE1201XE1-H01	1	1	With PCB2
	100-2518	Encoder LCD Modulo	GWMS16545	2	2	With PCB2
PCB3	P30086Q00	LCD Module Printed circuit board	P30086Q00	1	1	WILLI FUBZ
PCB3 PCB4	P30086Q00 P30087Q00	Printed circuit board Printed circuit board	P30086Q00	1	1	
PCB4 PCB5	P30087Q00 P30086V00	Printed circuit board Printed circuit board	P30087Q00	1	1	
1.000	P30086V00	i inteu circuit boalu	P30086V00	1	_	
PCB6	P30087V00	Printed circuit board	P30086V00	-	1	
	P30086M00		P30086M00	1	-	
PCB7	P30115M00	Printed circuit board	P30115M00	-	1	
PCB8	P30086T00	Printed circuit board	P30086T00	1	1	
PCB9	P30087T00	Printed circuit board	P30087T00	1	1	
PCB10	P30086S00	Printed circuit board	P30086S00	1	1	
PCB11	P30200X00	Printed circuit board	P30200X00	1	-	
	100-3888			1	-	
(1)	100-3889	Mold cover	P30086G01	-	1	Upper side cover
(2)	P30086G02	Mold cover	P30086G02	1	2	Under side cover
(3)	P30344W02	Operation panel sheet	P30344W02	1	1	
` '		1			1	1

Code	Part No.	Product Name	Specifications	Q'ty		Remarks	
Code	Fait No.	Floduct Name	Specifications	WB-M352	WB-M502	nomana	
(4)	W-W03636	Сар	W-W03636	1	1	For P30086G01	
(5)	100-2456	Receptacle	CX0058	2	-		
(3)	100-1836	Песеріасіе	EDZ120b(B)-1(ROHS)	-	2		
(6)	W-W03829	Handle cover	W-W03829	1	-	For NF	
(0)	100-1736	Handle cover	899-35054-001	-	1	101111	
(7)	4739-476	Сар	W-W02814	2	2	For CON1, 2	
(8)	4735-038	Knob	K-100 22RSB	2	2	Parameter adjusting knob	
(9)	4735-039	Сар	K-100 22CSBL	2	2		
(10)	100-0201	Fixed type caster	420SR-RD50	4	4		
(11)	100-2231	Blind bushing	BB-1187B	4	4		
(12)	100-3665	Rear cover	P30086G13	1	1		
(13)	100-3670	Side cover (left)	P30115G15	1	1		
(14)	100-3674	Side cover (right)	P30099G17	1	1		
(15)	100-3675	Top cover	P30086G18	1	1		
(16)	W-W03784	Socket cover	W-W03784	-	1		
(17)	K5804Q00	Resin panel	K5804Q00	1	1		

^{*1:} When placing an order of a printed circuit board P30099P00, provide us the following No.

- Serial No. shown on the nameplate on the front or rear of the welding power source
- Software version No. shown on the indication panel (under the input terminal block) at the rear of the welding power source

The welding power source needs to be set various adjustment functions (Calibration function) for each product. Contact your dealer.

Analog remote control parts list (K5804S00) (Optional)


Code	Part No.	Product Name	Specifications	Q'ty	Remarks
Iset, Vset	4501-039	Variable resistor	RV24YN20SB 5kΩ	2	
	100-0487	Carbon resistor	RD20S 12ΩJ	1	
	4531-710	Diode	D1N60	2	
INCH	4750-077	Push switch	A2A-4R	1	
	4735-013	Knob	K-2195 (middle)	2	
CON2	4730-009	Metal connector	DPC25-6A-1H-Z	1	
	3361-655	Knurled screw	N-3 M5L=10 (black)	1	
	4252-013	Rotary switch	SRF-113-Z	1	
	K5804S01	Remote control box lid	K5804S01	1	For 200 A
	K5804S02	Remote control box lid	K5804S02	1	For 350 A/500 A


10.2 Reference Drawing

This section contains the schematic diagram and the parts layout drawing of the welding power source.


10.2.1 Schematic diagram


• WB-M352






WB-M502






10.2.2 Parts layout drawing

• WB-M352



• WB-M502



10.3 Materials for Setting Welding Conditions

This section provides reference information for setting the welding conditions.

10.3.1 Guide for changing welding conditions

This section gives examples of the problems that can occur due to improper welding conditions.

Problem	Symptom
	The arc length becomes long.
The wire feeding length is too long.	The bead width becomes wide.
	Shielding becomes poor.
The wire feeding length is too short.	The arc length becomes short.
The wife reeding length is too short.	Spatter is generated.
	The arc length becomes long.
The welding voltage is too high.	The bead width becomes wide.
	Penetration and bead become small.
The welding voltage is too low.	The wire contacts the base metal and spatter is generated.
The welding voltage is too low.	The bead width becomes narrow.
The welding current is too high.	The bead width becomes wide.
The welding current is too night.	Penetration and bead become large.
The travel speed is too high.	The bead width becomes narrow.
The traver speed is too night.	Penetration and bead become small.

10.3.2 Samples of welding condition settings

This section provides samples of common welding condition settings.

The values are for reference purpose. Adjust them according to the shape of actual weld zone and position of welding.

10.3.2.1 Example of CO, welding conditions

Example of welding conditions of horizontal fillet




Plate thickness t [in. (mm)]	Leg length L [in. (mm)]	Wire diameter [in. (mm) Φ]	Current (A)	Voltage (V)	Travel speed [IPM (cm/min)]	CO ₂ gas flow rate [CFH (L/min)]
18 ga. (1.2)	3/32 to 1/8 (2.5 to 3.0)	035, .040 (0.9, 1.0)	70 to 100	18 to 19	20 to 24 (50 to 60)	21 to 32 (10 to 15)
16 ga. (1.6)	3/32 to 1/8 (2.5 to 3.0)	.035 to .045 (0.9 to 1.2)	90 to 120	18 to 20	20 to 24 (50 to 60)	21 to 32 (10 to 15)
14 ga. (2.0)	1/8 to 9/64 (3.0 to 3.5)	.035 to .045 (0.9 to 1.2)	100 to 130	19 to 20	20 to 24 (50 to 60)	32 to 42 (15 to 20)
12 ga. (2.3)	1/8 to 9/64 (3.0 to 3.5)	.035 to .045 (0.9 to 1.2)	120 to 140	19 to 21	20 to 24 (50 to 60)	32 to 42 (15 to 20)
1/8 (3.2)	1/8 to 5/32 (3.0 to 4.0)	.035 to .045 (0.9 to 1.2)	130 to 170	19 to 21	18 to 22 (45 to 55)	32 to 42 (15 to 20)
11/64 (4.5)	5/32 to 11/64 (4.0 to 4.5)	.045 (1.2)	190 to 230	22 to 24	18 to 22 (45 to 55)	32 to 42 (15 to 20)
15/64 (6.0)	13/64 to 15/64 (5.0 to 6.0)	.045 (1.2)	250 to 280	26 to 29	16 to 20 (40 to 50)	32 to 42 (15 to 20)
23/64 (9.0)	15/64 to 9/32 (6.0 to 7.0)	.045 (1.2)	280 to 300	29 to 32	14 to 16 (35 to 40)	32 to 42 (15 to 20)

Plate thickness	Leg length	Wire diameter	Current	Voltage	Travel speed	CO ₂ gas flow rate
t [in. (mm)]	L [in. (mm)]	[in. (mm) Φ]	(A)	(V)	[IPM (cm/min)]	[CFH (L/min)]
15/32 (12.0)	9/32 to 5/16 (7.0 to 8.0)	.045 (1.2)	300 to 340	32 to 34	12 to 14 (30 to 35)	42 to 53 (20 to 25)

Example for welding conditions of downward fillet





Plate thickness t [in. (mm)]	Leg length L [in. (mm)]	Wire diameter [in. (mm) Φ]	Current (A)	Voltage (V)	Travel speed [IPM (cm/min)]	CO ₂ gas flow rate [CFH (L/min)]
18 ga. (1.2)	3/32 to 1/8 (2.5 to 3.0)	.035, .040 (0.9, 1.0)	70 to 100	18 to 19	20 to 24 (50 to 60)	21 to 32 (10 to 15)
16 ga. (1.6)	3/32 to 1/8 (2.5 to 3.0)	.035 to .045 (0.9 to 1.2)	90 to 120	18 to 20	20 to 24 (50 to 60)	21 to 32 (10 to 15)
14 ga. (2.0)	1/8 to 9/64 (3.0 to 3.5)	.035 to .045 (0.9 to 1.2)	100 to 130	19 to 20	20 to 24 (50 to 60)	32 to 42 (15 to 20)
12 ga. (2.3)	1/8 to 9/64 (3.0 to 3.5)	.035 to .045 (0.9 to 1.2)	120 to 140	19 to 21	20 to 24 (50 to 60)	32 to 42 (15 to 20)
1/8 (3.2)	1/8 to 5/32 (3.0 to 4.0)	.035 to .045 (0.9 to 1.2)	130 to 170	20 to 22	18 to 22 (45 to 55)	32 to 42 (15 to 20)
11/64 (4.5)	5/32 to 11/64 (4.0 to 4.5)	.045 (1.2)	200 to 250	23 to 26	18 to 22 (45 to 55)	32 to 42 (15 to 20)
15/64 (6.0)	13/64 to 15/64 (5.0 to 6.0)	.045 (1.2)	280 to 300	29 to 32	16 to 20 (40 to 50)	32 to 42 (15 to 20)
23/64 (9.0)	15/64 to 5/16 (6.0 to 8.0)	.045 (1.2)	300 to 350	32 to 34	16 to 18 (40 to 45)	32 to 42 (15 to 20)
15/32 (12.0)	25/64 to 15/32 (10.0 to 12.0)	.045 (1.2)	320 to 350	33 to 36	10 to 14 (25 to 35)	42 to 53 (20 to 25)

Example for welding conditions of I shape butt (without backing plate)






Plate thickness t [in. (mm)]	Root opening g [in. (mm)]	Wire diameter [in. (mm) Φ]	Current (A)	Voltage (V)	Travel speed [IPM (cm/min)]	CO ₂ gas flow rate [CFH (L/min)]	Number of layers
18 ga. (1.2)	0	.035, .040 (0.9, 1.0)	70 to 80	17 to 18	18 to 22 (45 to 55)	21 (10)	1
16 ga. (1.6)	0	.035, .040 (0.9, 1.0)	80 to 100	18 to 19	18 to 22 (45 to 55)	21 to 32 (10 to 15)	1
14 ga. (2.0)	0 to 1/64 (0 to 0.5)	.035, .040 (0.9, 1.0)	100 to 110	19 to 20	20 to 22 (50 to 55)	21 to 32 (10 to 15)	1
12 ga. (2.3)	1/64 to 3/64 (0.5 to 1.0)	.035, .045 (0.9, 1.2)	110 to 130	19 to 20	20 to 22 (50 to 55)	21 to 32 (10 to 15)	1
1/8 (3.2)	3/64 to 3/64 (1.0 to 1.2)	.035, .045 (0.9, 1.2)	130 to 150	19 to 21	16 to 20 (40 to 50)	21 to 32 (10 to 15)	1
11/64 (4.5)	3/64 to 1/16 (1.2 to 1.5)	.045 (1.2)	150 to 170	21 to 23	16 to 20 (40 to 50)	21 to 32 (10 to 15)	1
15/64 (6.0)	3/64 to 1/16 (1.2 to 1.5)	.045 (1.2)	220 to 260	24 to 26	16 to 20 (40 to 50)	32 to 42 (15 to 20)	Front:1 Back:1
23/64 (9.0)	3/64 to 1/16 (1.2 to 1.5)	.045 (1.2)	320 to 340	32 to 34	18 to 22 (45 to 55)	32 to 42 (15 to 20)	Front:1 Back:1

Example for welding conditions of single and double grooves

Plate thickness t [in. (mm)]	Bevel shape	Root opening g [in. (mm)]	Root face h [in. (mm)]	Wire diameter [in. (mm) Φ]	Current (A)	Voltage (V)	Travel speed [IPM (cm/min)]	CO ₂ gas flow rate [CFH (L/min)]	N	lumber o	f									
				.045 (1.2)	300 to 350	32 to 35	12 to 16 (30 to 40)	42 to 53 (20 to 25)	ı	Front										
45 (20 (40)		0 to 1/64	5/32 to	,	,	,	5/32 to 15/64	,	,	,	,	.045 (1.2)	300 to 350	32 to 35	18 to 20 (45 to 50)	42 to 53 (20 to 25)		Back	2	
15/32 (12)	60°	(0 to 0.5)	(4 to 6)	1/16 (1.6)	380 to 420	36 to 39	14 to 16 (35 to 40)	42 to 53 (20 to 25)	ı	Front	_									
				1/10 (1.0)	380 to 420	36 to 39	18 to 20 (45 to 50)	42 to 53 (20 to 25)		Back										
	<u>√ </u>			.045 (1.2)	300 to 350	32 to 35	10 to 12 (25 to 30)	42 to 53 (20 to 25)	ı	Front										
5/8 (16)		5 () to 1/64 '	5/32 to 15/64	.045 (1.2)	300 to 350	32 to 35	12 to 14 (30 to 35)	42 to 53 (20 to 25)		Back	2									
3/8 (10)	(0 to 0.5)		(0 to 0.5)	(4 to 6)	1/16 (1.6)	380 to 420	36 to 39	12 to 14 (30 to 35)	42 to 53 (20 to 25)	ı	Front	_								
													_/ 10 (1.0)	380 to 420	36 to 39	14 to 16 (35 to 40)	42 to 53 (20 to 25)	Back		
					5/32 to 15/64 (4 to 6)	15/64	0 15/64	.045 (1.2)	300 to 350	32 to 35	12 to 14 (30 to 35)	42 to 53 (20 to 25)	I	Front						
5/8 (16)								15/64	10 10 (2.2)	300 to 350	32 to 35	12 to 14 (30 to 35)	42 to 53 (20 to 25)		Back	2				
0/0 (10)	. 60°		,	(4 to 6)					(4 to 6)	(4 to 6)	,	,	1/16 (1.6)	380 to 420	36 to 39	14 to 16 (35 to 40)	42 to 53 (20 to 25)	Front	_	
					1/ 10 (1.0)	380 to 420	36 to 39	14 to 16 (35 to 40)	42 to 53 (20 to 25)		Back									
	t)			1/16 (1.6)	400 to 450	36 to 42	10 to 12 (25 to 30)	42 to 53 (20 to 25)	I	Front	2									
3/4 (19)	60°	0	13/64 to 9/32	1/ 10 (1.0)	400 to 450	36 to 42	10 to 12 (25 to 30)	42 to 53 (20 to 25)		Back	_									
3, 1 (23)			(5 to 7)	1/16 (1.6)	400 to 420	36 to 39	18 to 20 (45 to 50)	42 to 53 (20 to 25)	1	Front/	4									
	g	g	1/10(1.0)		400 to 420	36 to 39	14 to 16 (35 to 40)	42 to 53 (20 to 25)	2 Back											
63/64 (25)		0	13/64 to 9/32	1/16 (1.6)	400 to 420	36 to 39	16 to 18 (40 to 45)	42 to 53 (20 to 25)	1	Front/	4									
33, 34 (23)	63/64 (25)	0 9/32 (5 to 7)	, , , , ,	420 to 450	39 to 42	12 to 14 (30 to 35)	42 to 53 (20 to 25)	2	Back											

Example for welding conditions of lap fillet




Plate thickness t [in. (mm)]	Wire diameter [in. (mm) Φ]	Current (A)	Voltage (V)	Travel speed [IPM (cm/min)]	Aim position	CO ₂ gas flow rate [CFH (L/min)]
18 ga. (1.2)	.030 to .040 (0.8 to 1.0)	80 to 100	18 to 19	18 to 22 (45 to 55)	А	21 to 32 (10 to 15)
16 ga. (1.6)	.030 to .045 (0.8 to 1.2)	100 to 120	18 to 20	18 to 22 (45 to 55)	А	21 to 32 (10 to 15)
14 ga. (2.0)	.040 to .045 (1.0 to 1.2)	100 to 130	18 to 20	18 to 22 (45 to 55)	A or B	34 to 42 (15 to 20)
12 ga. (2.3)	.040 to .045 (1.0 to 1.2)	120 to 140	19 to 21	18 to 20 (45 to 50)	В	34 to 42 (15 to 20)
1/8 (3.2)	.040 to .045 (1.0 to 1.2)	130 to 160	19 to 22	18 to 20 (45 to 50)	В	34 to 42 (15 to 20)
11/64 (4.5)	.045 (1.2)	150 to 200	21 to 24	16 to 18 (40 to 45)	В	34 to 42 (15 to 20)

10.3.2.2 Example of MAG short arc welding

Material: Mild steel

Gas: Ar + CO_2 mixed gas [21 to 32 CFH (10 to 15 L/min)]

Joint shape	Plate thickness t [in. (mm)]	Wire diameter [in. (mm) Φ]	Gap [in. (mm)]	Current (A)	Voltage (V)	Travel speed [IPM (cm/min)]
Butt joint _	19.5 ga. (1.0)	.030 to .040 (0.8 to 1.0)	0	50 to 55	13 to 15	16 to 22 (40 to 55)
	18 ga. (1.2)	.030 to .040 (0.8 to 1.0)	0	60 to 70	14 to 16	12 to 20 (30 to 50)
	16 ga. (1.6)	.030 to .040 (0.8 to 1.0)	0	100 to 110	16 to 17	16 to 24 (40 to 60)
	12 ga. (2.3)	.035 to .045 (0.9 to 1.2)	0 to 0 (0 to 1.0)	110 to 120	17 to 18	12 to 22 (30 to 40)
	1/8 (3.2)	.035 to .045 (0.9 to 1.2)	0 to 0.1 (1.0 to 1.5)	120 to 140	17 to 19	10 to 12 (25 to 30)
	5/32 (4.0)	.035 to .045 (0.9 to 1.2)	0.1 to 0.1 (1.5 to 2.0)	150 to 170	18 to 21	10 to 16 (25 to 40)

10.3.2.3 Example for short welding conditions of aluminum MIG

Example for welding conditions of I shape butt

Plate thickness t [in. (mm)]	Wire diameter [in. (mm) Φ]	Current (A)	Voltage (V)	Travel speed [IPM (cm/min)]	Wire feeding length [in. (mm)]	Gas flow rate [CFH (L/min)]
1/8 (3.0)	.045 (1.2)	120 to 140	20 to 22	24 to 31 (60 to 80)	0.6 (15)	42 (20)
5/32 (4.0)	.045 (1.2)	150 to 170	22 to 24	24 to 31 (60 to 80)	0.6 to 0.7 (15 to 18)	42 (20)
15/64 (6.0)	1/16 (1.6)	180 to 210	23 to 25	16 to 24 (40 to 60)	0.7 to 0.8 (17 to 20)	42 to 53 (20 to 25)

Example for welding conditions of horizontal fillet

Plate thickness t [in. (mm)]	Wire diameter [in. (mm) Φ]	Current (A)	Voltage (V)	Travel speed [IPM (cm/min)]	Wire feeding length [in. (mm)]	Gas flow rate [CFH (L/min)]
1/8 (3.0)	.045 (1.2)	140 to 160	21 to 22	24 to 28 (60 to 70)	0.6 (15)	32 to 42 (15 to 20)
5/32 (4.0)	.045 (1.2)	150 to 170	22 to 24	20 to 24 (50 to 60)	0.6 to 0.7 (15 to 18)	32 to 42 (15 to 20)
15/64 (6.0)	1/16 (1.6)	200 to 230	24 to 26	20 to 26 (50 to 65)	0.7 to 0.8 (17 to 20)	42 to 53 (20 to 25)